

BlendPRO-II

Quick Start Guide

Barco Media and Entertainment

11101 Trade Center Drive

Rancho Cordova, CA 95670 • USA Phone: +1 (916) 859-2500 Fax: +1 (916) 859-2515


Technical Support:

Websites:

+1 (866) 374-7878

www.folsom.com

www.events.barco.com



Quick Install

Signal Connection

Note: Use the system diagrams (on the other side) for reference during the following signal installation process.

- Connect Program/Preview monitoring, using ScreenPRO-II analog outputs.
- Connect Ethernet to all ScreenPRO-II units, to BlendPRO-II, the ScreenPRO-II Controller, and all other Ethernet compatible devices. Ensure that you use a completely local network with no outside connections.
- Connect DVI outputs from each ScreenPRO-II to BlendPRO-II DVI inputs.
- Connect DVI or analog outputs from BlendPRO-II to your projector inputs. For analog connections, use the "BlendPRO-II Analog Output Connections" table.
- (Optional) Connect external Genlock signal to BlendPRO-II GENLOCK IN connector. Do <u>not</u> connect Genlock signal to any ScreenPRO-II units.

Note: Steps 6 through 9 are required.

- Connect BlendPRO-II WIDESCREEN LOCK output to the GENLOCK IN connector on ScreenPRO-II with the lowest numbered ID.
- Connect that ScreenPRO-II's GENLOCK LOOP connector to the GENLOCK IN connector on the ScreenPRO-II with the next highest numbered ID.
- 8. Repeat step 7 for all remaining ScreenPRO-II units in your system configuration.
- 9. Set the Termination Switch for all ScreenPRO-II units.
 - For all ScreenPRO-II units except the last one, ensure that the unit is un-terminated (HI-Z), with the Termination Switch out.
 - On the last unit in the chain (only), ensure that the ScreenPRO-II is terminated (75-OHM), with the Termination Switch pushed in.
- Refer to the "ScreenPRO-II Controller User's Guide" for system setup and operating procedures.

BlendPRO-II Analog Output Connections

Use the following table to connect BlendPRO-II RGB outputs to various projector inputs (3, 4, and 5 wire.)

 Use a customer-supplied VGA to 5 x BNC breakout cable, or for RGB with H and V sync, use the VGA connector directly.

Breakout Cable Wire Color		RGB Sync on Green	RGB Comp Sync	RGB Separate H V
R		✓	✓	✓
G		✓	✓	✓
В		✓	✓	✓
H Sync			✓	✓
V Sync				✓