

FSN-1004



User's Guide

- Manual #: 26-0702200-00
- Revision: 00



FSN-1004 • User's Guide

Copyright

© Barco. March 21, 2013

All rights reserved. No part of this document may be copied, reproduced or translated. It shall not otherwise be recorded, transmitted or stored in a retrieval system without the prior written consent of Barco.

Notice

Barco provides this manual "as is" without warranty of any kind, either expressed or implied, including but not limited to the implied warranties or merchantability and fitness for a particular purpose. Barco may make improvements and/or changes to the product(s) and/or the program(s) described in this publication at any time without notice.

This publication could contain technical inaccuracies or typographical errors. Changes are periodically made to the information in this publication; these changes are incorporated in new editions of this publication.

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case the user will be responsible for correcting any interference.

Guarantee and Compensation

Barco provides a guarantee relating to perfect manufacturing as part of the legally stipulated terms of guarantee. On receipt, the purchaser must immediately inspect all delivered goods for damage incurred during transport, as well as for material and manufacturing faults Barco must be informed immediately in writing of any complaints.

The period of guarantee begins on the date of transfer of risks, in the case of special systems and software on the date of commissioning, at latest 30 days after the transfer of risks. In the event of justified notice of compliant, Barco can repair the fault or provide a replacement at its own discretion within an appropriate period. If this measure proves to be impossible or unsuccessful, the purchaser can demand a reduction in the purchase price or cancellation of the contract. All other claims, in particular those relating to compensation for direct or indirect damage, and also damage attributed to the operation of software as well as to other services provided by Barco, being a component of the system or independent service, will be deemed invalid provided the damage is not proven to be attributed to the absence of properties guaranteed in writing or due to the intent or gross negligence or part of Barco.

If the purchaser or a third party carries out modifications or repairs on goods delivered by Barco, or if the goods are handled incorrectly, in particular if the systems are commissioned operated incorrectly or if, after the transfer of risks, the goods are subject to influences not

agreed upon in the contract, all guarantee claims of the purchaser will be rendered invalid. Not included in the guarantee coverage are system failures which are attributed to programs or special electronic circuitry provided by the purchaser, e.g. interfaces. Normal wear as well as normal maintenance are not subject to the guarantee provided by Barco either.

The environmental conditions as well as the servicing and maintenance regulations specified in this manual must be complied with by the customer.

Trademarks

Brand and product names mentioned in this manual may be trademarks, registered trademarks or copyrights of their respective holders. All brand and product names mentioned in this manual serve as comments or examples and are not to be understood as advertising for the products or their manufactures.

Company Address



Barco, Inc.
11101 Trade Center Drive
Rancho Cordova, California 95670
USA

- Phone: (916) 859-2500
- Fax: (916) 859-2515
- Website: www.barco.com

Barco N.V.
Noordlaan 5
8520 Kuurne
BELGIUM

- Phone: +32 56.36.82.11
- Fax: +32 56.35.16.51

Technical Support

- **Customer Service Portal** — www.barco.com/esupport
- **(866) 374-7878** — Events (24/7)
- **(866) 469-8036** — Digital Cinema (24/7)

Operators Safety Summary

The general safety information in this summary is for operating personnel.

Do Not Remove Covers or Panels

There are no user-serviceable parts within the unit. Removal of the top cover will expose dangerous voltages. To avoid personal injury, do not remove the top cover. Do not operate the unit without the cover installed.

Power Source

This product is intended to operate from a power source that will not apply more than 230 volts rms between the supply conductors or between both supply conductor and ground. A protective ground connection by way of grounding conductor in the power cord is essential for safe operation.

Grounding the Product

This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before connecting to the product input or output terminals. A protective-ground connection by way of the grounding conductor in the power cord is essential for safe operation.

Use the Proper Power Cord

Use only the power cord and connector specified for your product. Use only a power cord that is in good condition. Refer cord and connector changes to qualified service personnel.

Use the Proper Fuse

To avoid fire hazard, use only the fuse having identical type, voltage rating, and current rating characteristics. Refer fuse replacement to qualified service personnel.

Do Not Operate in Explosive Atmospheres

To avoid explosion, do not operate this product in an explosive atmosphere.

Terms In This Manual and Equipment Marking



WARNING

Highlights an operating procedure, practice, condition, statement, etc., which, if not strictly observed, could result in injury to or death of personnel.

Note

Highlights an essential operating procedure, condition or statement.
--



CAUTION

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



AVERTISSEMENT!

Le point d'exclamation dans un triangle équilatéral signale à alerter l'utilisateur qu'il y a des instructions d'opération et d'entretien très importantes dans la littérature qui accompagne l'appareil.



VORSICHT

Ein Ausrufungszeichen innerhalb eines gleichwinkligen Dreiecks dient dazu, den Benutzer auf wichtige Bedienungs- und Wartungsanweisungen in der dem Great beiliegenden Literatur aufmerksam zu machen.

Change History

The table below lists the changes to the FSN-1004 User's Guide.

Table 0-1. Change History

Rev	Date	ECP #	Description	Approved By
00	3/21/13	604387	FSN-1004 User's Guide	R. Pellicano



Table of Contents

- Chapter 1 Introduction 13**
 - In This Chapter 13
 - Software Version 14
 - Chapter Structure 14
 - How to Use This Guide 15
 - Navigating 15
 - Table of Contents and Index 15
 - Conventions 15
 - Glossary of Switcher Terms 16
 - About the FSN-1004 18
 - Overview 18
 - Control GUI 19
 - System Configuration 20
 - FSN-1004 System 20
 - FSN-1004 Cards 20
 - Connectivity Diagrams 21
 - System 1 — Single Screen 21
 - System 2 — Multiple Destinations 22
 - Application Questions 23

- Chapter 2 FSN-1004 Orientation 25**
 - In This Chapter 25
 - Hardware Description 26
 - Chassis Overview 26
 - Card Slot Allocation 27
 - Chassis Front Door 28
 - Air Filter 29
 - Door Removal and Re-installation 29
 - Chassis Front 30
 - Chassis Rear 32
 - Card Descriptions 34
 - System Card 35
 - Ethernet Connections 38
 - M/E Card 39
 - Universal Input Card 41
 - Standard Output Card 43
 - Multiviewer Card 45
 - Card LEDs 47
 - Analog Format Connection Table 48

Chapter 3	Installation	49
	In This Chapter	49
	Safety Precautions	50
	Shipping Information	50
	Unpacking and Inspection	50
	Site Preparation	50
	Cable and Adapter Information	50
	PC Connection	52
	FSN-1004 Rack-Mount Procedure	53
	System Connections	55
	Power Cord/Line Voltage Selection	58
	Card and Rear Panel	59
	Rear Panel Insertion	60
	Rear Panel Removal	60
	Card Insertion	61
	Card Removal	63
	Signal Connections	64
	Output Connections	65
	Universal Input Connections	66
	Analog Format Connection Table	67
	Multiviewer Connections	68
Chapter 4	Menu Orientation	69
	In This Chapter	69
	Menu Tree	70
	High-Level Menu Tree	70
	System Menu Tree	71
	Using the Menu System	72
	Buttons, Tables and Matrices	74
	Button Categories and Colors	74
	Latching, Momentary and Conditional Buttons	75
	Value Buttons	76
	Toggle Buttons	76
	Pop-up Buttons	77
	Location Buttons	77
	Summary of Button Types	79
	Tables	80
	Matrices	81
	Notes and Error Messages	81
	Using the Keypad	82
	Using the Pop-up Keyboard	85
	Memory Menu	86
	Memory Menu Access	87
	Memory Menu Description	88
	Memory Menu in View Mode	88
	Memory Menu in Store Mode	90
	Memory Menu in Recall Mode	91
	Enables Menu Description	92
	Enable Descriptions	94
	System Enables	94
	Out Enables	94

Selecting Registers	95
Naming Registers	95
Advanced Memory Functions	95
Keyboard Shortcuts	96
Deleting Registers	97
Locking and Unlocking Registers	97
Stills Menu	99
Stills Menu Access	99
Stills Menu Description	99
Stills Menu Capture Mode	99
Summary of Stills Capture Method	103
Still Menu Recall Mode	103
Summary of Stills Recall Method	104
Screens Menu	105
System Menu	107
System Menu Description	108
System Menu Access	108
System Menu Functions	109
Status Tables	110
Communications Setup Menu	112
Input Setup	117
Rear I/O View Description	118
Connector Colors	119
Input Table Description	120
Input Menu Functions	121
Default Naming Conventions	122
Input Setup Menu	123
Input Capture and Process Panel	124
Input Capture and Timing Section	124
Input Processing Section	128
Input Sizing and Scaling Panel	129
Input Color Correction Section	135
Input Setup Menu Tool Bar Functions	136
Multiviewer Setup Menu	137
Output Setup Menu	138
Rear I/O View Description	139
Aux Table Description	139
Aux Mixer Description	140
Output Setup Menu Functions	140
SOC Setup Menu	141
Output and Process Panel	142
Output Section	142
Output Processing Section	143
Output Status Section	143
Output and Process Tool Bar Functions	144
Advanced SOC Output Setup Menu	145
Output Sizing and Scaling Panel	146
Output Color Correction Panel	150
User Preferences Menu	151
User Preferences Table	152
User Preferences Functions	152
Software Menu	153
Software Table	154
Software Functions	154

Table of Contents

Output Test Patterns Menu	156
Lock/Unlock GUI	158
Save All	158
Backup and Restore Menu	160
Reset Menu	161
Factory Default Settings	162

Chapter 5 System Setup 163

In This Chapter	163
Setup Prerequisites	164
System Setup Sequence	165
Power Up and Status Check	166
Return to Factory Default	167
Communications Setup	168
Restoring the System	169
Output Format Setup	170
Output Test Patterns	171
Universal Input Setup	172
Aux Output Setup	175
Multiviewer Setup	178
User Preferences Setup	180
Saving the Setup	181
Backing up the System	181

Chapter 6 Operations 183

In This Chapter	183
Quick Setup and Operations	184
Quick Function Reference	186
Understanding Error Messages	186
Working with Pop-ups	188
Using the Keypad	188
Working with Memory Registers	189
Memory Register Overview	189
Storing Memory Registers	190
Store, Set Enables, Enter Custom Name	190
Memory Store Notes	191
Recalling Memory Registers	192
Recall, Bypass Enables	192
Recall, Adjust Enables	192
Memory Recall Notes	193
Viewing Memory Registers	194
Locking and Unlocking Memory Registers	194
Deleting Memory Registers	195
Assigning a Keyboard Shortcut to a Memory Register	195
Backing Up and Restoring the System	196
Backing Up the System	196
Restoring the System	196

Chapter 7	Multiviewer Operations	197
	In This Chapter	197
	Introduction to the Multiviewer	198
	Multiviewer Menu Orientation	200
	Multiviewer Setup Menu	201
	Multiviewer Output Setup Menu	203
	Select Layout Menu	204
	Select Colors Menu	208
	Clock Setup Menu	209
	Assign Source Keypad	212
	Multiviewer Setup	213
	Multiviewer Memory	213
Chapter 8	Updating Software	215
	In This Chapter	215
	Software Update Overview	216
	Hardware Requirements	216
	Downloading Software	217
	Via FTP Site	217
	Via Web Site	218
	Updating FSN-1400 Software	219
Appendix A	Specifications.....	221
	In This Appendix	221
	System Specifications Overview	222
	Reference Video Output Specifications	223
	Physical and Electrical Specifications	224
	Communications Specifications	225
	Agency Specifications	225
	Cable Specifications	225
	Delay Specifications	226
	Pinouts	227
	Analog 15-pin D Connector	227
	DVI-I Connector	228
	Ethernet Connector	229
	Serial Connectors	230
	Output Format Tables	231
	Output Formats	231
Appendix B	Contact Information	233
	In This Appendix	233
	Warranty	233
	Return Material Authorization (RMA)	233
	Contact Information	234
Index	235

Table of Contents

1. Introduction

In This Chapter

This chapter is designed to introduce you to the FSN-1004 User's Guide. Areas to be covered are:

- [Software Version](#)
- [Chapter Structure](#)
- [How to Use This Guide](#)
- [Conventions](#)
- [Glossary of Switcher Terms](#)
- [About the FSN-1004](#)
- [Connectivity Diagrams](#)
- [Application Questions](#)

1. Introduction

Software Version

Software Version

This version of the FSN-1004 User's Guide is based on software version 7.50.

Chapter Structure

The following chapters provide instructions for all aspects of FSN-1004 operations:

- Chapter 1, "[Introduction](#)" provides a system overview, a list of features, and system connectivity diagrams.
- Chapter 2, "[FSN-1004 Orientation](#)" on page 25 provides detailed explanations of the system's chassis and internal cards.
- Chapter 3, "[Installation](#)" on page 49 provides comprehensive system installation instructions.
- Chapter 4, "[Menu Orientation](#)" on page 69 provides menu trees, plus comprehensive explanations of each menu and function.
- Chapter 5, "[System Setup](#)" on page 163 provides detailed instructions for setting up system inputs, outputs and communications.
- Chapter 6, "[Operations](#)" on page 183 provides comprehensive system operating instructions.
- Chapter 7, "[Multiviewer Operations](#)" on page 197 provides full instructions on setting up and operating the Multiviewer.
- Chapter 8, "[Updating Software](#)" on page 215 outlines procedures for upgrading system software components.
- Appendix A, "[Specifications](#)" on page 221 lists the FSN-1004' specifications.
- Appendix B, "[Contact Information](#)" on page 233 lists important Barco contact, RMA, warranty and technical support details.

How to Use This Guide

This section provides important tips for streamlining your use of this User's Guide in its electronic "PDF" form.

Navigating

Use Acrobat Reader's "bookmarks" to navigate to the desired location. All chapter files have the same bookmark structure for instant navigation to any section. Please note:



- Extensive hyperlinks are provided within the chapters.
- Use Acrobat's "**Go to Previous View**" and "**Return to Next View**" buttons to trace your complete navigational path.
- Use the "**Previous Page**" and "**Next Page**" buttons to go to the previous or next page within a file.
- Use Acrobat's extensive search capabilities, such as the "**Find**" tool and "**Search Index**" tool to perform comprehensive searches as required.

Table of Contents and Index

Use the **Table of Contents** bookmarks to navigate a desired topic. Click any item to instantly jump to that section of the guide. You can also use the **Index** to jump to specific topics within a chapter. Each page number in the **Index** is a hyperlink.

Conventions

The following conventions are used throughout this guide:

- The symbol ■ denotes an operations procedure.
- The symbol ▲ denotes an example.
- Entries written in bold-face letters denote GUI buttons, chassis connectors and "sections" in the GUI.
 - ▲ Press **DSK** to ...
- Entries written between braces denote buttons on the Touch Screen.
 - ▲ Press **{Edge Color}** to ...
- A sequence of GUI button presses is denoted by the button names, separated by commas.
 - ▲ Press **STORE, M/E 1, #, ENTER** to ...
- A "press and hold" sequence involving two buttons is denoted by the + symbol in between button names.
 - ▲ Press **MIX + FX TRIG** to ...
- A sequence of button presses on the Touch Screen is denoted by the button names, separated by arrows.
 - ▲ Press **{System} > {Input Setup}** to ...

Glossary of Switcher Terms

The following terms and abbreviations are used throughout this guide:

- **3G** — A 3 Gbit/s serial digital 10-bit or 12-bit video interface (SMPTE 424M and 425M).
- **AUX** (Auxiliary) Bus — AUX buses are extra switching buses that allow video signals connected to the switcher to be routed to external equipment such as VTRs, monitors, projectors, etc.
- **Chassis Cards** — The following cards are installed in the chassis:
 - ~ **1 M/E** (Mixer/Effects Card) — provides crosspoints to route inputs to outputs.
 - ~ **1 System Card** — provides CPU, system memory, and still stores.
 - ~ **5 UIC** (Universal Input Card) — provides two universal scaler inputs per card.
 - ~ **2 SOC** (Standard Output Card) — provides two universal auxiliary outputs per card.
- **Computer Video** — A generic term indicating video that originates from a computer platform. A progressive scan signal that follows VESA (Video Electronics Standards Association) standards, with typical resolutions of 800 x 600, 1024 x 768, 1280 x 1024, etc.
- **Crosspoint** — The video switch (or button) that selects the input required on a particular switcher bus.
- **Cut** — an instantaneous switch from one video source to another.
- **DA** (Distribution Amplifier) — A video device that inputs one video signal, and outputs multiple “identical” signals.
- **Enables** — Within a **Module**, **Enables** are arrays of sub-functions that can be toggled on or off.
- **GUI** (Graphical User Interface) — A term that describes a status display based on graphics and icons, rather than strictly on numbers and letters.
- **HD-SDI** (High Definition Serial Digital Interface) — a high definition SDI signal (SMPTE 292M). Example formats are 720p, 1080i, and 1080p.
- **LTC** — Longitudinal Timecode, an encoding of SMPTE timecode data in an audio signal, as defined in SMPTE 12M specification.
- **Menu** — A term used to describe buttons and functions on the GUI.
- **Module** — A column in the **Memory Menu**’s table of registers.
- **Multiviewer** (MVR) — a monitoring system that enables multiple sources (input and outputs) to be displayed on one or two monitors, eliminating the need for individual source monitors. By utilizing different arrays of PIPs, users can select the preferred multiviewer “look,” and streamline control room operations.
- **Native Resolution** — The resolution to which all processing is set within the switcher frame.
- **PGM** (Program) — The on-line (or on-air) output from the FSN switcher.
- **PVW** (Preview) — The off-line (or off-air) output from the FSN switcher used to show content that can be transitioned to Program.
- **RGB** — The red, green and blue color signal components.

1. Introduction

Glossary of Switcher Terms

- **RGBHV** — Defines a connection scheme with five lines: one for red, one for green, one for blue, one for the horizontal sync and one for the vertical sync. This is the standard used in VGA and other analog PC computer monitors.
- **RGBS** — Defines a connection with four signals, to transmit video and sync information. Vertical and horizontal sync are combined on a single channel
- **RGsB** — Defines a connection with three signals, to transmit video and sync information. Here, the sync information is transmitted on the green channel.
- **SD-SDI** — (Standard Definition Serial Digital Interface) — a standard definition SDI signal with a data rate of 270 Mbit/s only (SMPTE 259M). Example formats are 480i and 525i.
- **SDI** (Serial Digital Video) — A digital representation of the video signal that is distributed via a single coaxial cable with BNC connectors.
- **TD** (Technical Director) — The person who operates the FSN-1004 switcher.
- **UMD** (Under Monitor Display) — The area beneath a multi-viewer window that shows the name of the display and can change color to convey information to the operator.
- **Y/C** — A video signal in which color and brightness information is transmitted separately (luminance Y, chrominance C).

1. Introduction

About the FSN-1004

About the FSN-1004

The following topics are discussed in this section:

- [Overview](#)
- [Control GUI](#)
- [System Configuration](#)

Overview

The FSN-1004 integrates 3G, HD, SD and computer sources in a professional multi-format production switcher. General features include:

- The ability to add computer inputs and HD/SD cross-conversion capability to traditional video switcher functionality, with seamless switching and mixing.
- The ability to select the native output video format (e.g. 720p, 1080p, 1200p). In this manner, the switcher can operate as an HD-SDI switcher with internal SD and computer video conversion to HD.
- An intuitive control GUI.
- A video processor (chassis) that uses field-serviceable cards, providing superior input and output flexibility.
- All cards, power supplies and fans are front-serviceable and hot-swappable.
- Video reference input, plus auto-timing of reference locked sources (+/- 0.5 lines).
- Six native resolution Aux outputs:
 - ~ 1280x720p@50
 - ~ 1280x720p@59.94
 - ~ 1920x1080p@50
 - ~ 1920x1080p@59.94 (default)
 - ~ Barco 1200p3G@50
 - ~ Barco 1200p3G@59.94
- Built-in test patterns.

Please note:

- To ensure trouble-free orientation, installation and operation of your FSN-1004 switcher, please follow all procedures in the following chapters:
 - ~ Chapter 2, "[FSN-1004 Orientation](#)" on page 25.
 - ~ Chapter 3, "[Installation](#)" on page 49.
 - ~ Chapter 4, "[Menu Orientation](#)" on page 69.
 - ~ Chapter 5, "[System Setup](#)" on page 163.
 - ~ Chapter 6, "[Operations](#)" on page 183.
 - ~ Chapter 7, "[Multiviewer Operations](#)" on page 197.
 - ~ Chapter 8, "[Updating Software](#)" on page 215.
- If you have questions regarding the FSN-1004, please consult with customer service. Refer to Appendix B, "[Contact Information](#)" on page 233.

Control GUI

A graphical user interface (GUI) running on a PC is used to control the FSN-1004. The GUI runs under the following PC operating systems:

- Windows® 7
- Macintosh OS X 10.6.8




Figure 1-1. FSN-1004 GUI

1. Introduction

About the FSN-1004

System Configuration

The following topics are discussed in this section:

- [FSN-1004 System](#)
- [FSN-1004 Cards](#)

FSN-1004 System

The FSN-1004 system consists of the following:

- **FSN-1004** chassis.
- One **System Card** and one **Crosspoint M/E Card**. Refer to the “**FSN-1004 Cards**” section below for details.

FSN-1004 Cards

The FSN-1004 cards are described below.

- **System Card** — this card includes:
 - ~ Video reference input and loop through.
 - ~ Video reference output.
 - ~ Ethernet port (10/100).
 - ~ One tally connector (24 contact closures).
 - ~ One GPIO connector (four GPI ports and eight GPO ports).

In Chapter 2, refer to the “[System Card](#)” section on page 35 for details.

- **Crosspoint M/E Card** — This card includes:
 - ~ Crosspoint matrix.
 - ~ Six Aux outputs.

In Chapter 2, refer to the “[M/E Card](#)” section on page 39 for details.

- **Five UIC** (Universal Input Card)

The **UIC** provides two independent universal scaler channels, each of which is used to scale input video to the switcher’s selected native output resolution. In Chapter 2, refer to the “[Universal Input Card](#)” section on page 41 for details.

- **Two SOC** (Standard Output Card)

The **SOC** provides two independent scaler output channels. Each card can output scaled video and/or computer resolutions up to UXGA or 1920 x 1080, or function as an additional native auxiliary output. In Chapter 2, refer to the “[Standard Output Card](#)” section on page 43 for details.

- **One MVR** (Multiviewer Card)

The **MVR** provides internal multiviewer capability, with the ability to display up to 16 source PIPs in both single and dual monitor configurations. In Chapter 2, refer to the “[Multiviewer Card](#)” section on page 45 for details.

Important

In Chapter 2, refer to the “[Card Slot Allocation](#)” section on page 27 for details on maximum card quantities and slot allocations in the FSN-1004 chassis.

Connectivity Diagrams

The following connectivity diagrams are provided in this section:

- [System 1 — Single Screen](#)
- [System 2 — Multiple Destinations](#)

System 1 — Single Screen

The figure below illustrates a single-screen FSN-1004 system:




Figure 1-2. Block diagram of FSN-1004 system (sample)

This configuration is a setup consisting of multiple inputs, a single destination output, and a single Aux output. In the diagram:

- Multiple scaled and un-scaled sources connect to the FSN-1004, including cameras, PCs, VTRs, DVRs and servers.
- The FSN-1004 and your PC connect via Ethernet.
- The Multiviewer monitor enables the TD to view the entire output of the switcher, and preview the “look” that’s coming next on all outputs.
- The switcher’s Program output connects to the projector.
- One Aux output is connected to a VTR, providing the ability to record the output of the event.

1. Introduction

Connectivity Diagrams

System 2 – Multiple Destinations

The figure below illustrates a sample system in which individual Aux outputs are routed to different destinations.




Figure 1-3. Block diagram, multiple destination FSN-1004 system (sample)

This configuration is demonstrating a setup consisting of three projected images behind a podium. The left and right images are identical, and the center image can be identical, or different from the two “wing” projectors. By connecting Aux outputs to different projectors, the TD has complete creative control over the look, with the ability to display different setups on the projectors.

In the diagram:

- Multiple scaled and un-scaled sources connect to the FSN-1004, including cameras, PCs, VTRs, DVRs and servers.
- The FSN-1004 and your PC connect via Ethernet.
- Aux outputs 1, 2 and 3 connect to the three projectors.
- Aux outputs 4, 5 and 6 are connected to peripheral devices, such as monitors and VTRs. In practice, this enables the TD to provide completely independent stage or green room monitors, plus the ability to record the output of the entire event.

Application Questions

At Barco, we take pride in offering unique solutions to demanding technical problems. If you have application questions, require further information or would like to discuss your application requirements in more detail, please call (866) 469-8036. Our Customer Support Engineers will be happy to supply you with the support you need. Refer to Appendix B, [“Contact Information”](#) on page 233 for details.

1. Introduction

Application Questions

2. FSN-1004 Orientation

In This Chapter

This chapter provides detailed explanations of the FSN-1004 chassis, including all front and rear chassis cards.

The following topics are discussed:

- [Hardware Description](#)
- [Card Descriptions](#)
- [Card LEDs](#)
- [Analog Format Connection Table](#)

Note

Once you have reviewed all of the sections in this chapter, please continue with Chapter 3, "[Installation](#)" on page 49.

2. FSN-1004 Orientation

Hardware Description

Hardware Description

The following topics are discussed in this section:

- [Chassis Overview](#)
- [Card Slot Allocation](#)
- [Chassis Front Door](#)
- [Chassis Front](#)
- [Chassis Rear](#)

Chassis Overview

The FSN-1004 chassis permits a high degree of flexibility in terms of the number of inputs and outputs. Please note:

- All cards are modular and hot-swappable.
- 6RU chassis.
- An internal “midplane” architecture with cards plugged in from both the front and rear of the chassis.
- There are no active components on the midplane or on the plug-in rear cards.
- The front door provides a seal for air flow and chassis cooling. There are no controls on the door, but two status LEDs are provided. Refer to the “[Chassis Front Door](#)” section on page 28 for details.
- The following additional features are provided:
 - ~ Optional dual redundant hot-swappable power supplies.
 - ~ One tally connector (24 contact closures).
 - ~ One GPIO connector, with four input (GPI) and eight output (GPO) ports.
 - ~ Two serial ports.

Card Slot Allocation

Table 2-1. FSN-1004 chassis card slot allocations

Card Type	Installed # of Cards per Chassis	Slot Number(s)
System	1	14
M/E	1	8
UIC (Universal Input Card), 2-channel	5	3 - 7
MVR (Multiviewer Card)	1	11
SOC (Standard Output Card), 2-channel	2	12, 13

Please note:

- Refer to the “[Chassis Front](#)” section on page 30 and the “[Chassis Rear](#)” section on page 32 for detailed information on all chassis card slots.
- Refer to the “[Card Descriptions](#)” section on page 34 for in-depth information of all cards and their capabilities.

2. FSN-1004 Orientation

Hardware Description

Chassis Front Door

The figure below illustrates a view of the chassis front door:




Figure 2-1. FSN-1004 chassis front door

1) Door Latch	2) System Status LEDs	3) Hinges
-------------------------------	---------------------------------------	---------------------------

Following are descriptions of each section.

1) Door Latch

One latch is provided to facilitate door opening and closing. See the [“Door Removal and Re-installation”](#) section on page 29 for instructions.

2) System Status LEDs

The two **System Status LEDs** are mounted on the **System Card**, but they are visible through the slot in the front door — via light pipe.

The **Power LED** indicates power status for the chassis and the system card.

- ~ **Green** = the system card has power and the card's software is running.
- ~ **Off** = one or more of the following conditions are present:
 - There is no power to the FSN-1004.
 - There is no **System Card** in the FSN-1004.
 - The **System Card** has failed.

2. FSN-1004 Orientation

Hardware Description

The **Video Reference LED** indicates the status of the system's analog video reference input, via the **Vid Ref** connector on the **System Card**'s rear panel.

- ~ **Green** = the system is configured for **External Reference**, a video reference signal is present and the FSN-1004 is locked to the signal.
- ~ **Red** = the system is configured for **External Reference**, the signal is missing or the FSN-1004 is not locked to the signal.
- ~ **Off** = the system is configured for **Free Run**.

Note

If the **Power LED** is off, the **Video Reference LED** will also be off.

3) Hinges

Two hinges are provided on the right side of the door, to facilitate door removal and re-installation. See the "[Door Removal and Re-installation](#)" section below for door removal and installation instructions.

Air Filter

An air filter is located on the inside of the front door, in the bottom half of the door. Using the four thumb nuts, this filter can be easily removed and cleaned periodically, as required.

Door Removal and Re-installation

- Use the following steps to open and remove the FSN-1004 front door:
 1. On the **Latch**, press inwards on the top label that reads "**Push.**"
 2. Lift the lower portion of the **Latch** that reads "**Lift and Turn.**"
 3. Turn the **Latch** clockwise, and open the door.
 4. To remove the door, lift it up and off of its hinges.
- Use the following steps to re-install the FSN-1004 front door:
 1. Align the female hinges on the door with the male hinges on the FSN-1004.
 2. Set the door down on the hinges until it is fully seated.
 3. Close the door.
 4. Turn the **Latch** counter-clockwise, then push the **Latch** in to re-seat it.

Important

Operating the FSN-1004 without the door fully closed and the filter installed will cause overheating and possible damage.

2. FSN-1004 Orientation

Hardware Description

Chassis Front

The figure below illustrates a front view of an FSN-1004 chassis (door removed):




Figure 2-2. FSN-1004 chassis, front view (sample)

1) Power Supplies	4) SOC Cards	7) Input Cards
2) Fan Tray	5) MVR Card	
3) System Card	6) M/E Card	

Following are descriptions of each section. Note that slots are numbered from right to left, to correlate with the associated rear slots.

1) Power Supplies

Two slots are provided for dual redundant hot-swappable power supplies, each with a 600W capability. Each supply has two LEDs:

~ DC OK LED:

- **Green** = DC power (from the supply) is OK.
- **Red** = DC power is bad or has failed.

~ AC OK LED:

- **Green** = AC power (into the supply) is OK.

2. FSN-1004 Orientation

Hardware Description

- **Red** = AC power is bad or has failed.

The FSN-1004 comes with a single power supply.

2) Fan Tray

For chassis cooling, one slot is provided for the required hot-swappable fan tray. The integral handle enables the tray to be easily removed and installed.

Important

The fan tray must be installed whenever power is applied to the chassis. Operating the unit without the fan tray will cause overheating and possible damage.

3) System Card

Slot 14 is populated with the **System Card**. Refer to the "[System Card](#)" section on page 35 for details.

4) SOC Cards

Slots 12 and 13 are populated with the **Standard Output Card**. See the "[Standard Output Card](#)" section on page 43.

5) MVR Card

Slot 11 is populated with the **MVR** (Multiviewer Card). See the "[Multiviewer Card](#)" section on page 45.

6) M/E Card

Slot 8 is populated with the **M/E** (Mix/Effects) card. Refer to the "[M/E Card](#)" section on page 39 for details.

7) Input Cards

Slots 3 through 7 are populated with **UICs** (Universal Input Cards). Refer to the "[Universal Input Card](#)" section on page 41 for details.

2. FSN-1004 Orientation

Hardware Description

Chassis Rear

The figure below illustrates a rear view of the FSN-1004 chassis:




Figure 2-3. FSN-1004 chassis, rear view

1) Air Vents	4) MVR Panel	7) AC Power
2) Input Card Panels	5) Standard Output Card Panels	
3) M/E Card Panel	6) System Card Panel	

In the descriptions below, slots are numbered from left to right:

1) Air Vents

At the top of the chassis, **Air Vents** are provided to assist with cooling. Air flows from the front of the chassis to the rear. To prevent overheating, do not block the air vents.

2) Input Card Panels

Slots 3 through 7 are populated with **UIC** panels. Refer to the “[Universal Input Card](#)” section on page 41 for details.

3) M/E Card Panel

Slot 8 is populated with the **M/E** card panel. Refer to the “[M/E Card](#)” section on page 39 for details.

2. FSN-1004 Orientation

Hardware Description

4) MVR Panel

Slot 11 is populated with the **MVR** card panel. See the "[Multiviewer Card](#)" section on page 45.

5) Standard Output Card Panels

Slots 12 and 13 are populated with two **SOCs** (Standard Output Cards). See the "[Standard Output Card](#)" section on page 43.

6) System Card Panel

Slot 14 is populated with the **System** card panel. Refer to the "[System Card](#)" section on page 35 for details.

7) AC Power

The **AC Power** section provides two AC power connectors with integral switches. One connector is provided for each supply, which allows the frame to be powered from two different circuit breakers in a redundant configuration.

Note

The default FSN-1004 configuration has one power supply installed in the lower slot. The bottom AC connector is used.

Important

Unused rear slots must have blank panels installed for purposes of thermal management and EMI.

2. FSN-1004 Orientation

Card Descriptions

Card Descriptions

The FSN-1004 cards are discussed in this section:

- [System Card](#)
- [M/E Card](#)
- [Universal Input Card](#)
- [Standard Output Card](#)
- [Multiviewer Card](#)
- [Card LEDs](#)
- [Analog Format Connection Table](#)

Note

On all following card descriptions, remember that all physical connectors are located on the associated rear panels.

System Card

■ Slot number: 14

Important

This card is pre-installed in the FSN-1004. Do not move the card to any other slots.

The **System Card** provides the following functions:

- System control, CPU, timing, and video reference (input, loop and output).
- Ethernet port 10/100, two serial outputs, Tally (24 contact closures).
- GPIO (four input ports, eight output ports).
- RS-232 port (diagnostics only).

The figure below illustrates the **System** card's front edge and rear panel connectors:




Figure 2-4. System card front edge and rear panel connectors

1) System Power LED	5) Loaded LED	9) Ethernet Port
2) Video Reference LED	6) Diagnostic Port	10) Ref In
3) Ejectors	7) CPU Reset Switch	11) Loop
4) Card Power LED	8) IP Address Reset Switch	

Following are descriptions of all components on the front edge of the **System** card:

1) System Power LED

The **System Power LED** indicates power status for the chassis and the cards.

2. FSN-1004 Orientation

Card Descriptions

- ~ **Green** = all system power is OK.
- ~ **Red** = one or more of the following conditions are present:
 - DC output from one (of the two) chassis power supplies is bad or has failed.
 - Power is bad (or has failed) on one or more of the installed circuit cards.
- ~ **Off** = one or more of the following conditions are present:
 - The chassis is turned off.
 - DC output from all power supplies is bad or has failed.
 - Power has failed on the **System Card**.

Note that this LED is carried through to the front door via light pipe.

2) Video Reference LED

The **Video Reference LED** indicates the status of the system's analog video reference input, via the **Vid Ref** connector on the **System Card**'s rear panel.

- ~ **Green** = the system is configured for **External Reference**, a video reference signal is present and the FSN-1004 is locked to the signal.
- ~ **Red** = the system is configured for **External Reference**, the signal is missing or the FSN-1004 is not locked to the signal.
- ~ **Off** = the system is configured for **Free Run**.

Note

If the **Power LED** is off, the **Video Reference LED** will also be off.

Note that this LED is carried through to the front door via light pipe.

3) Ejectors

Use the card's top and bottom **Ejectors** to remove (and re-insert) the card.

4) Card Power LED

The **Card Power LED** indicates power status for the card. Refer to the "[Card LEDs](#)" section on page 47 for details.

5) Loaded LED

The **Loaded LED** indicates the status of all FPGAs on the card. Refer to the "[Card LEDs](#)" section on page 47 for details.

6) Diagnostic Port

One RS-232 port is provided for diagnostics. This port is not available to the user.

7) CPU Reset Switch

Using a small tool such as a paper clip, press the **CPU Reset Switch** to perform a soft system reset. This function reboots the system, but preserves all setups and memory registers, and maintains all crosspoint selections on the GUI. Please note:

- ~ This is the same as pressing **{Soft Reset System}** on the **Reset Menu**. In Chapter 4, refer to the "[Reset Menu](#)" section on page 161 for details.

8) IP Address Reset Switch

Using a small tool such as a paper clip, press the **IP Address Reset Switch** for 5 (five) seconds. This action resets the chassis IP address to the default value of **192.168.0.4**, and then performs a factory reset. Please note:

- ~ This is the same as pressing **{Factory Reset}** on the **Reset Menu**. In Chapter 4, refer to the [“Reset Menu”](#) section on page 161 for details.
- ~ Use the **Com Setup Menu** to change the IP address if required. In Chapter 5, refer to the [“Communications Setup”](#) section on page 168 for details.

Following are descriptions of all components on the **System** card's rear panel:

9) Ethernet Port

One RJ-45 connector is provided for a 10/100 **Ethernet** connection between the FSN-1004 and your PC. For multiple Ethernet connections, an Ethernet switch is recommended. There are two LEDs on the connector:




Figure 2-5. Ethernet Connector

- ~ When a valid link is present, the amber **Link Speed LED** indicates 100mb Ethernet speed when lit, and 10mb speed when off.
- ~ The green **Link/Activity LED** indicates that a link is present when lit, and link activity when blinking.

Please note:

- ~ In Appendix A, refer to the [“Ethernet Connector”](#) section on page 229 for Ethernet connector pinout details.
- ~ Use the **Com Setup Menu** to change the chassis' IP address. In Chapter 5, refer to the [“Communications Setup”](#) section on page 168 for details.
- ~ Refer to the [“Ethernet Connections”](#) section on page 38 for more information about Ethernet.

10) Ref In

One BNC is provided for an analog **Reference Input** connection. Accepted video reference signals are black burst, SMPTE bi-level sync and tri-level sync.

11) Loop

One BNC connector is provided for a reference **Loop** connection, which enables you to loop the incoming reference signal to the next device in your system. If the reference **Loop** is not used, connect a 75 ohm terminator to the connector.

2. FSN-1004 Orientation

Card Descriptions

Ethernet Connections

This section provides information on all FSN-1004 Ethernet connections.




Figure 2-6. Basic system Ethernet diagram

- **FSN-1004**

The FSN-1004 has a single **Ethernet** port located on the **System** card. This port connects to **Ethernet Port** on your PC, either directly or via an Ethernet switch. By default, the following conditions are set:

- ~ DHCP = **OFF**
- ~ Default IP address: **192.168.0.4**
- ~ Default Netmask: **255.255.255.0**

The user can use the default address, or set a different address.

Use the **Com Setup Menu** to change IP addresses. In Chapter 5, refer to the "[Communications Setup](#)" section on page 168 for details.

M/E Card

■ Slot number: 8

Important

This card is pre-installed in the FSN-1004. Do not move.

The **M/E (Mix/Effects) Card** provides the following functions:

- Crosspoint switch.
- Six native Aux outputs.

The figure below illustrates the **M/E** card's front edge and rear panel connectors:




Figure 2-7. M/E card front edge and rear panel connectors

1) Ejectors	2) Card Power LED	3) Loaded LED	4) Native Aux Outputs
-----------------------------	-----------------------------------	-------------------------------	---------------------------------------

Following are descriptions of all **M/E** card components:

- 1) **Ejectors**
Use the card's top and bottom **Ejectors** to remove (and re-insert) the card.
- 2) **Card Power LED**
The **Card Power LED** indicates power status for the card. Refer to the "[Card LEDs](#)" section on page 47 for details.
- 3) **Loaded LED**
The **Loaded LED** indicates the status of all FPGAs on the card. Refer to the "[Card LEDs](#)" section on page 47 for details.

2. FSN-1004 Orientation

Card Descriptions

4) Native Aux Outputs

Six BNCs are provided for the system's six **Native Aux Outputs**. Source selection is performed in the GUI. In Chapter 5, refer to the "[Aux Output Setup](#)" heading on page 163 for details.

Universal Input Card

- Installed in slots: 3 - 7
- Number of cards per chassis: 5

The **UIC** (Universal Input Card) is a two-channel card that scales non-native inputs (up to UXGA or 1920 x 1080) to the switcher's native resolution and timing. One **UIC** provides two universal scaled video inputs, plus additional capabilities for native resolution sources:

- Frame synchronization for sources not locked to video reference.
- For SDI inputs that match the native format, +/- 0.5 line auto-timing for input sources that are locked to video reference.

Refer to the “[Card Slot Allocation](#)” section on page 27 for details on **UIC** configurations in the FSN-1004.

The figure below illustrates the **UIC**'s front edge and rear panel connectors:




Figure 2-8. UIC front edge and rear panel connectors

1) Ejectors	3) Loaded LED	5) Universal Input 2
2) Card Power LED	4) Universal Input 1	

Following are descriptions of all **UIC** components:

1) Ejectors

Use the card's top and bottom **Ejectors** to remove (and re-insert) the card.

2. FSN-1004 Orientation

Card Descriptions

2) Card Power LED

The **Card Power LED** indicates power status for the card. Refer to the “[Card LEDs](#)” section on page 47 for details.

3) Loaded LED

The **Loaded LED** indicates the status of all FPGAs on the card. Refer to the “[Card LEDs](#)” section on page 47 for details.

4) Universal Input 1

Three connectors are provided for **Universal Input 1** (1 x **HD15**, 1 x **DVI-I**, 1 x **BNC**). Using these connectors, different combinations of inputs can be connected to the FSN-1004, as outlined below, but only one of the three connectors can be used at a time in the GUI.

Cells with check marks denote the connections required for the indicated format.

Table 2-2. UIC connector combinations for selected universal input formats

Format	Connectors		
	BNC	DVI-I	HD-15
3G-SDI	✓		
HD-SDI	✓		
SD-SDI	✓		
DVI *		✓	
CVBS			✓
Y/C			✓
YPbPr **			✓
RGsB			✓
RGBS			✓
RGBHV ***			✓

* up to 165 MHz

** NTSC, PAL or HD

*** up to 165 MHz (UXGA)

Please note the following important points regarding the **UIC**:

~ Refer to the “[Analog Format Connection Table](#)” section on page 48 for additional information on using the HD-15 connector.

5) Universal Input 2

Input connections for **Universal Input 2** are identical to Universal Input 1. Refer to the explanation of **Universal Input 1** for details.

Note

In Appendix A, refer to the “[Delay Specifications](#)” section on page 226 for details on UIC delay.

Standard Output Card

- Installed in slots: 12, 13
- Number of cards per chassis: 2

The **SOC** (Standard Output Card) is a two-channel scaler card that creates scaled video and/or computer Aux outputs up to UXGA or 1920 x 1080. Users can set the output resolution to be different from (or the same as) the system’s native resolution.

Use the **Aux Setup Menu** to map Aux outputs and name Aux outputs (if desired). Refer to the “[Card Slot Allocation](#)” section on page 27 for details on **SOC** configurations in the FSN-1004.

The figure below illustrates the **SOC’s** front edge and rear panel connectors:




Figure 2-9. SOC front edge and rear panel connectors

1) Ejectors	3) Loaded LED	5) Universal Output 2
2) Card Power LED	4) Universal Output 1	

Following are descriptions of all **SOC** components:

- 1) **Ejectors**
Use the card’s top and bottom **Ejectors** to remove (and re-insert) the card.
- 2) **Card Power LED**
The **Card Power LED** indicates power status for the card. Refer to the “[Card LEDs](#)” section on page 47 for details.
- 3) **Loaded LED**

2. FSN-1004 Orientation

Card Descriptions

The **Loaded LED** indicates the status of all FPGAs on the card. Refer to the “[Card LEDs](#)” section on page 47 for details.

4) Universal Output 1

Three connectors are provided for **Universal Output 1**:

- ~ 1 x **HD15**
- ~ 1 x **DVI-I**
- ~ 1 x **BNC**

Using these connectors, different combinations of outputs can be connected to the FSN-1004, as outlined below.

Note

Multiple outputs on a single **SOC** channel can be active at the same time, provided that the selected format is compatible. For example, 1920 x 1080i @ 59.94 is a compatible format on all three output connectors.

Cells with check marks denote the connections required for the indicated format.

Table 2-3. SOC connector combinations for selected universal output formats

Format	Connectors		
	BNC	DVI-I	HD-15
3G-SDI	✓		
HD-SDI	✓		
SD-SDI	✓		
DVI *		✓	
CVBS			✓
Y/C			✓
YPbPr **			✓
RGsB			✓
RGBS			✓
RGBHV ***			✓

* up to 165 MHz

** NTSC, PAL or HD

*** up to 165 MHz (UXGA)

Refer to the “[Analog Format Connection Table](#)” section on page 48 for additional information on using the HD-15 connector.

5) Universal Output 2

Output connections for **Universal Output 2** are identical to Universal Output 1. Refer to the explanation of **Universal Output 1** for details.

Note that test patterns can be assigned to any **SOC** output, and a raster box can be turned on or off. In Chapter 4, see the “[Output Test Patterns Menu](#)” section for details.

Multiviewer Card

■ Installed in slot: 11

The **MVR** (Multiviewer) provides the ability to display up to 16 source PIPs in both single and dual monitor configurations. With the desired monitor(s) connected to the card, users can set the **MVR**'s output resolution, and select from a variety of pre-defined multiviewer layouts.

The figure below illustrates the **MVR**'s front edge and rear panel connectors:




Figure 2-10. MVR front edge and rear panel connectors

1) Ejectors	3) Loaded LED	5) MVR Output 2
2) Card Power LED	4) MVR Output 1	6) LTC Input

Following are descriptions of all **MVR** components:

- 1) **Ejectors**
Use the card's top and bottom **Ejectors** to remove (and re-insert) the card.
- 2) **Card Power LED**
The **Card Power LED** indicates power status for the card. Refer to the "[Card LEDs](#)" section on page 47 for details.
- 3) **Loaded LED**
The **Loaded LED** indicates the status of all FPGAs on the card. Refer to the "[Card LEDs](#)" section on page 47 for details.

2. FSN-1004 Orientation

Card Descriptions

4) MVR Output 1

In order to provide multiviewer connections to both SDI and DVI compatible monitors, two connectors are provided for **MVR Output 1**:

- ~ 1 x **DVI-I**
- ~ 1 x **BNC**

The same output signal appears on both the **DVI-I** and **BNC** connectors. **MVR Output 1** can be used in both single and dual multiviewer monitor configurations, as selected on the **Multiviewer Setup Menu**:

- ~ In a single monitor layouts, the selected layout appears identically on **MVR Output 1** and **MVR Output 2**.
- ~ In a dual monitor layouts, one half of the selected layout appears on **MVR Output 1**, and the other half appears on **MVR Output 2**.

Please note:

- ~ The output resolution for both **MVR** outputs is set on the **Multiviewer Output Setup Menu**, using the **Output Format Keypad**.
- ~ Both the **BNC** and **DVI-I** connectors can be active at the same time, provided that the selected format is compatible. The valid combinations are fully listed in the **Output Format Keypad**.
- ~ Refer to Chapter 7, "[Multiviewer Operations](#)" on page 197 for full multiviewer setup details.

5) MVR Output 2

Output connections for **MVR Output 2** are identical to **MVR Output 1**. See above for details.

6) LTC Input

One Phoenix connector is provided for the Multiviewer's **LTC** (Longitudinal Time Code) **Input**.




Figure 2-11. LTC Input connector

Two types of time code connections are possible:

- ~ For a differential connection, use the **+**, **-** and **GND** terminals.
- ~ For a single-ended connection, use the **+** and **GND** terminals.

Please note:

- Test patterns can be assigned to any **MVR** output, and a raster box can be turned on or off. In Chapter 4, see the "[Output Test Patterns Menu](#)" section for details.

Card LEDs

On the front edge of all cards, two LEDs indicate the card's FPGA and power status.

Note

An **FPGA** (field-programmable gate array) is a semiconductor device that can be reconfigured after manufacturing — hence the name "field-programmable"




Figure 2-12. Card front edge LEDs

1) Card Power LED	2) Loaded LED
-----------------------------------	-------------------------------

Following are descriptions of the two LEDs:

1) Card Power LED

The **Card Power LED** indicates power status for the card.

- ~ **Green** = card power is OK.
- ~ **Red** = power is bad (or has failed) on the card.
- ~ **Off** = the chassis is turned off or power has failed.

2) Loaded LED

The **Loaded LED** indicates the status of all FPGAs on the card.

- ~ **Green** = all FPGAs are loaded successfully.
- ~ **Red** = an FPGA is malfunctioning, or software has not properly loaded.
- ~ **Off** = the chassis is turned off or power has failed.

2. FSN-1004 Orientation

Analog Format Connection Table

Analog Format Connection Table

Each HD-15 analog connector on both the **UIC** and **SOC** enables you to input (or output) a variety of video formats — including VGA, composite video, S-Video and YUV component video.

- For RGB with H and V sync, use the HD-15 connector directly.
- Using a customer supplied HD-15 to 5 x BNC breakout cable, many combinations are possible. Cells with check marks denote the connections required for the indicated format.

Table 2-1. Analog Input and Output Combinations using Breakout Cable

Breakout Cable Wire Color	Composite Video	S-Video (Y/C)	YUV (YP _b P _r)	RGB Sync on Green	RGB Comp Sync	RGB Separate H V
R			✓ (P _r)	✓	✓	✓
G	✓	✓ (Lum)	✓ (Lum)	✓	✓	✓
B		✓ (Chroma)	✓ (P _b)	✓	✓	✓
H Sync					✓	✓
V Sync						✓

3. Installation

In This Chapter

This chapter provides detailed instructions for installing FSN-1004 hardware. The following topics are discussed:

- [Safety Precautions](#)
- [Shipping Information](#)
- [Unpacking and Inspection](#)
- [Site Preparation](#)
- [Cable and Adapter Information](#)
- [FSN-1004 Rack-Mount Procedure](#)
- [System Connections](#)
- [Card and Rear Panel](#)
- [Signal Connections](#)
- [Analog Format Connection Table](#)

Please note the following important points:

- As you follow the installation instructions in this chapter, remember the following important term:
 - ~ **Native Resolution** — The resolution to which all processing is set within the switcher frame.
- In Chapter 5, refer to the “[Aux Output Setup](#)” section on page 175 for instructions on setting the native resolution.

Note

Once you have reviewed all of the sections in this chapter, please continue with Chapter 4, “[Menu Orientation](#)” on page 69.

3. Installation

Safety Precautions

Safety Precautions

For all FSN-1004 installation procedures, observe the following important safety and handling rules to avoid damage to yourself and the equipment:

- To protect users from electric shock, ensure that the power supplies for each unit connect to earth via the ground wire provided in the AC power cord.
- AC Socket-outlets should be installed near the equipment and be easily accessible.

Shipping Information

All FSN-1004 systems are shipped in one box as follows:

- **Box 1**
 - ~ FSN-1004 chassis and cards
- If a redundant power supply is ordered, it is shipped in its own box.

Unpacking and Inspection

Inspect the shipping boxes for damage. If you find any damage, notify the shipping carrier immediately for all claims adjustments. As you open each box, compare its contents against the packing slips. If you find any shortages, contact your Barco sales representative.

Once you have removed all components from their packaging and checked that the listed components are present, inspect each unit to ensure there was no shipping damage. If there is damage, notify the shipping carrier immediately for all claims adjustments.

Site Preparation

The environment in which you install your FSN-1004 switcher should be clean, properly lit, free from static, and have adequate power, ventilation, and space for all components.

Cable and Adapter Information

The table below provides information regarding cables included with the FSN-1004:

3. Installation

Cable and Adapter Information

Table 3-1. FSN-1004 Cables

Cable / Adapter	Description	Quantity
AC Power Cord	7 foot, 10A (US Power Cord)	1
AC Power Cord	7 foot, 10A (European Power Cord)	1

3. Installation

PC Connection

PC Connection

The figure below illustrates the connectors and cabling used to connect your Personal Computer (PC) to the FSN-1004.




Figure 3-1. PC Installation

- Use the following steps to connect your **PC**:
 1. Using standard Ethernet cables, connect an **Ethernet Port** on your **PC** to a customer supplied **Ethernet Switch**. Then, connect the **FSN-1004's Ethernet Port** to the **Ethernet Switch**.

Note

Although the use of the **Switch** is recommended, you can use a direct Ethernet connection between the **FSN-1004** and your **PC** as an alternate method.

FSN-1004 Rack-Mount Procedure

The FSN-1004 chassis is designed to be rack mounted and is supplied with front rack-mount hardware. Please note the following important points:

- The FSN-1004 is 6RU in height.
 - When rack mounting the unit, remember that the maximum ambient operating temperature is 40 degrees C.
 - Leave sufficient front and rear space to ensure that airflow through the FSN-1004 is not restricted.
 - When installing equipment into a rack, distribute the units evenly to prevent hazardous conditions that may be created by uneven weight distribution.
 - Connect the FSN-1004 only to a properly rated supply circuit.
 - Reliable grounding (earthing) of rack-mounted equipment should be maintained.
 - Rack mount the FSN-1004 from the front rack ears using four rack screws (not supplied). Threads may be metric or otherwise, depending upon the rack type.
- Use the following steps to rack mount the FSN-1004:
1. An FSN-1004 chassis weighs 77 pounds (34.92 kg). To avoid injury, it is recommended that two people rack mount the chassis.
 2. The FSN-1004 ships with side rails installed, which when properly adjusted, assist with the distribution of chassis (and cable) weight within your rack. Use the following steps to properly adjust the side rails:

- a. Measure and install the two supplied mounting brackets on your rear rack rails.



Figure 3-2. Rear rail mounting bracket

- b. Measure the distance between the front and rear rack rails. Remove the four mounting screws that secure each side rail to the FSN-1004, then adjust the spacing of each side rail as necessary.




Figure 3-3. Side rail adjustment

- c. Re-install the mounting screws. When properly adjusted, the end of each side rail will protrude through the slot in the rear mounting bracket, once the chassis is rack mounted.

3. Installation

FSN-1004 Rack-Mount Procedure

3. To facilitate easy rack mounting, each rack ear on the front of the FSN-1004 is equipped with a special “keyhole” slot on the lower hole, as shown below.




Figure 3-4. Rack Ear Keyhole

To take advantage of this feature, ensure that there is at least 1/2” of clearance above the chassis’ intended 6RU location.




Figure 3-5. Equipment Rack Layout

4. For the FSN-1004’s two keyhole slots, measure and install two rack screws in your equipment rack’s front rails. Allow each screw to protrude approximately 3/4” from the surface of the rails.
5. Lift the chassis, and while supporting it, slide the side rails through the slots in the rear mounting brackets.
6. While continuing to support the chassis, slide the screws (in the front rails) through the two keyholes, and let the chassis settle up into the keyhole slots.
7. Tighten the two lower screws, then install and tighten the two uppers screws in the rack rail.

System Connections

The figure below illustrates the connections on the **System** card's rear panel, plus the power connections. Use this figure for reference during installation.




Figure 3-6. System card and power connections

- Use the following steps to install “system” connections on the **FSN-1004**:
 1. Ensure that the **FSN-1004** is properly rack mounted. If not, refer to the [“FSN-1004 Rack-Mount Procedure”](#) section on page 53 for instructions.
 2. On the **System** card's rear panel, ensure that the **Ethernet Port** is connected to the **Ethernet Switch**, and the **Switch** is connected to an **Ethernet Port** on your PC.

Note

As an alternate method, you can use a direct Ethernet connection between the **FSN-1004** and your **PC**.

3. Installation

System Connections

3. (Recommended) Using a BNC cable, connect an analog reference video input to the **Ref In** connector. This connection enables you to genlock the FSN-1004 to an external reference.
 - ~ Accepted signals are black burst, SMPTE bi-level sync and tri-level sync.
 - ~ Computer sync is not an accepted signal.
4. (Optional) Using a BNC cable, connect the **Loop** connector to the reference video input on the next device in your video system. This connection enables you to “daisy-chain” reference video to additional devices.

Important

If the reference **Loop** connection is not used, connect a 75 ohm terminator to the connector.

5. (Optional) Using a BNC cable, connect the **Ref Out** connector to the reference video input connector on the next video device in your system, or to a reference DA (distribution amplifier) for multiple reference feeds.

Important

This connection assumes that the FSN-1004 is the “master” sync source in your system, for distributing an advanced sync signal to additional devices such as cameras.

Please note:

- ~ Using the **{Reference Out}** button on the **Reference and Output Setup Menu**, toggle this output between **Tri-Level Sync** and **Black Burst**.
 - ~ The sync out format (as provided on the connector) changes, depending on the selected native video format. In Appendix A, refer to the [“Reference Video Output Specifications”](#) section on page 223.
6. For AC connections, one **AC** connector is provided for each FSN-1004 power supply. Please note:
 - ~ One supply is standard, the redundant supply is optional.
 - ~ In a redundant configuration with both supplies installed, the FSN-1004 can be powered from two different circuit breakers.

Open the FSN-1004 front door and note the number of power supplies installed. If only one supply is installed, note its location (in the top or bottom slot).

3. Installation

System Connections

7. Connect the supplied **AC Power Cord(s)** to the AC connectors on the rear of the FSN-1004, and then to AC outlet(s).
 - ~ If a power supply is installed in the top slot, use **AC Connector 1**.
 - ~ If a power supply is installed in the bottom slot, use **AC Connector 2**.

Note

Connect the FSN-1004 to a properly rated supply circuit. Reliable grounding of rack-mounted equipment should be maintained. Refer to the "[Power Cord/Line Voltage Selection](#)" section on page 58 for details.

3. Installation

System Connections

Power Cord/Line Voltage Selection

The FSN-1004 is rated to operate with the following specifications:

- **Input Power:** 100-240 VAC, 50-60 Hz
- **Power Consumption:** 800 watts maximum

Each FSN-1004 component performs line voltage selection automatically, and no user controls are required. The AC power cords must be accessible so that they can be removed during field servicing.



Warning

When the FSN-1004 is used in the 230-volt mode, a UL listed line cord rated for 250 volts at 15 amps must be used and must conform to IEC-227 and IEC-245 standards. This cord will be fitted with a tandem prong-type plug.

The rear panel ON/OFF switch does not disconnect the unit from input AC power. To facilitate disconnection of AC power, the power cord must be connected to an accessible outlet near the unit.

Building Branch Circuit Protection (minimum requirements):
For 115 V use 20 A, for 230 V use 8 A.



Figure 3-7. Tandem Prong-type Plug

Avertissement

La choix de la ligne de voltage se réalise automatiquement par le FSN-1004 Transformateur Graphique. On n'a pas besoin du controller usager pour la choix de la ligne de voltage.

Warnung

Das FSN-1004 gerät mu beim Anschlu an 240V ~ mit einer vom VDE auf 250V/10A geprüften Netzleitung mit einem Schukostecker ausgestattet sein.

Card and Rear Panel

The FSN-1004 ships with all cards installed. The following instructions are provided in case a card needs to be replaced.

The table below outlines the card slots within the FSN-1004 chassis. Use this chart for reference during the following procedures, and remember that all cards and their rear panels are hot-swappable.

Table 3-2. FSN-1004 chassis card slot allocations

Card Type	Max. # of Cards per Chassis	Slot Number(s)
System	1	14
M/E	1	8
UIC (Universal Input Card), 2-channel	5	3 - 7
MVR (Multiviewer Card)	1	11
SOC (Standard Output Card), 2-channel	3	12, 13

Use the procedures in the following sections to insert (and extract) cards, as required:

- [Rear Panel Insertion](#)
- [Rear Panel Removal](#)
- [Card Insertion](#)
- [Card Removal](#)

3. Installation

Card and Rear Panel

Rear Panel Insertion

- To insert a rear panel:
 1. Use [Table 3-2](#) on page 59 to verify the slots in which the cards and their corresponding rear panels can be installed. Front and rear slot numbers will match. For example, if you install an **SOC** in front slot **13**, its corresponding rear panel must be installed in rear slot **13**.
 2. If a blank rear panel is installed in the target slot, loosen the two captive thumb screws in the blank panel, remove it, and store it safely.
 3. Ensure that the selected rear panel is properly oriented:
 - ~ **UIC**: orient the label “1” at the top.
 - ~ **SOC**: orient the label “1” at the top.
 - ~ **MVR**: orient the label “1” at the top.
 4. Using the nylon guides in the chassis for alignment, carefully insert the rear panel into the chassis. Be sure to push on both the top and bottom thumb screws simultaneously, until the card is fully seated in the chassis connector.

Caution

Always push both thumb screws simultaneously. If you only push on one, you can damage the panel or bend a pin.

5. Once the panel is fully seated, tighten the two thumb screws.
6. Repeat from step 1 for all additional rear panels that you want to install.

Rear Panel Removal

- To remove a rear panel:
 1. Loosen the two captive thumb screws in the rear panel, and carefully remove it from the FSN-1004 chassis. Store the panel safely for later use.
 2. Install a blank panel in its place.

Important

Unused rear slots must always have blank panels installed.

3. Repeat from step 1 for all additional rear panels that you want to remove.

Card Insertion

- To insert a card:
 1. Use [Table 3-2](#) on page 59 to verify the slots in which the card can be installed.
 2. Once verified, open the chassis front door and remove it (if desired). In Chapter 2, refer to the [“Chassis Front Door”](#) section on page 28 for details.
 3. Orient the card so that the label (e.g., **UIC**) is at the top. Ensure that both ejectors are unlatched from the slots in the card's front plate.
 4. Once unlatched, hold the top ejector up, as shown below. The bottom ejector will automatically fall away from the front of the card.




Figure 3-8. Ejector Orientation prior to card insertion

3. Installation

Card and Rear Panel

- Using the nylon guides in the chassis for alignment, carefully insert the card into the chassis until both ejectors engage the rim of the card cage. Each ejector will “automatically” angle towards the middle of the card.




Figure 3-9. Ejectors engaged in card cage rim

- On each ejector, squeeze the two black handles together, then simultaneously push both latches into the slot on the card's front plate — until the card is fully seated in the FSN-1004 chassis.




Figure 3-10. Final card insertion

Caution

Always push both latches simultaneously. If you only use one latch, you can damage the card.

3. Installation

Card and Rear Panel

7. Release the handles so that they spring back and lock into place.
8. Repeat from step 1 for all additional cards that you want to install.
9. When complete, re-install the chassis front door, close and secure.

Card Removal

■ To remove a card:

1. Open the chassis front door and remove it (if desired).
2. For the selected card, simultaneously squeeze the two black handles together on each ejector, then pull the ejectors away from the center of the card.




Figure 3-11. Card removal

Caution

Always pull both latches simultaneously. If you only use one latch, you can damage the card.

3. When both latches have disengaged from the chassis, remove the card completely and store it safely in an anti-static bag.

Important

Unused rear slots must always have blank panels installed.

4. Repeat from step 2 for all additional cards that you want to remove.
5. When complete, re-install the chassis front door (if required), close and secure.

3. Installation

Signal Connections

Signal Connections

The following topics are discussed in this section:

- [Output Connections](#)
- [Universal Input Connections](#)
- [Analog Format Connection Table](#)
- [Multiviewer Connections](#)

Output Connections

Aux (auxiliary) buses are extra switching buses that allow video signals to be routed from the FSN-1004 to external equipment. The figure below illustrates the Aux output connections on the **M/E** card's rear panel, and the **SOC** rear panel:




Figure 3-12. Aux output connections

- Use the following steps to connect Aux outputs from the FSN-1004.
 1. Using BNC cables, connect **Aux Outputs 1** through **6** to your target auxiliary devices or monitors. These six outputs run at the system's native resolution.
 2. Use BNC, DVI or HD-15 cables (as required) to connect outputs to your target devices. Use the **Aux Setup Menu** to set the output resolution for each **SOC** output. In Chapter 4, refer to the "[Output Setup Menu](#)" section for setup details.

Please note:

- Use the **Aux Setup Menu** to map **SOC** Aux outputs to a GUI button, and name Aux outputs (if desired). In Chapter 4, refer to the "[Output Setup Menu](#)" section on page 138 for setup details.

3. Installation

Signal Connections

Universal Input Connections

The figure below illustrates universal input connections on a **UIC**'s rear panel:




Figure 3-13. Universal input connections

- Use the following steps to connect universal inputs to a **UIC**.
 1. Using an HD-15 cable directly, or an HD-15 to 5 x BNC breakout cable, connect the desired analog input to the **Universal Input 1, Analog** connector.
 2. Using a standard DVI cable, connect the desired digital input to the **Universal Input 1, Digital** connector. The connector accepts digital signals only.
 3. Using a BNC cable, connect the desired SDI signal to the **Universal Input 1, SDI** connector.
 4. Using an HD-15 cable directly, or an HD-15 to 5 x BNC breakout cable, connect the desired analog input to the **Universal Input 2, Analog** connector.
 5. Using a standard DVI cable, connect the desired digital input to the **Universal Input 2, Digital** connector. The connector accepts digital signals only.
 6. Using a BNC cable, connect the desired SDI signal to the **Universal Input 2, SDI** connector.

Please note the following important points:

- You can connect three signals to **UIC Input 1**, and three signals to **UIC Input 2**, but you can only use one signal at a time for each input. However, you can also store setup files for different input combinations, and recall the desired setup. Use

3. Installation

Signal Connections

the **Input Setup Menu** to set up universal input signals. In Chapter 4, refer to the [“Input Setup”](#) section on page 117 for setup details.

- In Chapter 5, refer to the [“Universal Input Setup”](#) section on page 172 for step-by-step setup instructions.
- Refer to the [“Analog Format Connection Table”](#) section on page 67 for a chart of analog formats available when using a customer supplied breakout cable.
- In Appendix A, refer to the [“Output Format Tables”](#) section on page 231 for a list of available input formats for the FSN-1004.
- The two SDI inputs enable you to connect SDI sources.

Analog Format Connection Table

Each HD-15 analog connector on the **UIC** enables you to input a variety of video formats — including VGA, composite video, S-video and YUV component video.

- For RGB with H and V sync, use the HD-15 connector directly.
- Using a customer supplied HD-15 to 5 x BNC breakout cable, several input combinations are possible. Cells with check marks denote the connections required for the indicated format.

Table 3-1. Analog Input Combinations using Breakout Cable

Breakout Cable Wire Color	Composite Video	S-Video (Y/C)	YUV (YP _b P _r)	RGB Sync on Green	RGB Comp Sync	RGB Separate H V
R			✓ (P _r)	✓	✓	✓
G	✓	✓ (Lum)	✓ (Lum)	✓	✓	✓
B		✓ (Chroma)	✓ (P _b)	✓	✓	✓
H Sync					✓	✓
V Sync						✓

3. Installation

Signal Connections

Multiviewer Connections

The figure below illustrates monitor output connections on the **MVR**'s rear panel:




Figure 3-14. Universal input connections

Please note:

- In both single and dual monitor configurations (as selected on the **Multiviewer Setup Menu**), the same signal appears on both the **DVI-I** and **BNC** connectors.
- Use the following steps to connect **MVR** outputs to your monitor(s).
 1. In single monitor configurations, use DVI and/or BNC cables to connect the DVI and/or SDI multiviewer output(s) to your monitor(s). The same signal appears on outputs 1 and 2.
 2. In dual monitor configurations:
 - ~ Use DVI and/or BNC cables to connect the DVI and/or SDI multiviewer **Monitor 1** output(s) to your assigned “left” monitor(s).
 - ~ Use DVI and/or BNC cables to connect the DVI and/or SDI multiviewer **Monitor 2** output(s) to your assigned “right” monitor(s).
 3. If you want to display time on the Multiviewer from an external LTC source, connect the output of your time code source (e.g., time code generator) to the **LTC Input** as follows:
 - ~ For a differential connection, use the **+**, **-** and **GND** terminals.
 - ~ For a single-ended connection, use the **+** and **GND** terminals.

4. Menu Orientation

In This Chapter

This chapter describes all system menus, including the functions that are available, and descriptions of each menu tree (in block diagram format).

The following topics are discussed:

- [Menu Tree](#)
- [Using the Menu System](#)
- [Buttons, Tables and Matrices](#)
- [Using the Keypad](#)
- [Using the Pop-up Keyboard](#)
- [Memory Menu](#)
- [Stills Menu](#)
- [Screens Menu](#)
- [System Menu](#)

Note

Once you have reviewed all of the sections in this chapter, please continue with Chapter 5, "[System Setup](#)" on page 163.

4. Menu Orientation

Menu Tree

Menu Tree

Two menu trees are illustrated in this section. Please use these diagrams for reference as you learn how to operate the system.

- [High-Level Menu Tree](#)
- [System Menu Tree](#)

High-Level Menu Tree

The figure below illustrates a high-level view of the menu tree.




Figure 4-1. FSN-1004 High-Level Menu Tree

4. Menu Orientation

Menu Tree

System Menu Tree

The figure below illustrates an expanded view of the **System Menu**.




Figure 4-2. FSN-1004 System Menu Tree

4. Menu Orientation

Using the Menu System

Using the Menu System

This section lists the rules and conventions for using FSN-1004 menus. For orientation purposes only, the figure below illustrates the various menu sections.




Figure 4-3. Sample Menu Layout

1) Title Bar	3) Palette	5) Tool Bar
2) Prompt Bar	4) Menu Bar	

Following are descriptions of each section and each type of button:

1) Title Bar

At the top of each menu, the **Title Bar** always names the current menu. When sub-menus are displayed, the convention of “**Parent Menu > Sub Menu**” will be used, e.g., **Keyer Menu > Advanced**.

2) Prompt Bar

Immediately below the **Title Bar**, the **Prompt Bar** provides a line of “help text” for each menu. The prompt changes according to the various functions selected on the menu.

4. Menu Orientation

Using the Menu System

3) Palette

In the center of the menu, the **Palette** provides an area for menu-specific and function-specific buttons, graphics and tables.

4) Menu Bar

Along the left side, the **Menu Bar** provides instant access to all primary menus. Each button is latching, and mutually exclusive with all other navigation buttons. When pressed, the button “lights” and the selected menu is displayed.




Figure 4-4. Navigation button selection

The **Menu Bar** does *not* scroll. Instead, press the **Page** button at the bottom of the bar to change navigation pages in groups of six buttons with each press.

5) Tool Bar

The **Tool Bar** at bottom edge of the menu displays up to 10 primary functions and options for the selected menu.

Note

There are many types of buttons that can appear on the **Tool Bar** and in the **Palette**. Refer to the [“Buttons, Tables and Matrices”](#) section on page 74 for details.

4. Menu Orientation

Buttons, Tables and Matrices

Buttons, Tables and Matrices

There are a variety of button “types” that can appear in the menus, and there are also general rules that apply to button categories, colors, tables and matrices. Detailed explanations are provided below.

- [Button Categories and Colors](#)
- [Latching, Momentary and Conditional Buttons](#)
- [Value Buttons](#)
- [Toggle Buttons](#)
- [Pop-up Buttons](#)
- [Location Buttons](#)
- [Summary of Button Types](#)
- [Tables](#)
- [Matrices](#)
- [Notes and Error Messages](#)

Button Categories and Colors

General button categories and color schemes are outlined below:

- **Menu Bar Buttons** are always gray. When pressed, the button lights and the selected menu is displayed in the **Palette**.




Figure 4-5. Menu Bar Buttons

- **Function Buttons** are always blue, and there are many different types such as “pop-ups” and “toggles.” Each type performs a specific function on the current menu, and behaves in a specific manner. See below for details.



Figure 4-6. Function Buttons

Note that in some cases, a button may be “grayed out,” indicating that the function is currently not available.



Figure 4-7. Grayed Out Button

4. Menu Orientation

Buttons, Tables and Matrices

- **Navigation Buttons** are brown, and when pressed, they take you to a new location in the menu tree. For example:
 - ~ Press to switch to a sub-menu beneath the current “parent” menu. In the sub-menu, the **{Back}** button appears in the **Tool Bar**, enabling you to go “back” up one level in the menu tree.
 - ~ Press to switch to a completely different menu, or a special navigation pop-up, that enables you to choose the next destination menu.




Figure 4-8. Navigation Buttons

Note

Because its function remains constant throughout the entire menu system, the **{Back}** button will not be explained any further in this chapter.

Latching, Momentary and Conditional Buttons

Latching, momentary and conditional buttons are explained below:

- **Latching**

The figure below illustrates both states of a **Latching** function button. The name of the function is written on the button itself.




Figure 4-9. Latching button states

- ~ When **OFF**, the button is unselected, unlit, and the function is inactive.
- ~ When **ON**, the button is selected, lit, and the function is active.

- **Momentary**

Both “function” and “navigation” buttons can be momentary:

- ~ A **Momentary** blue “function” button lights briefly when pressed, performs the selected function, then returns to its default “off” condition.



Figure 4-10. Momentary Function Button Sequence

4. Menu Orientation

Buttons, Tables and Matrices

- **Conditional**

The figure below illustrates both states of a **Conditional** function button.




Figure 4-11. Conditional button states

Conditional buttons appear when certain conditional functions are required. They can be either momentary or latching, depending on the required function.

Value Buttons

The figure below illustrates a **Value** button.



Figure 4-12. Value button

When certain functions are enabled in a menu. These buttons let you to enter values for the selected parameter. The parameter's current value appears within the button's dark blue insert. To adjust the value:

- Press the value button. When pressed, the button latches and the **Keypad** appears. Refer to the ["Using the Keypad"](#) section on page 82 for details.

Toggle Buttons

The figure below illustrates both states of a **Toggle** button.




Figure 4-13. Toggle button states

Toggle buttons are two-state "function" buttons with a cyan colored insert, and the current state appears within the insert (e.g., **On** or **Off**). Pressing the button changes the state of the selected function.

Pop-up Buttons

The figure below illustrates both states of a **Pop-up** button.




Figure 4-14. Pop-up button states (sample)

A **Pop-up** button has a dark blue colored insert, and just like a **Toggle**, the current selection appears within the insert. When pressed, the button latches, and a pop-up appears (on top of the **Palette**) with an array of options.

When you select an option, the pop-up clears and the selection appears within the insert. To cancel without making a change, simply press the pop-up button again to cancel the operation.

Location Buttons

The figure below illustrates a **Location** button.



Figure 4-15. Location button

A **Location** button is a type of **Navigation** button that takes you to a new location in the menu tree, but because the button behaves like a pop-up, there is a choice of locations within the same “parent” menu.

When pressed, the button latches, and a pop-up appears. When you select a location, the pop-up clears and the new location appears within the yellow insert.

To cancel without making a change, simply press the pop-up button again to cancel the operation.

4. Menu Orientation

Buttons, Tables and Matrices

When the switcher location changes, the label in the **Title Bar** also changes.

The figure below illustrates both states of a **Location** button.












Figure 4-16. Location button states (sample)

Summary of Button Types

The table below summarizes buttons types, attributes, colors and functions.

Table 4-1. Button types, colors and functions

	Type	Attributes	Color	Insert	Function
	Menu Bar	Latching	Gray	—	Provides direct access to all primary menus.
	Function	Latching	Blue	—	Enables and disables the selected function. May have an associated "Conditional" button that appears when the function button is latched.
	Function	Momentary	Blue	—	Performs the selected function, then returns to its default "off" state.
	Navigation	Momentary	Brown	—	Changes your view to a new location in the menu tree.
	Value	Latching	Blue	Dark Blue	Enables entry of values for the selected parameter.
	Toggle	Momentary	Blue	Cyan	Toggles between two states only, for the selected function.
	Pop-up	Latching	Blue	Dark Blue	Provides a choice of two or more options for the selected function.
	Location	Latching	Brown	Yellow	Provides a choice of locations within the same "parent" menu.

4. Menu Orientation

Buttons, Tables and Matrices

Tables

The FSN-1004 user interface makes extensive use of tables, for a variety of functions such as keys, memory registers, tallies, etc. The figure below illustrates a sample table:

Heading	Heading	Heading	Heading
Data	Data	Data	Data
Data	Data	Data	Data
Data	Data	Data	Data
Data	Data	Data	Data

Figure 4-17. Sample Table

Each table includes a heading row at the top, and multiple data rows beneath. The “highlighted” yellow row indicates that functions can be performed to the device (or parameter) that is shown on this row.

The yellow highlight can be scrolled automatically or manually. For example:

- On the **Input Setup Menu**, the highlight *automatically* jumps to a certain row, when you click on the associated graphic of a rear-panel connector.
- On the **Memory Menu**, you can simply click on the desired register to highlight the desired row.




Figure 4-18. Manual table, with scrolling via direct touching

Matrices

On certain menus such as the **Output Test Pattern Menu**, matrices are provided that enable you to choose a particular item (from a large group of items). A sample matrix is shown below:




Figure 4-19. Sample Matrix

In the matrix, each function is a mutually exclusive button. To select a function, touch the desired button. The yellow border indicates the current selection. Note that in some cases (as shown above), a function may be grayed out.

Notes and Error Messages

In certain cases, notes will pop-up that provide important information about a process, a function, or a “prompt” for further action. Each note has a title box, a subject line, an “explanation” section and a **Close** button — which clears the note from the menu. Some notes also include buttons for various choices, such as “**Yes**” or “**No**.”

A sample note is shown below.




Figure 4-20. Sample note

If an error occurs, a red “**Error**” button will appear in the top right corner of the menu — superimposed over the **Title Bar**. If this occurs, press the **Error** button to display a note for more information. A sample error message is shown below.




Figure 4-21. Sample error message

If an “**LOS**” or “**Invalid Signal**” error occurs to an input, the **Programmable Display** turns red, and the red “**Error**” button appears. These error messages can be turned off, if desired. In Chapter 6, refer to the “[Understanding Error Messages](#)” section on page 186 for full details.

4. Menu Orientation

Using the Keypad

Using the Keypad

When a value button is pressed, the **Keypad** appears. The figure below illustrates a sample **Keypad**:




Figure 4-22. Keypad (sample)

1) Function Bar	5) +/-	9) Trim -
2) Register	6) Close	10) Trim +
3) Backspace	7) Undo	11) Enter
4) Numerics	8) Clear	12) Decimal

Following are descriptions of each section and each type of button in the **Keypad**:

1) Function Bar

The **Function Bar** displays the selected parameter's range, and when required, provides a mini-prompt for the function that you are entering. For example:

▲ If you press the **{Hue}** value button, the prompt reads:
Range: 0 - 360

▲ If you press the **{Brightness}** value button, the prompt reads:
Range: 1 - 100

2) Register

The **Register** displays a parameter's *current* value when the **Keypad** first appears. This enables you to "trim" existing values or enter new values. The

4. Menu Orientation

Using the Keypad

register clears when you begin entering numbers, and digits shift left as you enter them. You must press **{Enter}** to complete an entry.

3) Backspace

Press **Backspace** {←} during a numeric entry process to clear the register by one digit with each press.

4) Numerics

Press the numeric buttons **{0 - 9}** to enter values. Digits shift left in the **Register** as you enter them. Use the **{Decimal}** button as required for entries that include decimal values.

5) +/-

Press **{+/-}** to invert the numeric entry in the **Register** (if applicable). For example, press **{+/-}** to change **+350** to **-350**.

Note

The **{+/-}** button is only applicable when certain **Keypad** functions that accept negative values are active.

6) Close

Press **{Close}** to clear the **Keypad** from the **Touch Screen**, and “un-latch” the selected value button.

Note

If you press **{Close}** prior to pressing **{Enter}**, **{Trim +}** or **{Trim -}**, the **Keypad** clears, and the previous value is maintained.

7) Undo

Prior to pressing **{Enter}**, press **{Undo}** at any point during the numeric entry process to restore the original value, even if **{Clear}** or **{+/-}** was pressed.

Note

If **{Enter}** is pressed, that value becomes the new value to which the register will return, if **{Undo}** is pressed.

8) Clear

Press **{Clear}** during a numeric entry process to clear the register to **0** (zero).

9) Trim -

Enter an offset value using the numeric buttons, then press **{Trim -}** to subtract from the parameter's current value. Pressing **{Enter}** is not required, and the “trim” value remains in the register, enabling you to trim repeatedly by the same offset. Once the value is trimmed, you can close the **Keypad**, or perform addition trims or entries in the normal way.

For example:

- ▲ To subtract 5 frames from a transition rate, press the **Rate** button for the desired M/E, then in the **Keypad**, press **{5, Trim -}**.
- ▲ To subtract 25 pixels from a mask value, press the desired mask edge (e.g., **{Mask Top}**), then in the **Keypad**, press **{25, Trim -}**.

4. Menu Orientation

Using the Keypad

10) Trim +

Enter an offset value using the numeric buttons, then press **{Trim +}** to add to the parameter's current value. Pressing **{Enter}** is not required, and the "trim" value remains in the register, enabling you to trim repeatedly by the same offset. Once the value is trimmed, you can close the **Keypad**, or perform addition trims or entries in the normal way.

For example:

- ▲ To add 10 frames to a transition rate, press the **Rate** button for the desired M/E, then in the **Keypad**, press **{1, 0, Trim +}**.
- ▲ To add 2 pixels to a mask value, press the desired mask edge (e.g., **{Mask Bottom}**), then in the **Keypad**, press **{2, Trim +}**.

11) Enter

Press **{Enter}** to accept a new value. When pressed, the **Keypad** remains open, and the new value is immediately active.

12) Decimal

Press the decimal button **{.}** as required for numeric entries that accept decimal values.

Note

The decimal button is only applicable when certain **Keypad** functions that accept decimal values are active.

Please note the following important points regarding the **Keypad**:

- Certain **Keypad** buttons may be grayed out, if their function is not applicable for the current operation.
- On several **Keypads** throughout the system, a "**Default Value**" button appears. When pressed, the parameter's values are returned to their defaults, and the **Keypad** remains open.
- Other types of **Keypads** are used in various system modes, to present arrays of functions from which to select, and to present lists from which you can select various items. For example:
 - ▲ When selecting output formats on the **Output Setup Menu**, a special "list" **Keypad** enables you to select the desired output format from a list of all available output formats.
 - ▲ When mapping sources to buttons, using the **Map Buttons Menu**, a special "list" **Keypad** enables you to select the source that you want to map to the selected GUI button.

Each of these "special" **Keypads** will be discussed in context with their respective features.

Using the Pop-up Keyboard

In several switcher menus, you can use a pop-up **Keyboard** to enter names and descriptions for various switcher functions. For example:

- ▲ On the **Input Setup Menu**, the **Keyboard** is used to name inputs, as they'll appear on the programmable displays.
- ▲ On the **Memory Menu**, the **Keyboard** is used to enter brief descriptions of memory registers.

The figure below illustrates a sample **Keyboard**, in "name" entry mode:




Figure 4-23. Keyboard (sample)

Please note:

- The top bar provides a prompt for the current action, e.g., entering a name or entering a description.
- Below the prompt is the entry register, where letters appear as you type.
- To use the keyboard, enter the desired text in the normal manner.
 - ~ Press **{Enter}** to complete an entry and close the **Keyboard**.

Note

In the **Memory Menu** (in **Store Mode**), the new entry will not immediately appear in the register table. Refer to the "[Naming Registers](#)" section on page 95 for details.

~ Press **{Clear Text}** to clear the entry register.

~ Press **{Cancel}** to cancel an entry and close the **Keyboard**.

- Press **{Caps Lock}** to switch between upper and lower case, where applicable.

Note

In some modes, such as input name entry, **{Caps Lock}** remains on, and not all letters and symbols are available.

4. Menu Orientation

Memory Menu

Memory Menu

The **Memory Menu** enables you to manage your memory registers. This includes the ability to view, name, lock and delete registers, plus the ability to enable or disable Memory Modules, and the sub-sections within each module called “**Enables.**” Remember, however, that the storage and recall modes can only be entered by pressing **STORE** or **RECALL** on the GUI.

The **Memory Menu** includes two different screens:

- The **Memory Menu** itself provides a table of all 1000 memory registers. Refer to the “[Memory Menu Description](#)” section on page 88 for details.
- The **Enables Menu** provides a close-up view of one register only, and all of its associated Enables. Refer to the “[Enables Menu Description](#)” section on page 92 for details.

The term “**Memory Modules**” itself refers to the columns in the Memory Menu’s table of registers. These buttons select the large categories of switcher functions to be included in the selected store or recall operation.

There are three modes in which both of the menus described above can be used:

- In the **View Mode**, you can look at all memory registers, name registers, and view the status of all modules and Enables. You cannot modify the modules or Enables within a register, but you can lock registers and delete registers.
- In the **Store Mode**, you can name registers, modify modules and Enables, but you cannot lock or delete registers.
- In the **Recall Mode**, you can modify modules and Enables, but only those that were initially stored. You cannot name, lock or delete registers.

The table below summarizes the functions you can perform in each mode:

Table 4-2. Memory Menu modes and functions

Memory Menu Mode	Name Registers	Modules	Enables	Lock Registers	Delete Registers
View	Yes	View Only	View Only	Yes	Yes
Store	Yes	Modify	Modify	No	No
Recall	No	Modify	Modify	No	No

The following topics are discussed in this section:

- [Memory Menu Access](#)
- [Memory Menu Description](#)
- [Enables Menu Description](#)
- [Selecting Registers](#)
- [Naming Registers](#)
- [Advanced Memory Functions](#)

Memory Menu Access

To access the **Memory Menu**, press the **{Memory}** button in the **Menu Bar**. When you do this, the following rules apply:

- If neither the **STORE** nor the **RECALL** button is lit, you will access the menu in **View Mode**, which is illustrated in [Memory Menu in View Mode](#).
- If **STORE** is lit, you will access the menu in **Store Mode**, which is illustrated in [Memory Menu in Store Mode](#).
- If **RECALL** is lit, you will access the menu in **Recall Mode**, which is illustrated in [Memory Menu in Recall Mode](#).

Note

Regardless of the mode, you will always return to the last menu used, either the **Memory Menu** or the **Enables Menu**. For example, if you are working on the **Enables Menu** and you jump over to the **Transition Menu**, you will return to the **Enables Menu**.

4. Menu Orientation

Memory Menu

Memory Menu Description

Memory Menu in View Mode

The figure below illustrates a sample **Memory Menu** in the **View Mode**.

Memory	Reg	Lck	Description	Modules			Key
				Sys	Out		
	1	X	Mixed Inputs		X		F1
	2	X	SDI Inputs		X		F2
Stills	3	X	DVI Inputs		X		F3
	4	X	Analog Inputs		X		F4
	5						
	6						
Screens	7						
	8						
	9						
	10	X	Layout 1 (Inputs)		X		F9
	11	X	Layout 2 (Outputs)		X		F10
	12						
	13						
System	14						
	15						

Figure 4-24. Memory Menu, View Mode (sample)

The **Memory Menu** provides a table of all 1,000 memory registers, using a view of 15 rows of registers at a time. The large register table itself is divided into two sections:

- The three left-hand columns list register numbers, locks and descriptions.
 - ~ **Reg** — indicates the register number, from 1 to 1000. Refer to the [“Selecting Registers”](#) section on page 95 for more information.
 - ~ **Lock** — indicates whether or not the register is locked, as set on the **Advanced Memory Menu**. An “x” indicates “locked.” Registers can only be locked and unlocked in **View Mode**.

4. Menu Orientation

Memory Menu

- ~ **Description** — displays a brief description (or name) of the register, as entered via the **{Description}** button. Descriptions can only be entered in **View** and **Store** modes.

Note

The space above these three columns is reserved for the large **STORE** and **RECALL** labels, which confirm each specific mode of operation. When no label is present, the menu is in **View** mode.

- The eight right-hand columns (called “**Modules**”) indicate which modules are included in each register. These columns correspond to the categories of modules available on the panel: **SYS** (System) and **Out**.
Please note:
 - ~ An “**x**” in a cell indicates that the module is included in the register. The “**x**” does not indicate the status of the Enables within the module.
 - ~ A blank cell indicates that the module is not part of the register.
 - ~ If a column heading is grayed out, that module is not currently available.
- In the table, the yellow highlight indicates the selected register. There are two ways that you can select registers, including clicking (pressing) on it and clicking the **{Memory Register}** value button. Refer to the “[Selecting Registers](#)” section on page 95 for details on all selection methods.
- Press **{Description}** to display the keyboard, which enables you to enter a register description (or name). Refer to the “[Naming Registers](#)” section on page 95 for details.
- Press **{Store}** to switch from the current mode to **Store Mode**.
- Press **{Recall}** to switch from the current mode to **Recall Mode**.
- Press **{Enables}** to display the **Enables Menu**, which allows you to view or modify the Enables within each module. Refer to the “[Enables Menu Description](#)” section on page 92 for details.
- Press **{Advanced}** to display the **Advanced Memory Menu**, which allows you to delete and lock registers. Refer to the “[Advanced Memory Functions](#)” section on page 95 for details.

4. Menu Orientation

Memory Menu

Memory Menu in Store Mode

The figure below illustrates a sample **Memory Menu** in the **Store Mode**.




Figure 4-25. Memory Menu, Store Mode (sample)

The menu in **Store Mode** has the same buttons as in **View Mode**, except that the **Advanced** button is dimmed and the following button is added:

- Press **{ENTER}** to store the register.

Memory Menu in Recall Mode

The figure below illustrates a sample **Memory Menu** in the **Recall Mode**.




Figure 4-26. Memory Menu, Recall Mode (sample)

The menu in **Recall Mode** has the same buttons as in **View Mode**, except that the **Advanced** button is dimmed and the following button is added:

- Press **{ENTER}** to recall the register.

4. Menu Orientation

Memory Menu

Enables Menu Description

From the **Memory Menu**, press {Enables} to display the **Enables Menu**, as shown below in the **View Mode**.




Figure 4-27. Enables Menu, View Mode (sample)

The **Enables Menu** provides a close-up view of the selected register only, and all of its associated Enables. The menu can be accessed in all modes (**View**, **Store** and **Recall**), but not all functions are available, depending on the mode.

Within an individual module, **Enables** are arrays of sub-functions that can be toggled on or off. For example:

- If you store a register that includes the SYS module, there are two Enables within that module that divide the SYS into its various functional components.
- You can elect to leave all enables on (and thus store or recall the *entire* SYS), or you can elect to turn specific Enables on or off (and thus store or recall only a *portion* of the SYS). Refer to the “[Enable Descriptions](#)” section on page 94 for a complete explanation of each module’s Enables.

The **Enables Menu** is divided into three sections:

- **Register Table** — The top portion of the menu provides the same table as the **Memory Menu**, but only the selected register is shown on a single line. All column headings are identical, including the space above the three left-hand columns — which is reserved for the large **STORE** and **RECALL** labels.

4. Menu Orientation

Memory Menu

- **Module Section** — Below the table two buttons, one for each module. Lines are drawn to the corresponding cells in the table for reference. Please note:
 - ~ In **Store Mode**, the **SYS** and **Out** buttons are always blue, indicating their availability for storage or modification. When selected, the button is bordered in yellow, and its corresponding Enables appear in the **Enables Section**.
 - ~ In **Recall** and **View** modes, if a button is grayed out, that module was not stored in the selected register. If a button is blue, it can be selected and modified (in **Recall** mode), or viewed (in **View** mode).
- **Enables Section** — When a blue button is selected in the **Module Section**, the bottom portion of the menu shows all available Enables for that module. The title of this section (in the black bar) changes as different modules are selected. Depending on the mode, the Enables can be viewed (only), or modified:
 - ~ In **View Mode**, Enables can only be viewed.
 - ~ In **Store Mode**, Enables can be modified. All Enables will be on by default, when you enter the **Store Mode**.
 - ~ In **Recall Mode**, Enables can be modified — but only those that were originally “enabled” in the selected register.

When an Enable is modified, it can be toggled on or off as desired.

- ~ When toggled **On**, the Enable is included in the selected memory **Store** or **Recall** operation.
- ~ When toggled **Off**, the Enable is excluded from the selected memory **Store** or **Recall** operation.
- ~ When an Enable is grayed out, it was not included in a previous memory **Store** operation.

Refer to the “[Enable Descriptions](#)” section on page 94 for explanations of each category of Enables.

The following functions are also available:

- Registers can be selected by pressing the **{Memory Register}** value button. Refer to the “[Selecting Registers](#)” section on page 95 for details.
- Press **{Description}** to display the keyboard, which enables you to enter a register description (or name). Refer to the “[Naming Registers](#)” section on page 95 for details.
- Press **{Advanced}** to display the **Advanced Memory Menu**, which allows you to delete and lock registers. The menu is only available in **View Mode**. Refer to the “[Advanced Memory Functions](#)” section on page 95 for details.
- On the **Enables Menu**:
 - ~ Press **{All On}** to toggle all Enables on during a **Store** or **Recall** operation.
 - ~ Press **{All Off}** to toggle all Enables off during a **Store** or **Recall** operation.

4. Menu Orientation

Memory Menu

Enable Descriptions

This section provides descriptions of each module's Enables.

Note

All Enables can be toggled on or off, without restriction.

The following topics are discussed:

- [System Enables](#)
- [Out Enables](#)

System Enables

The figure below illustrates the Enables when the **SYS** (System) module is selected:




Figure 4-28. SYS Enables

Following are descriptions of each System Enable:

- **{All Inputs}** — stores or recalls all input setup parameters (including the name) for inputs, as set on the **Input Setup Menu**. Refer to the "[Input Setup](#)" section on page 117 for a menu description.
- **{Multi Viewer}** — stores or recalls all multiviewer settings, as set on the **Multiviewer Setup Menu**. Refer to the "[Multiviewer Setup Menu](#)" section on page 137 for menu details.

Out Enables

The figure below illustrates the available Enables when the **Out** module is selected. If an Enable is grayed out, the SOC card must not be installed.




Figure 4-29. Out Enables (sample)

Following are descriptions of each Out Enable:

- **{PGM 8-1}** through **{PVW 13-2}** — stores or recalls the source assignment on the selected outputs. For example, if **U3-1: SDI** is assigned to **PVW 8-1**, that association will be stored or recalled in the memory register.

Selecting Registers

The following methods are available for selecting memory registers:

- **Memory Menu, Table Selection** — In the **Store**, **Recall** and **View** modes, you can select a register simply by touching any of the 15 visible rows in the register table. The highlight jumps to the selected register.

On the **Memory Menu**, note that when the highlight reaches the top or bottom of the screen, it remains there — and the entire table scrolls.

- **Memory Menu, Value Button Selection** — In the **Store**, **Recall** and **View** modes, on both the **Memory Menu** and the **Enables Menu**, you can select a register by pressing the **{Memory Register}** value button. When the **Keypad** appears, enter the desired register and press **{Enter}**. The highlight jumps to the selected register.

Memory Register

123

Naming Registers

The “name register” feature is available in the following memory modes only:

- **View Mode**
- **Store Mode**

By default, new registers are named **Register_[n]**, where **[n]** is the number of the selected register. As desired, you can enter a custom description of a register.

To use the feature:

- Access the **Pop-up Keyboard**:
 - ~ From the **Memory Menu**, highlight the desired register in the table, and then press **{Description}**.
 - ~ From the **Enables Menu**, press **{Description}**.
- Enter a brief description, then press **{Enter}** to close the **Keyboard**.

Note

In **View Mode**, the new (or edited) description appears immediately in the register table. In **Store Mode**, the new (or edited) description will not appear in the table until the **ENTER** button is pressed on the **Keypad**.

Refer to the “[Using the Pop-up Keyboard](#)” section on page 85 for more information about the **Keyboard**.

Advanced Memory Functions

From the **Memory Menu**, press **{Advanced}** to display the **Advanced Memory Menu**, as

4. Menu Orientation

Memory Menu

shown below.




Figure 4-30. Advanced Memory Menu (sample)

Advanced

The **Advanced Memory Menu** provides access to the following memory functions:

- [Locking and Unlocking Registers](#)
- [Deleting Registers](#)

Please note the following important points regarding the **Advanced Memory Menu**:

- the **Advanced Memory Menu** is only available in **View Mode**.
- If you initiate a **Store** or **Recall** function and you are not in the **Advanced Memory Menu**, the **{Advanced}** button is grayed out.
- If you initiate a **Store** or **Recall** function and you are already in the **Advanced Memory Menu**, the system automatically takes you back to the **Memory Menu**.

These functions occur to prevent you from locking, unlocking or deleting a memory register during a **Store** or **Recall** operation.

Keyboard Shortcuts

Keybrd Short-cut

From the **Memory Menu**, press **{Advanced}** and then press **{Keyboard Shortcuts}** to display the **Advanced Memory Keyboard Shortcuts Popup Menu**, as shown below.

The **Advanced Memory Keyboard Shortcuts Popup Menu** allows you to assign a

function key on your PC to a memory register.




Figure 4-31. Memory Keyboard Shortcuts Pop-Up Menu (sample)

Deleting Registers

Delete Register

The “delete register” feature is available in the following memory mode only:

- **View Mode**

All registers except “locked” registers can be deleted. This action clears the selected memory register completely. To use the feature:

- From the **Memory Menu**, highlight the desired register in the table, and then press **{Advanced}**.
- From the **Enables Menu**, press **{Advanced}**.

On the **Advanced Memory Menu**, ensure that the register is unlocked. Then, press the **{Delete Register}** button to delete the register. You will be asked to confirm.

Locking and Unlocking Registers

Lock
Unlock

The “lock/unlock register” feature is available in the following memory mode only:

- **View Mode**

By default, a newly stored memory register is unlocked. As desired, you can lock a register to prevent accidental deletion, or accidental over-writing.

To use the feature:

- From the **Memory Menu**, highlight the desired register in the table, and then press **{Advanced}**.
- From the **Enables Menu**, press **{Advanced}**.

4. Menu Orientation

Memory Menu

On the **Advanced Memory Menu**, press the **{Lock Unlock}** button to toggle the mode.

- If currently unlocked, pressing **{Lock Unlock}** locks the register, and an "X" appears in the appropriate table cell under the **Lock** heading. If you attempt to delete or over-write the register, an error message pops up on screen.
- If currently locked, pressing **{Lock Unlock}** unlocks the register and removes the "X" from the table cell.

Stills Menu

The **Stills Menu** enables you to store and recall up to 100 still frames. Captured frames are stored in Flash memory, and up to three of these captured frames can be copied into fast-access memory buffers, where they are available for immediate “live” use.

The **Stills Menu** has two operating modes: **Capture** and **Recall**. Still frames can be captured from a UIC input, an Aux input, a test pattern, or a color background. Recalls can be performed into any M/E, SOC, or Multiviewer output by way of three live frame buffers.

The following topics are discussed in this section:

- [Stills Menu Access](#)
- [Stills Menu Description](#)

Stills Menu Access

To access the **Stills Menu**, press the **{Stills}** button in the **Menu Bar**. The **Stills Menu** operates with two basic modes:

- **Capture Mode**
- **Recall Mode**

These modes are toggled by pressing the **{Menu Mode}** button.

Stills Menu Description

The **Stills Menu** operates with two basic modes: Capture and Recall, as described below.

Stills Menu Capture Mode

The figure below illustrates a sample **Stills Menu** in the **Capture Mode**. At the top, below the “Capture Source” title, is the name of the source selected in the pop-up that shows when a user presses the “Assign Capture Source” button. Beneath this are three live-access still buffers that can be filled with any of the up to 100 sources displayed in the array

4. Menu Orientation

Stills Menu

in the middle of the **Stills Menu**.






Figure 4-32. Stills Menu, Capture Mode (sample)



To toggle between the **Capture** and **Recall** modes, press the **{Menu Mode}** button.



In the **Capture** mode, pressing the **{Assign Capture Source}** button displays the pop-up keypad shown below. This keypad is used to assign a capture source for the selected still

4. Menu Orientation

Stills Menu

frame in the array of up to 100 still frames. The source may be from a UIC input, an M/E (Aux) output, a test pattern, or a color background.






Figure 4-33. Stills Menu, Assign Capture Source Pop-Up (sample)



Pressing the **{Capture Still}** button captures the current frame of video from the current source specified with the **{Assign Capture Source}** button and stores it into the selected one of 100 locations in the storage array. If one of the three live still buffers is also selected at the top of the menu, this live buffer will be immediately updated with the still just captured.



Pressing the **{Auto-Advance}** button toggles the auto-advance function between on or off. It stores a frame of video into the selected one of the 100 locations in the storage array. If the **Auto Advance** button is **On**, the next available empty location will be automatically selected, ready for the next capture.

4. Menu Orientation

Stills Menu

Name
Still
Store

Pressing the **{Name Still Source}** button displays the pop-up keypad shown below. This keypad is used to name the selected capture source.




Figure 4-34. Stills Menu, Capture Mode, Name Source Pop-Up

Delete
Still
Store

Pressing the **{Delete Still Store}** button deletes the selected capture source.

Delete
All

Pressing the **{Delete All}** button quickly deletes all capture sources in the array.

Erase
All

Pressing the **{Erase All}** button destructively deletes all capture sources in the array.

Note

The **Erase All** operation can take over five minutes to complete.

4. Menu Orientation

Stills Menu

Summary of Stills Capture Method

Here is a summary of how the buttons in the **Capture Mode** can be used:

- Use the following steps to capture (store) a source image to one of the 100 Flash memory locations:
 1. Press the **{Menu Mode}** toggle button to select the **Capture** mode.
 2. Click on one of the 100 memory locations that you want to capture an image into.
 3. Press **{Assign Capture Source}** to display the pop-up.
 4. Select a source from the list of input sources.
 5. Press **{Assign}** and **{Close}** in the pop-up. The image will then appear in the currently displayed array of 25 image sources.
 6. Press **{Capture Still}**.

For a summary of how stills are recalled, see [Summary of Stills Recall Method](#)” section on page 104.

Still Menu Recall Mode

The figure below illustrates a sample **Stills Menu** in the **Recall Mode**. The layout is that same as for the **Capture Mode**, except for the buttons at the bottom.





Figure 4-35. Stills Menu, Recall Mode (sample)

4. Menu Orientation

Stills Menu


You can recall a captured still frame into one of the three live still buffers shown near the top of the **Stills Menu**. To do this, first select one of the three live still buffers, then select one of the 100 locations that have a captured still. This will immediately copy the selected still into the live still buffer.



To toggle between the **Capture** and **Recall** modes, press the **{Menu Mode}** button.



Pressing the **{Name Still Source}** button displays the pop-up keypad naming. Naming individual still stores can be done in either the **Capture** or **Recall** mode.



Pressing the **{Delete Still Store}** button deletes the selected capture source. Deleting individual still stores can be done in either the **Capture** or **Recall** mode.

Summary of Stills Recall Method

Here is a summary of how the buttons in the **Recall Mode** can be used:

- Use the following steps to map one of the three still buffers to one of the 100 stored images in Flash memory:
 1. Press the **{Menu Mode}** toggle button to select the **Recall** mode.
 2. Click one of the three still buffers that you want to fill.
 3. Click one of the 100 stored images in memory that you want to recall into the still buffer.

For a summary of how stills are captured, see [Summary of Stills Capture Method](#) section on page 103.

Memory Registers can store and recall the state of the three live still buffers. Use the "STILLS" module key in the memory section of the controller to include or eliminate the storage or recall of the live still buffers in the memory register. Use the Enables within the Memory menu to manipulate the storage or recall of individual live buffers. For details, see [Enables Menu Description](#) section on page 92.

Screens Menu

The figure below illustrates the **Screens Menu**. in the **Pgm/PVW** (Program/Preview) Mode:




Figure 4-36. Screens Menu, Pgm/PVW Mode (sample)

4. Menu Orientation

Screens Menu

The figure below illustrates the **Screens Menu** in the **Aux Mixer Mode**:




Figure 4-37. Screens Menu, Aux Mixer Mode (sample)

The **Screens Menu** provides status-at-a-glance for all installed outputs, plus the ability to select a specific output on which to switch sources. To access the menu, press the **Screens** button.

System Menu

The following topics are discussed in this section:

- [System Menu Description](#)
- [Communications Setup Menu](#)
- [Input Setup](#)
- [Multiviewer Setup Menu](#)
- [Output Setup Menu](#)
- [User Preferences Menu](#)
- [Software Menu](#)
- [Output Test Patterns Menu](#)
- [Lock/Unlock GUI](#)
- [Save All](#)
- [Backup and Restore Menu](#)
- [Reset Menu](#)

4. Menu Orientation

System Menu

System Menu Description

The figure below illustrates a sample **System Menu**.




Figure 4-38. System Menu (sample)

The **System Menu** provides access to all setup functions, plus convenient status tables.

Important

For all startup conditions, the **System Menu** is always displayed first.

The following topics are discussed in this section:

- [System Menu Access](#)
- [System Menu Functions](#)
- [Status Tables](#)
- [Lock/Unlock GUI](#)

System Menu Access

To access the **System Menu**:

- Press the **{System}** button.

System Menu Functions

On the **System Menu**, navigation buttons are arranged in three groups:

- **Setup Functions** (at the top of the **Palette**)
- **Miscellaneous Functions** (at the bottom of the **Palette**)
- **Tool Bar** functions

Note

In the **Setup Functions** group, buttons are arranged in the *recommended* order in which the individual setup procedures should initially be performed — from left to right, and from top to bottom.

The following functions are provided in the **Setup Functions** group:

Com
Setup

- Press **{Com Setup}** to display the **Communications Setup Menu**, which enables you to “discover” an FSN-1004 chassis (if required), and set up Ethernet. Refer to the [“Communications Setup Menu”](#) section on page 112 for details.

Input
Setup

- Press **{Input Setup}** to display the **Input Setup Menu**, which enables you to set up switcher inputs. Refer to the [“Input Setup”](#) section on page 117 for details.

Multi-
viewer
Setup

- Press **{Multiviewer Setup}** to display the **Multiviewer Setup Menu**, which enables you to set up all aspects of the Multiviewer. Refer to the [“Multiviewer Setup Menu”](#) section on page 137 for complete details.

Output
Setup

- Press **{Output Setup}** to display the **Out Setup Menu**, which enables you to set up and map standard outputs. Refer to the [“Output Setup Menu”](#) section on page 138 for complete details.

The following functions are provided in the **Miscellaneous Functions** group:

User
Prefs

- Press **{User Prefs}** to display the **User Preferences Menu**, which enables you to set a variety of important user preferences and options. Refer to the [“User Preferences Menu”](#) section on page 151 for details.

Software

- Press **{Software}** to display the **Software Menu**, which enables you to update the FSN-1004 with the latest software version. Refer to the [“Software Menu”](#) section on page 153 for details.



Output
Test
Patterns

- Press **{Output Test Patterns}** to display the **Output Test Patterns Menu**, which enables you to select and display test patterns on all system outputs. Refer to the [“Output Test Patterns Menu”](#) section on page 156 for details.

4. Menu Orientation

System Menu

The following functions are provided in the **Tool Bar**:



- Press **{Lock GUI}** to lock and unlock the GUI. Refer to the [“Lock/Unlock GUI”](#) section on page 158 for details.
- Press **{Save All}** to save all system input and output setup parameters to non-volatile memory. Refer to the [“Save All”](#) section on page 158 for details.
- Press **{Backup and Restore}** to display the **Backup and Restore Menu**, which enables you to backup and restore the system to/from your PC. Refer to the [“Backup and Restore Menu”](#) section on page 160 for details.
- Press **{Reset}** to display the **Reset Menu**, which enables you to perform both soft and factory resets. Refer to the [“Reset Menu”](#) section on page 161 for details.

Status Tables

The **System Menu** includes two status tables, as described below.

- The **System Status Table** provides device, status and software version information:

System Status		
Device	Status	SW Version
FSN-1400	Connected	07.00.25, Oct 3 2012, 11:33:56
FSN-1004 GUI	Connected	07.00.25, Oct 3 2012, 12:21:03

Figure 4-39. System Status Table (sample)

Column descriptions are as follows:

- ~ **Device** — lists the two system devices: FSN-1004 GUI and FSN-1400.
- ~ **Status** — provides device status, either **Connected** or **Not Connected**.
- ~ **SW Version** — lists the device's software version.
- The **FSN-1004 Table** lists important system configuration information:

FSN-1400 Status	
Output Format:	1920x1080p @59.94
Video Reference Input:	External, Locked
M/E (Mix/Effects Card):	Present
MVR (Multiviewer Card):	Present
UIC (Universal Input Card):	5
SOC (Standard Output Card):	2

Figure 4-40. FSN-1004 Table (sample)

Row descriptions are as follows:

4. Menu Orientation

System Menu

- ~ **Output Format** — lists the system's native resolution.
- ~ **Video Reference Input** — lists the system's video reference input and "lock" status.
- ~ **M/E** — **M/E (Mix/Effect) Card** is missing or present.
- ~ **MVR** — **Multiviewer Card** is missing or present.
- ~ **UIC** — lists the number of **Universal Input Cards** installed (5).
- ~ **SOC** — lists the number of **Standard Output Cards** installed (2).

4. Menu Orientation

System Menu

Communications Setup Menu

From the **System Menu**, press **{Com Setup}** to display the **Communications Setup Menu**, which enables you to “discover” an FSN-1400 chassis and set up Ethernet.

The figure below illustrates a sample **Communications Setup Menu**.




Figure 4-41. Communications Setup Menu (sample)

At the top of the menu, the **Ethernet Status Table** provides system Ethernet information, along with an important note reminding you to set both the **IP address** and the **Subnet Mask**, prior to pressing **{Apply}**.

Changes can be made to the ports shown on the highlighted row. The following columns of information are provided:

- **Connection** — lists the FSN-1400 Ethernet port.
- **Status** — provides Ethernet port status, either “**Connected**” or “**Not Connected.**”
- **DHCP** — lists DHCP status, either **ON** or **OFF**.

Note

DHCP status cannot be changed at this time.

- **IP Address** — lists the IP address of the associated Ethernet port. This address can be changed using the **{Set IP Address}** button.

4. Menu Orientation

System Menu

- **Subnet Mask** — lists the subnet mask of the associated Ethernet port. This address can be changed using the **{Set Subnet Mask}** button.
- **MAC** — lists the MAC address of the associated Ethernet port.

In the **Tool Bar**, the following operations can be performed on the highlighted port:

- If the **Status** column in the **Ethernet Status Table** reads **“Not Connected”** for any reason, use the “discover” process to locate the IP address(es) of all **FSN-1400** units within your local network. This action might be required, for example, if the IP address of a particular unit was changed.

Press **{Discover FSN-1400}** to display the following pop-up:

Discover
FSN-
1400

Barco: FSN-1004 GUI

System Menu > Communications Setup

Select a communication port to set up

Ethernet			
Connection	Status	DHCP	IP Address
FSN-1400 Ethernet 1	Connected	Off	192.168.0.4

Important:

- Please set both IP address and Subnet Mask, before

Select the FSN-1400 to which you want to connect

Device	IP Address
FSN1400	192.168.0.4

Up Down Connect

Discover FSN-1400 Set IP Address Set Subnet Mask Apply Restore Default Setting Back

Figure 4-42. Communications Setup Menu, Discover FSN-1400 pop-up (sample)

4. Menu Orientation

System Menu

During this interval, the system searches the network for **FSN-1400** systems. If an **FSN-1400** is not present, the following message appears:



No FSN-1400 found on the network

Figure 4-43. Discover FSN-1400 Not Found pop-up

If an **FSN-1400** is present, **FSN-1400 Selection Keypad** appears:




Figure 4-44. FSN-1400 selection keypad (sample)

In the **Keypad**, touch the desired **FSN-1400**, and then press **{Connect}**.

4. Menu Orientation

System Menu

Set IP
Address

- To change the **IP address** of a highlighted port, press **{Set IP Address}** to display the **IP Address Keypad**:



Figure 4-45. Communications Setup Menu, IP Address keypad (sample)

Enter the desired IP address using the decimal point as the separator between the four "octets," and press **{Enter}**.

Note

You do not have to enter all three digits in a particular octet. For example, you can enter **4** instead of **004**.

4. Menu Orientation

System Menu

Set Subnet Mask

- To change the **Subnet Mask** of a highlighted port, press **{Set Subnet Mask}** to display the **Subnet Mask Keypad**:



Figure 4-46. Communications Setup Menu, IP Subnet Mask keypad (sample)

Enter the desired subnet mask using the decimal point as the separator between the four “octets,” and press **{Enter}**.

Apply

- After setting both the **IP address** and the **Subnet Mask**, press **{Apply}** to complete the procedure.

Restore Default Settings

- To return the highlighted port's IP address and Subnet Mask to their factory default values, press **{Restore Default Settings}**.

Input Setup

From the **System Menu**, press **{Input Setup}** to display the **Input Menu**, which enables you to set up universal switcher inputs. The figure below illustrates a sample **Input Menu**.




Figure 4-47. Input Menu (sample)

The **Input Menu** is divided in half. The left side of the **Palette** shows the **Rear I/O View**, while the right side shows the **Input Table**.

To set up an input, press the desired connector in the **Rear I/O View**. In the **Input Table**, the selected input is automatically highlighted. Once selected, you can name the input, and set up a variety of input parameters.

The following topics are discussed in this section:

- [Rear I/O View Description](#)
- [Connector Colors](#)
- [Input Table Description](#)
- [Input Menu Functions](#)
- [Input Setup Menu](#)
- [Input Setup Menu Tool Bar Functions](#)

4. Menu Orientation

System Menu

Rear I/O View Description

The figure below illustrates a sample **Rear I/O View** on the **Input Menu**:

Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6	Slot 7
		Analog 1	Analog 1	Analog 1	Analog 1	Analog 1
		DVI 1	DVI 1	DVI 1	DVI 1	DVI 1
		SDI 1	SDI 1	SDI 1	SDI 1	SDI 1
		SDI 2	SDI 2	SDI 2	SDI 2	SDI 2
		DVI 2	DVI 2	DVI 2	DVI 2	DVI 2
Not Installed	Not Installed	Analog 2	Analog 2	Analog 2	Analog 2	Analog 2
		UIC	UIC	UIC	UIC	UIC

Figure 4-48. Input Menu, Rear I/O View (sample)

The **Rear I/O View** shows the I/O panels for FSN-1004 slots 3 through 7. This view always matches your system configuration exactly — based on the installed cards. Please note:

- The number of each slot is shown along the top.
- The type of each installed card is shown along the bottom (e.g., **UIC**).
- If a card is not installed, the label “**Not Installed**” appears in the slot.
- To set up an input on a **UIC** card:
 - ~ Press any of the top three connectors to select **Input 1**, or any of the bottom three connectors to select **Input 2**. The selected input is highlighted with a yellow border around all three connectors.
 - ~ Next, press the desired connector (either **Analog**, **DVI** or **SDI**) to highlight it with a green border. This indicates that the connector is selected, and in the **Input Table**, the input is automatically highlighted.

Please note:

- ~ When you switch connectors on the **UIC**, freeze will always be turned off. If “**Black on Invalid Video**” is turned on, the input will go black as it acquires the new input.

Refer to the “[Connector Colors](#)” section on page 119 for important information about **Rear I/O View** connectors.



Connector Colors

On the **Rear I/O Views** of the **UIC** and **M/E** panels, the color of the individual input connectors is significant:



- **Green** indicates that the input is mapped to the GUI, and the signal is OK.



- **Red** indicates that the mapped input has an “**LOS**” or “**Invalid Signal**” error. In this situation, the input’s **Programmable Display** turns red, and the red “**Error**” button appears in the top right corner of the **Touch Screen**. Press the **{Error}** button to learn more. Refer to the “[Notes and Error Messages](#)” section on page 81 for details.

Note

For the input connectors on the **UIC**, this “red” condition only occurs if the input has been mapped to the panel, and the signal was previously OK.

Note


If desired, use the **{Error Reporting}** button to turn the red error message off, and return the **Programmable Display** to green. In this mode, the connector remains red. In Chapter 6, refer to the “[Understanding Error Messages](#)” section on page 186 for full details.



- **Yellow** indicates that the input is un-mapped, and a signal is present.



- **White** indicates that the input is un-mapped, and no input signal has been detected.



The above “color” information is always available on the **Input Menu** and **External DSK Setup Menu**. Press **{Info}** to display the **Input Color Legend Pop-up**:



Figure 4-49. Input Color Legend pop-up

4. Menu Orientation

System Menu

Input Table Description

The figure below illustrates a sample **Input Table** on the **Input Menu**:

Slot	In	Map	Name	Format
3	1	1	U3-1	NTSC - 16:9
3	2	2	U3-2	1280x720p @30
4	1	3	U4-1	NTSC - 16:9
4	2	4	U4-2	1920x1080i @60
5	1	5	U5-1	NTSC - 16:9
5	2	6	U5-2	1280x720p @30
6	1	7	U6-1	NTSC (480i)
6	2	8	U6-2	1280x720p @30
7	1	9	U7-1	NTSC - 16:9
7	2	10	U7-2	1920x1080i @60

Figure 4-50. Input Table (sample)

The **Input Table** provides information about each input, and the yellow highlight automatically tracks the selected input connector in the **Rear I/O View**.

The following columns of information are provided:

- **Slot** — indicates the selected input card slot (1 through 7).
- **In** — indicates the selected input (1 or 2 for a **UIC**).
- **Map** — indicates the button number the on the input selection bus shown in the Screens menu to which the physical input is mapped.
- **Name** — indicates the input's name, as defined with the **{Input Name}** button.
- **Format** — displays the following information:
 - ~ When the associated connector is green, the format is shown:
 - For a **UIC**, the input's resolution is shown (e.g., **1920 x 1080i @ 59.94**).
 - ~ When the associated connector is red, the label "**Error**" is shown.
 - ~ When the associated connector is yellow, the cell is blank.
 - ~ When the associated connector is white, the cell is blank.



Input Menu Functions

The following functions are available in the **Tool Bar**:



- Press **{Input Name}** to associate a four-character name with the selected input. When pressed, the following pop-up **Keyboard** appears:




Figure 4-51. System Menu, Input Name Keyboard (sample)

Enter the desired name and press **{Enter}** on the **Keyboard**. On the panel, the name appears on the display above the selected input. In the table, the name appears in the “**Name**” column.

See the “[Using the Pop-up Keyboard](#)” section on page 85 for more details about the keyboard, and the “[Default Naming Conventions](#)” section on page 122 for details about default input names.



- Press **{Freeze}** to toggle the freeze “state” of the selected input.
 - ~ Select **On** to freeze the input.
 - ~ Select **Off** to un-freeze the input.
- Use the **{Error Reporting}** button to toggle error reporting on or off on a connector by connector basis.
 - ~ When **on**, if an input experiences an error, the associated BNC turns red on the rear I/O view. In addition, the input’s **Programmable Display** turns red, and the “**Error**” button appears.
 - ~ When **off**, the input’s **Programmable Display** remains green, the red “**Error**” button does not appear, and the error message is removed from the list in the **View Errors Menu**. The connector, however, remains red.

Note

You can also use this button to turn error reporting off, after an error has occurred and you have acknowledged it.

4. Menu Orientation

System Menu

In Chapter 6, refer to the "[Understanding Error Messages](#)" section on page 186 for more information.



- Press **{Setup}** to display the **Input Setup Menu** for the selected input.
 - ~ Refer to the "[Input Setup Menu](#)" section for details on the menu functions for inputs.

Default Naming Conventions

Each **UIC** input has a default name which can be left on the panel when inputs are mapped, or changed using the **{Input Name}** function.

- For **UIC** inputs, the convention is **U [slot #] - [input #]**. For example, **U4-1** indicates UIC in slot 4, input 1.

Input Setup Menu

The following figure illustrates a sample of the **Input Setup Menu** when one of the inputs is chosen on the **Input Menu**. This particular figure applies to an Analog input; SDI and DVI inputs will have fewer buttons. The **Capture and Process Panel** is selected by default:




Figure 4-52. Input Setup Menu for Analog Inputs, Capture and Process Panel (sample)

The top portion of the menu displays the same information as the **Input Table** on the **Input Menu** — but only the selected input is shown. The columns of information are identical.

The bottom portion consists of three panels. Each panel, in turn, is divided into sections that pertain to specific adjustment parameters.

Refer to the following sections for details:

- [Input Capture and Process Panel](#)
- [Input Sizing and Scaling Panel](#)
- [Output Color Correction Panel](#)

4. Menu Orientation

System Menu

Capture
And
Process

Input Capture and Process Panel

On the **Input Setup Menu** for universal inputs, press **{Capture and Process}** to display the **Input Capture and Process Panel**.

The panel is divided into two sections:

- [Input Capture and Timing Section](#)
- [Input Processing Section](#)

■ Input Capture and Timing Section

The figure below illustrates the **Input Capture and Timing Section**:




Figure 4-53. Input Capture and Timing Section, Universal Inputs

The following adjustments are provided:

Auto
Acquire
Off

- Press **{Auto Acquire}** to toggle the **Auto Acquire** mode **On** or **Off**. This function is per connector on the **UIC**, and not per input.
 - ~ When **Off**, you can manually set the resolution of the incoming source using the **{Input Format}** button.
 - ~ When **On**, the system attempts to detect the input resolution. As the system auto-acquires, it compares the incoming signal to the formats stored in the **Input Format Table**. When an exact match is found, the format is applied and the **Format** field in the table is updated.

Note

If an exact match cannot be found, you may need to use **{Input Format}** button to set the format manually.

Please note the following important points regarding **Auto Acquire**:

- ~ Once the system acquires a new input format, it automatically scales the input up (or down) to the current native resolution.
- ~ The input's aspect ratio is fully maintained in this process, and no masking will be applied. For example:
 - ▲ If a 1024 x 768 input is scaled up to 1920 x 1080 (HD/1080i), the system fills vertically, leaving black pillars on either side.
 - ▲ If a 1920 x 1080 input is scaled down to 1280 x 720 (HD/720p), the system fills horizontally, leaving black bars on the top and bottom.
- ~ After the input has been acquired, you can manually change the method by which the system fills the screen, and you can also mask any edge and re-scale the input. Refer to the "[Input Sizing and Scaling Panel](#)" section on page 129 for details.

4. Menu Orientation

System Menu

Input
Format

- Press **{Input Format}** to display the **Input Format Keypad**. Use the up (▲) and down (▼) arrows to locate the desired format in the list, then press **{Apply}** to accept. In Appendix A, refer to the “[Output Format Tables](#)” section on page 231 for the complete list of formats.




Figure 4-54. Input Format Keypad

EDID
Format

- Press **{EDID Format}** to display the **EDID Format Keypad**, which enables you to update the preferred EDID (Extended Display Identification Data) resolution for the selected input. EDID is a VESA standard data format that contains

4. Menu Orientation

System Menu

information about a display device and its capabilities, including the preferred (as well as the allowed) device resolutions.




Figure 4-55. EDID Format Keypad

Note

This function is available for analog and DVI inputs only. The button does not appear when an SDI input is selected on the **UIC**.

The selected input's EDID file is stored in non-volatile memory. This file is read by a computer's DVI graphics card during boot-up, when its DVI output is connected to a DVI-I input connector on the FSN-1004. The FSN-1004 must be powered on first for the EDID information to be read.

Important

This feature is designed for advanced users only. Do not program the EDID unless it is necessary.

In the **EDID Format Keypad**, use the up (▲) and down (▼) arrows to locate the desired EDID format in the list, then press **{Apply}** to program the EDID.

Please note the following additional important points:

- ~ The EDID on the **UIC** will be reprogrammed under the following circumstances:
 - EDID settings are changed on the **UIC Input Setup Menu**.
 - Factory defaults are restored on the system.
 - A "SYS" memory register is recalled which contains different EDID settings.
 - A previous system configuration is restored in which different EDID settings are present.

4. Menu Orientation

System Menu



- When a **UIC** is replaced, the EDID on the new **UIC** will be changed to match the previous card's EDID.
- When the **System Card** is hot-swapped.
 - ~ The EDID on the **UIC** will not be reprogrammed when the **{Restore Default Settings}** button is pressed, in the **UIC Input Setup Menu**.
- Press **{Color Space}** to toggle between **SMPTE** and **RGB** processing. Note that the system automatically sets the Color Space based on the selected format, but the color space can be changed if desired.
 - ~ Select **SMPTE** to process the input signal in the SMPTE color space (4:2:2), in which the two chroma components are sampled at half the sample rate of luminance component. This mode is commonly used for cameras, video servers, etc.
 - ~ Select **RGB** to process the input signal in RGB color space (4:4:4), in which the individual red, green and blue signals are sampled at the same rate. The **RGB** mode is typically used for computer and graphic sources.

Note

This function is available for DVI and analog inputs only, with the exception of NTSC and PAL. The button does not appear when an SDI, NTSC or PAL input is selected on the **UIC**.



- Press **{1:1 Sample}** to toggle the 1:1 sampling mode on or off.
 - ~ Select **On** to process the input with pixel-for-pixel sampling to provide better image quality.
 - ~ Select **Off** to process the input with multiple samples for every pixel. This mode generally results in a "softer" image.

Note

This function is available for analog inputs only, with the exception of NTSC and PAL. The button does not appear when SDI, DVI, NTSC or PAL inputs are selected on the **UIC**.



- Press **{Sample Phase}** to display the **Sample Phase** value button. Use the button to adjust the input's A/D converter, allowing you to select where pixels are sampled (ideally, on the pixel's peak).


Range: -16 to 15

Default: 0

For optimum visual results when adjusting high-resolution sources, output a burst test pattern from the source, and adjust for minimum noise.

Note

This function is available for analog inputs only, with the exception of NTSC and PAL. The button does not appear when SDI, DVI, NTSC or PAL inputs are selected on the **UIC**.



- Press **{Adjust H Timing}** to adjust the image's horizontal timing. Three value buttons appear:
 - ~ Use the **{H Pos}** button to set the start of the active area's horizontal offset from H sync.
 - ~ Use the **{H Active}** button to set the width of the active area.

4. Menu Orientation

System Menu

- ~ Use the **{H Total}** button to set the total pixel count per line.

Note

This function is available for analog inputs only, with the exception of NTSC and PAL. The button does not appear when SDI, DVI, NTSC or PAL inputs are selected on the **UIC**.



- Press **{Adjust V Timing}** to adjust the image's vertical timing. Two value buttons appear:
 - ~ Use the **{V Pos}** button to set the start of the active area's vertical offset from V sync.
 - ~ Use the **{V Active}** button to set the number of vertical lines in the image.

Note

This function is available for analog inputs only, with the exception of NTSC and PAL. The button does not appear when SDI, DVI, NTSC or PAL inputs are selected on the **UIC**.

Note

V Total is a fixed value which cannot be adjusted.

Important

Any time that input timing adjustments are made, the mask settings for the selected input will automatically be reset to their default values — without any notification on screen.

■ Input Processing Section

The figure below illustrates the **Input Processing Section** for universal inputs:





Figure 4-56. Input Processing Section, Universal Inputs


The following adjustments are provided:



- Press **{Sharpness}** to display the **Sharpness** value button. Use the button to set the input's sharpness.

Range: -16 (very smooth) to 15 (very sharp)


Default: 0



- Press **{Flicker Filter}** to display the **Flicker Filter** value button. Use the button to adjust the filter for interlaced inputs.

4. Menu Orientation

System Menu



- Press **{Pulldown Comp}** to toggle the Pulldown Compensation mode on or off.
 - ~ Select **On** to apply pulldown compensation, in order to process video derived from film material.
 - ~ Select **Off** to disable the mode. This is the default mode.

Note

This function applies only for standard video (component, s-video, composite) inputs.



- Press **{De-Interlace}** to display the **De-Interlace Pop-up**. If the input is interlaced, this function enables you to set how the system processes the input. The following options are available:
 - ~ Select **Motion Adaptive** to use motion adaptive de-interlacing. In this mode, the **{Motion Threshold}** button appears. See below for details.
 - ~ Select **Field to Frame** to use field-to-frame de-interlacing. This mode avoids motion artifacts by converting individual input fields to progressive output frames.

Note

This function is available for interlaced formats only. The button does not appear for progressive scan inputs.



- If **Motion Adaptive** de-interlacing is selected, press **{Motion Threshold}** to adjust the threshold of the motion adaptive de-interlacer. Because adjustment is rarely required, it is recommended that you leave the function at its default setting.

Range: 0 to 15

Default: 15

Input Sizing and Scaling Panel

The figure below illustrates a sample **Input Setup Menu** when an analog input is chosen on

4. Menu Orientation

System Menu

the **Input Menu**, and the **Sizing and Scaling Panel** is selected:




Figure 4-57. Input Setup Menu for Analog Inputs, Sizing and Scaling Panel (sample)

Sizing and Scaling

On the **Input Setup Menu** for universal inputs, press **{Sizing and Scaling}** to display the **Input Sizing and Scaling** section. This panel enables you to scale a non-native resolution input up (or down) to the system's native resolution, set the image's sizing and scaling, pan and zoom the image, and set a mask if required.

The panel has one section, as shown below, plus additional sections that appear, depending on your selection.




Figure 4-58. Input Sizing and Scaling section

Size and Position

- In the **Input Sizing and Scaling** section, press **{Size and Position}** to display four size/position value buttons, plus the convenient **Quick Adjust** section.

4. Menu Orientation

System Menu



Reset

- ~ Press **{H Size}** to change the universal input's horizontal size. Remember that **{H Size}** and **{V Size}** track together if the **{Lock}** is enabled.
- ~ Press **{V Size}** to change the universal input's vertical size.
- ~ Press the **{Lock}** button to lock or unlock **H** and **V** tracking. When locked, both parameters track together. When unlocked, H and V can be adjusted independently.
- ~ Press **{H Position}** to change the universal input's horizontal position along the X axis.
- ~ Press **{V Position}** to change the universal input's vertical position along the Y axis.
- ~ Press **{Reset}** to reset all size and position values to default (including those performed from the **Quick Adjust Section**). Any Mask values present in the image will not be affected.

The figure below illustrates the **Quick Adjust** section, which appears when **{Size and Position}** is pressed:





Figure 4-59. Quick Adjust Section

The following adjustments are provided:



- ~ Press **{Fill H}** to scale the selected universal input up (or down) to the current native **horizontal** resolution. Please note:
 - Aspect ratio is maintained. Manual size/position adjustments using the four value buttons are maintained.
 - If the left and/or right edges of the image are manually masked, those edges are used for the **Fill H** calculations.
 - Black bars are visible above and below an image, for example, when a 16:9 image is scaled down to 4:3.
 - The top and bottom portions of an image may fall outside of the raster, for example, when a 4:3 image is scaled up to 16:9.

4. Menu Orientation

System Menu

The images below represent two examples of **Fill H**.




Figure 4-60. Fill H examples




- ~ Press **{Fill V}** to scale the selected universal input up (or down) to the current native **vertical** resolution. Please note:
- Aspect ratio is maintained. Manual size/position adjustments using the four value buttons are maintained.
 - If the top and/or bottom edges of the image are manually masked, those edges are used for the **Fill V** calculations.
 - Black pillars are visible to the left and right of an image, for example, when a 4:3 image is scaled up to 16:9.
 - The left and right portions of an image may fall outside of the raster, for example, when a 16:9 image is scaled down to 4:3.

The images below represent two examples of **Fill V**.



Figure 4-61. Fill V examples



- ~ Press **{Fill H/V}** to scale the selected universal input up (or down) to the current native **horizontal** and **vertical** resolutions. Please note:
- Aspect ratio is not maintained. Non-proportional image stretching or compression will occur.
 - If any edges of the image are manually masked, those edges are used for the **Fill H/V** calculations.

4. Menu Orientation

System Menu

The images below represent two examples of **Fill V**.



1024 x 768 scaled up
to 1920 x 1080



1920 x 1080 scaled down
to 1024 x 768

Figure 4-62. Fill HV examples

Pan
Zoom
Source

- ~ Use the **{Reset}** function to reset all size and position values to default.
- In the **Input Sizing and Scaling** section, press **{Pan Zoom Source}** to display four value buttons that enable you to size and position the video *within* the boundaries of the image's current sizing. In this mode, the outside boundaries remain constant, but you can pan and zoom the video inside, as desired.

Note

The **Pan Zoom Source** function does not allow you to reveal video that is outside of the input's active area.

The following functions are provided:

- ~ Press **{Source H Size}** to change the source image's horizontal size. Remember that **{Source H Size}** and **{Source V Size}** track together if the **{Lock}** is enabled.
- ~ Press **{Source V Size}** to change the source image's vertical size.
- ~ Press the **{Lock}** button to lock or unlock **H** and **V** source size tracking. When locked, both parameters track together. When unlocked, **H** and **V** can be adjusted independently.
- ~ Press **{Source H Pos}** to change the source image's horizontal position along the X axis.
- ~ Press **{Source V Pos}** to change the source image's vertical position along the Y axis.
- ~ Press **{Reset}** to reset all source pan and zoom values to default.
- In the **Input Sizing and Scaling** section, press **{Mask}** to display four "manual" mask value buttons, plus the convenient **Mask Presets** section. These functions enable you to mask (crop) the top, bottom, left, and right edges of the universal input. When a mask is applied on a selected edge, black is revealed in each masked section. All values are in percent, and the range is **0.00** to **100.0**.

Mask

The following manual mask controls are provided:

- ~ Press **{Mask Top}** to manually mask the top edge of the universal input.
- ~ Press **{Mask Bottom}** to manually mask the bottom edge of the universal input.
- ~ Press **{Mask Left}** to manually mask the left edge of the universal input.

4. Menu Orientation

System Menu

- ~ Press **{Mask Right}** to manually mask the right edge of the universal input.
- ~ Press **{Reset}** to reset all mask values to default.

The figure below illustrates the **Mask Presets** section, which appears when **{Mask}** is pressed:




Figure 4-63. Mask Presets Section

Note

All mask presets are additive. For example, if you mask to **16:9** and then press **4:3**, the system creates the **4:3** mask using the previous **16:9** image as a base.

The following preset functions are provided:

- ~ Press **{16:9}** to mask the input to a 16:9 aspect ratio.
- ~ Press **{5:4}** to mask the input to a 5:4 aspect ratio.
- ~ Press **{4:3}** to mask the input to a 4:3 aspect ratio.
- ~ Press **{3:2}** to mask the input to a 3:2 aspect ratio.
- ~ Press **{1:1}** to mask the input to a 1:1 aspect ratio.

Remember that once the image is masked as desired, you can use the **{Fill H}**, **{Fill V}** or **{Fill H/V}** functions to scale the image to full screen.

Note

For each mask function, the range shown in the **Keypad's** top **Function Bar** is dynamic. For example, if you press **{Mask Left}** and mask 100 pixels from the image's left edge, when you press **{Mask Right}**, the maximum range is now 100 pixels less.

Important

Any time that input timing adjustments are made, the mask settings for the selected input will automatically be reset to their default values — without any notification on screen.

4. Menu Orientation

System Menu

Input Color Correction Section

The figure below illustrates a sample **Input Setup Menu** when an analog input is chosen on the **Input Menu**, and the **Color Correction Panel** is selected:




Figure 4-64. Input Setup Menu for Universal Inputs, Color Correction Panel (sample)

The following input adjustments are provided:

Bright
Contrast
Gamma

- Press **{Bright Contrast Gamma}** to adjust overall brightness, contrast and Gamma. Three value buttons appear:

~ Use the **{Bright}** button to set brightness.

~ Use the **{Contrast}** button to set contrast.

Range: 50% to 150%

Default: 100%

~ Use the **{Gamma}** button to set gamma.

Range: 0.50 to 3.00 (in .01 increments)

Default: 1.00

RGB
Bright

- Press **{RGB Bright}** to adjust RGB brightness. Three value buttons appear:

~ Use the **{Red Bright}** button to set red brightness.

~ Use the **{Green Bright}** button to set green brightness.

~ Use the **{Blue Bright}** button to set blue brightness.

4. Menu Orientation

System Menu




Range: 50% to 150%

Default: 100%

- Press **{RGB Contrast}** to adjust RGB contrast. Three value buttons appear:
 - ~ Use the **{Red Contrast}** button to set red contrast.
 - ~ Use the **{Green Contrast}** button to set green contrast.
 - ~ Use the **{Blue Contrast}** button to set blue contrast.

Range: 50% to 150%

Default: 100%



- Press **{Hue Sat}** to adjust hue and color saturation. Two value buttons appear:
 - ~ Use the **{Hue}** button to set the hue.

Range: -90 to +90

Default: 0

- ~ Use the **{Sat}** button to set the saturation.

Range: 0 to 125

Default: 100

Input Setup Menu Tool Bar Functions


For all inputs, the following functions are provided in the **Tool Bar**:



- Press **{Save Settings}** to save the selected input's setup parameters in non-volatile memory.



- Press **{Restore Saved Settings}** to recall the selected input's setup parameters from non-volatile memory. This function effectively allows you to return to the saved settings, after making temporary adjustments.



- Press **{Restore Default Settings}** to recall the selected input's default setup parameters back into the input's "temporary" settings. This function does not over-write the "saved" settings.

Multiviewer Setup Menu

From the **System Menu**, press **{Multiviewer Setup}** to display the **Multiviewer Setup Menu**. The figure below illustrates a sample menu.

System Menu > Multiviewer

Setup selected monitor layout.

Memory

Custom


Aux

System

Help

Format: 1920 x1080i @ 59.94

Single Layout 1



Monitor 1 and 2

PIP #	Mode	Source	UMD Text	Color
1	On	PREVIEW	PREVIEW	UMD1
2	On	PROGRAM	PROGRAM	UMD1
3	On	M/E1 PVW	M/E1 PVW	UMD1
4	On	M/E1 PGM	M/E1 PGM	UMD1
5	On	AUX 1	STG LFT	UMD1
6	On	AUX 2	STG RGT	UMD1
7	On	AUX 3	AUX 3	UMD1
8	On	AUX 4	AUX 4	UMD1
9	On	AUX 5	AUX 5	UMD1
10	On	CAM 1	C1-JIM	UMD1
11	On	CAM 2	C2-DAVE	UMD1
12	On	CAM 3	C3-ROB	UMD1
13	On	CAM 4	CAM 4	UMD1
14	On	PC-1	PC-1	UMD1
15	On	PC-2	PC-2	UMD1
16	On	DVR	DVR	UMD1

Page
2 of 2

Output Setup

Select Layout

Select Colors

Clock Setup

Mode
ON

Assign Source

UMD Text

UMD Color
UMD 1

Back

Figure 4-65. Multiviewer Setup Menu (sample)

The **Multiviewer Setup Menu** enables you to set up all aspects of the Multiviewer, including the layout (single or dual), the output resolution, PIP and background colors, UMD (Under Monitor Display) text, and PIP source assignments.

For complete information on Multiviewer setup, refer to Chapter 7, "[Multiviewer Operations](#)" on page 197.

4. Menu Orientation

System Menu

Output Setup Menu

From the **System Menu**, press {**Output Setup**} to display the **Out Setup Menu**. The figure below illustrates a sample menu.




Figure 4-66. Out Setup Menu (sample)

The **Out Setup Menu** enables you to name, map, and set the format for outputs.

To set up an output, press the desired connector in the **Rear I/O View**. In the **Out Setup Table**, the selected output is automatically highlighted. Once selected, you can name the output and set up a variety of parameters for outputs on any installed **SOCs**.

The following topics are discussed in this section:

- [Rear I/O View Description](#)
- [Aux Table Description](#)
- [Aux Mixer Description](#)
- [Output Setup Menu Functions](#)
- [SOC Setup Menu](#)

Rear I/O View Description

The **Rear I/O View** for the **Out Setup Menu** shows the I/O panels for output slots **8**, **11**, **12** and **13**. This view matches your system configuration exactly — based on the installed cards. Please note:

- The number of each slot is shown along the top.
- Only Aux output connectors will be active in the view — all other connectors will be grayed out, including those on the Multiviewers.
- The type of each installed card is shown along the bottom (e.g., **SOC**).
- If a card is not installed, the label “**Not Installed**” appears in the slot.
- To set up an Aux output on the **M/E** card, press the desired connector on the **M/E** card. The yellow border indicates that the connector is selected, and in the **Out Setup Table**, the output row is automatically highlighted.
- To set up a universal output on a **SOC**, press any of the top three connectors to select **Output 1**, or any of the bottom three connectors to select **Output 2**. The selected output is highlighted with a yellow border around all three connectors.

Note

SOC connectors that are not outputting video will be grayed out (e.g., for an un-supported video format).

Aux Table Description

The figure below illustrates a portion of the **Out Setup Table** on the **Out Setup Menu**:

Slot	Out	PGM Name	PVW Name
8	1	PGM 8-1	
8	2		PVW 8-1
8	3	PGM 8-3	
8	4		PVW 8-3
8	5	PGM 8-5	
8	6		PVW 8-5
12	1	PGM 12-1	PVW 12-1
12	2	PGM 12-2	PVW 12-2
13	1	PGM 13-1	PVW 13-1
13	2	PGM 13-2	PVW 13-2

Figure 4-67. Out Setup Table (sample)

The **Out Setup Table** provides information about each Aux output, and the yellow highlight automatically tracks the selected Aux connector in the **Rear I/O View**. Because more than 16 Aux outputs can be installed (and because the table is only 16 rows in length), the table automatically scrolls as required.

The following columns of information are provided:

- **Slot** — indicates the selected card slot (**8**, **11**, **12** or **13**).
- **Out** — indicates the selected Aux output:
 - ~ 1 through 6 on the **M/E** card.
 - ~ 1 or 2 for a **SOC**.

4. Menu Orientation

System Menu

- **PGM Name** — this column indicates the Aux output's default on-line (or on-air) program name (e.g., **PGM 8-1**), or custom name as defined with the **{Out Name}** button. Custom names can be up to eight characters in length.
- **PVW Name**— this column indicates the Aux output's default preview (or off-air) program name (e.g., **PVW 8-1**)

Aux Mixer Description




The FSN-1004 has two output modes for the Aux outputs on the **M/E card**. These modes are selectable through the **{M/E Out Type}** button in the **Out Setup Menu**:

- **Mixer**—In this mode, each pair of Aux outputs uses the odd-numbered output (e.g., **PGM 8-1**) as the physical Program (on-air) output and the even-numbered output (e.g., **PVW 8-1**) as the physical Preview (off-air) output. This output mode serves as a personal-preference alternative to setting up Preview outputs in the Multiviewer.
- **Pgm/Pvw**—In this mode, each Aux output is the physical Program (on-air) output for that channel. Preview for these outputs can be set up in the Multiviewer.

These two output modes apply only to the Aux outputs on the **M/E card**. The **SOC card** outputs only operate in the Program (on-air) mode.

Output Setup Menu Functions

The following functions are available in the **Tool Bar**:



- Press **{Out Name}** to associate a name (up to eight characters in length) with the selected Aux output. When pressed, the pop-up **Keyboard** appears. Enter the desired name and press **{Enter}** on the **Keyboard**. The name appears in the Aux Table's "**Name**" column, replacing the default name. See the "[Using the Pop-up Keyboard](#)" section on page 85 for details about the keyboard.
- Press **{Setup}** to display the **SOC Setup Menu**. The button is grayed out when Aux outputs are selected. Refer to the "[SOC Setup Menu](#)" section below for details on the setup menu functions for universal Aux outputs.

SOC Setup Menu

The figure below illustrates a sample **SOC Setup Menu**, which enables you to set all parameters for universal Aux outputs. The **Output and Process Panel** is selected.




Figure 4-68. SOC Setup Menu (sample)

The top portion of the menu displays the same information as the **Out Setup Table** on the **Out Setup Menu** — but only the selected output is shown. The columns are identical.

The bottom portion consists of three panels. Each panel, in turn, is divided into sections that pertain to specific adjustment parameters.

Refer to the following sections for details on each panel:

- [Output and Process Panel](#)
- [Output Sizing and Scaling Panel](#)
- [Output Color Correction Panel](#)

4. Menu Orientation

System Menu

Output
and
Process

Output and Process Panel

From the **SOC Setup Menu**, press **{Output and Process}** to display the **Output and Process Panel**, which is divided into three sections plus several tool bar functions. Each section is explained below.

- [Output Section](#)
- [Output Processing Section](#)
- [Output Status Section](#)
- [Output and Process Tool Bar Functions](#)
- [Advanced SOC Output Setup Menu](#)

■ Output Section

The figure below illustrates the **Output Section** on the **Output and Process Panel**:




Figure 4-69. Output Section, Output and Process Panel

The following adjustments are provided:

Output
Format

- Press **{Output Format}** to display the **Output Format Keypad**. Use the up (**▲**) and down (**▼**) arrows to locate the desired output format in the list, then press **{Apply}** to set the new Aux output format. Six native resolution Aux outputs are standard:
 - ~ 1280x720p@50
 - ~ 1280x720p@59.94
 - ~ 1920x1080p@50
 - ~ 1920x1080p@59.94 (default)
 - ~ Barco 1200p3G@50
 - ~ Barco 1200p3G@59.94

In Appendix A, see the “[Output Format Tables](#)” section on page 231 for the complete list of formats.

Adv.
Output
Setup

- Press **{Advanced Output Setup}** to display the **Advanced SOC Setup Menu**, which enables you to adjust advanced SOC output parameters. Refer to the “[Advanced SOC Output Setup Menu](#)” section on page 145 for details.

Caution



The **Advanced SOC Setup Menu** is designed for advanced users who are completely familiar with all aspects of output timing adjustments. Do not use this menu if you are uncertain about any output timing parameter.

■ Output Processing Section

The figure below illustrates the **Output Processing Section**:



Figure 4-70. Output Processing Section, Output and Process Panel



- Press **{Sharpness}** to display the **Sharpness** value button. Use the button to set the Aux output's sharpness.
- For interlaced Aux outputs only, press **{Flicker Filter}** to display the **Flicker Filter** value button. Use the button to adjust the filter.
- For interlaced Aux outputs only, press **{De-Interlace}** to display the **De-Interlace Pop-up**. This function enables you to set how the system processes the Aux output. The following options are available:
 - ~ Select **Motion Adaptive** to use motion adaptive de-interlacing. In this mode, the **{Motion Threshold}** button appears. See below for details.
 - ~ Select **Field to Frame** to use field-to-frame de-interlacing. This mode avoids motion artifacts by converting fields to progressive output frames.

■ Output Status Section

The figure below illustrates the **Output Status Section** on the **Output and Process Panel**:




Figure 4-71. Output Status Section, Output and Process Panel (sample)


This section mirrors the selected **SOC** connector on the **Rear I/O View** — either output 1 or output 2 will be listed. Connectors that are not outputting video will be grayed out.

4. Menu Orientation

System Menu


■ Output and Process Tool Bar Functions

On the **Output and Process Panel**, the following functions are provided in the **Tool Bar**:




- Press **{DVI Sync}** to select the polarity of the digital sync output on the DVI connector. The following options are available in the pop-up:

- ~ **+H+V**
- ~ **+H-V**
- ~ **-H+V**
- ~ **-H-V**




- Press **{Analog Type}** to choose the type of analog sync output desired on the HD-15 connector. The following options are available in the pop-up:

- ~ **CVBS**
- ~ **Y/C**
- ~ **SOG/Y**
- ~ **CSync**
- ~ **HV Sync**




- If **{HV Sync}** is selected on the **{Analog Type}** button, press **{Analog Sync}** to select the polarity of the analog sync output on the HD-15 connector. The following options are available in the pop-up:

- ~ **+H+V**
- ~ **+H-V**
- ~ **-H+V**
- ~ **-H-V**



- Press **{Copy All Settings}** to copy all settings on the current SOC channel to another SOC output channel. The **Copy Settings Keypad** appears, which lists all other SOC channels in the frame — except the current channel. Select the desired Aux output, then press **{Copy}** to complete the process.



- Press **{Restore Default Settings}** to recall the selected Aux output's default setup parameters back into the output's "temporary" settings on the menu. Note that all settings on the **Advanced SOC Setup Menu** are also set to default.

■ Advanced SOC Output Setup Menu

From the **SOC Setup Menu**, press **{Advanced Output Setup}** to display the **Advanced SOC Setup Menu**, a sample of which is shown below:




Figure 4-72. Advanced SOC Output Setup Menu (sample)

This menu enables you to adjust SOC output parameters, in order to create a “custom” output format. Please note:

- The top portion displays the same information as the **Out Setup Table** on the **Out Setup Menu** — for the selected output.
- The **Output Status Section** is identical to that on the **SOC Setup Menu**.

Caution

The **Advanced SOC Setup Menu** is designed for advanced users who are familiar with all aspects of output timing adjustments. Do not use this menu if you are uncertain about any output timing parameter.

The following functions are available in the **H/V Output Adjustment** section:

- Press **{Totals}** to set the total number of horizontal pixels and vertical lines. Two value buttons appear:
 - ~ Press **{H Total}** to set the desired total number of horizontal pixels in the output image.



4. Menu Orientation

System Menu

- ~ Press **{V Total}** to set the desired total number of vertical lines in the output image.

Important

Changing the H and V Totals will cause a disruption to the SOC's output video. Press **{Apply}** to apply changes, or **{Undo}** to reverse un-applied changes.

Active and Pos

- Press **{Active and Pos}** to set the H and V active area, and the H and V position. Four value buttons appear:
 - ~ Press **{H Pos}** to set the start of the active area's horizontal offset from H sync, in pixels.
 - ~ Press **{V Pos}** to set the start of the active area's vertical offset from V sync, in lines.
 - ~ Press **{H Active}** to set the width of the active area, in pixels.
 - ~ Press **{V Active}** to set the number of active vertical lines in the output.

Sync

- Press **{Sync}** to adjust the horizontal and vertical sync pulse width. Two value buttons appear:
 - ~ Press **{H Sync}** to adjust the horizontal sync pulse width, in pixels.
 - ~ Press **{V Sync}** to adjust the vertical sync pulse width, in lines.

Offset Timing

- Press **{Offset Timing}** to adjust the SOC output's video timing relative to the system's native resolution. Please note:
 - ~ If the selected SOC output format is vertically locked to the native resolution's vertical sync, the **{Offset Timing}** button is active.
 - ~ If the selected SOC format is not vertically locked to the native resolution's vertical sync, the **{Offset Timing}** button is grayed out.

When **{Offset Timing}** is pressed, two value buttons appear, along with the **{Offset Timing Info}** button:

- ~ Press **{H Offset}** to offset the output's horizontal timing (in pixels), relative to the timing of the system's native resolution. The adjustment range is +/- 1/2 line.
- ~ Press **{V Offset}** to offset the output's vertical horizontal timing (in lines), relative to the timing of the system's native resolution. The adjustment range is +/- 1/2 frame.

Offset Timing Info

- Press **{Offset Timing Info}** to display a pop-up with the following important information on video output offset timing:
 - ~ If the reference input is set to **External**, H and V offsets adjust the video output relative to the video reference input. H and V can be positive or negative values.
 - ~ If the reference input is set to **Free Run**, H and V offsets adjust the video output relative to the switcher's internal Black signal.

Output Sizing and Scaling Panel

Sizing and Scaling

From the **SOC Setup Menu**, press **{Sizing and Scaling}** to display the **Output Sizing and Scaling Panel**. This panel enables you to size and scale the universal output to a different size, position, resolution and mask, as required.

The panel has one **Output Sizing and Scaling** section, (as shown below) plus additional

sections that appear, depending on your selection.




Figure 4-73. Output Sizing and Scaling section



- Press **{Size and Position}** to display four “manual” size/position value buttons, plus the convenient **Quick Adjust** section.
 - ~ Press **{H Size}** to change the universal output’s horizontal size. Remember that **{H Size}** and **{V Size}** track if the **{Lock}** is enabled.
 - ~ Press **{V Size}** to change the output’s vertical size.
 - ~ Press the **{Lock}** button to lock or unlock **H** and **V** tracking. When locked, both parameters track together. When unlocked, H and V can be adjusted independently.
 - ~ Press **{H Position}** to change the output’s horizontal position along the X axis.
 - ~ Press **{V Position}** to change the universal output’s vertical position along the Y axis.
 - ~ Press **{Reset}** to reset all size and position values to default (including those performed from the **Quick Adjust Section**). Any Mask values present in the image will not be affected.

The figure below illustrates the **Quick Adjust** section, which appears when **{Size and Position}** is pressed:




Figure 4-74. Quick Adjust Section

The following adjustments are provided:

- ~ Press **{Fill H}** to scale the output up (or down) to the selected **horizontal** resolution. Please note:
 - Aspect ratio is maintained. Manual size/position adjustments using the four value buttons are maintained.
 - If the left and/or right edges of the image are manually masked, those edges are used for the **Fill H** calculations.
 - Black bars are visible above and below an image, for example, when a 16:9 image is scaled down to 4:3.
 - The top and bottom portions of an image may fall outside of the raster, for example, when a 4:3 image is scaled up to 16:9.
- ~ Press **{Fill V}** to scale the output up (or down) to the selected **vertical** resolution. Please note:

4. Menu Orientation

System Menu

- Aspect ratio is maintained. Manual size/position adjustments using the four value buttons are maintained.
 - If the top and/or bottom edges of the image are manually masked, those edges are used for the **Fill V** calculations.
 - Black pillars are visible to the left and right of an image, for example, when a 4:3 image is scaled up to 16:9.
 - The left and right portions of an image may fall outside of the raster, for example, when a 16:9 image is scaled down to 4:3.
- ~ Press **{Fill H/V}** to scale the output up (or down) to the selected **horizontal** and **vertical** resolutions. Please note:
- Aspect ratio is not maintained. Non-proportional image stretching or compression will occur.
 - If any edges of the image are manually masked, those edges are used for the **Fill H/V** calculations.
- ~ Use the **{Reset}** function to reset all size and position values to default.

When **{Size and Position}** is selected, one additional function is available in the **Tool Bar**:

- ~ Press **{Aspect Ratio}** to display the **Aspect Ratio Pop-up**. This function affects the output's H dimension only. Choices are 16:9, 5:4, 4:3, 3:2, 1:1 and Custom.

When **{Custom}** is selected, the **{Adjust Custom Aspect}** button appears in the **Tool Bar**. Press to display the **{Custom Aspect}** value button. Unlatch to re-display size and position adjustments.


- In the **Output Sizing and Scaling** section, press **{Pan Zoom Source}** to display four buttons which enable you to size and position the video *within* the boundaries of the output's current sizing. In this mode, the output's outside boundaries remain constant, but you can pan and zoom the video inside, as desired.


Note

The **Pan Zoom Source** function does not allow you to reveal video that is outside of the output's active area.

The following functions are provided:

- ~ Press **{Source H Size}** to change horizontal size inside the output's boundaries. Remember that **{Source H Size}** and **{Source V Size}** track together if the **{Lock}** is enabled.
- ~ Press **{Source V Size}** to change vertical size inside the output's boundaries.
- ~ Press the **{Lock}** button to lock or unlock **H** and **V** source size tracking. When locked, both parameters track together. When unlocked, **H** and **V** can be adjusted independently.
- ~ Press **{Source H Pos}** to change the horizontal position inside the output's boundaries along the X axis.
- ~ Press **{Source V Pos}** to change the vertical position inside the output's boundaries along the Y axis.





- ~ Press **{Reset}** to reset all pan and zoom values to default.
- In the **Output Sizing and Scaling** section, press **{Mask}** to display four “manual” mask value buttons, plus the convenient **Output Mask Presets** section. These functions enable you to mask (crop) the top, bottom, left, and right edges of the universal output. When a mask is applied on a selected edge, black is revealed in each masked section. All values are in percent, and the range is **0.00** to **100.0**.

The following manual mask controls are provided:

- ~ Press **{Mask Top}** to manually mask the top edge of the universal output.
- ~ Press **{Mask Bottom}** to manually mask the bottom edge of the universal output.
- ~ Press **{Mask Left}** to manually mask the left edge of the universal output.
- ~ Press **{Mask Right}** to manually mask the right edge of the universal output.
- ~ Press **{Reset}** to reset all mask values to default.

The figure below illustrates the **Output Mask Presets** section, which appears when **{Mask}** is pressed:




Figure 4-75. Output Mask Presets Section

Note

All mask presets are additive. For example, if you mask to **16:9** and then press **4:3**, the system creates the **4:3** mask using the previous **16:9** image as a base.

The following preset functions are provided:

- ~ Press **{16:9}** to mask the output to a 16:9 aspect ratio.
- ~ Press **{5:4}** to mask the output to a 5:4 aspect ratio.
- ~ Press **{4:3}** to mask the output to a 4:3 aspect ratio.
- ~ Press **{3:2}** to mask the output to a 3:2 aspect ratio.
- ~ Press **{1:1}** to mask the output to a 1:1 aspect ratio.

Remember that once the image is masked, you can use the **{Fill H}**, **{Fill V}** or **{Fill H/V}** functions to scale the image to the selected output resolution.

4. Menu Orientation

System Menu

Color
Correct

Output Color Correction Panel

From the **SOC Setup Menu**, press **{Color Correct}** to display the **Output Color Correction Panel**, which includes one section, as shown below:



Figure 4-76. Output Color Correction Section

The following input adjustments are provided:

- Press **{Bright Contrast Gamma}** to adjust the output's overall brightness, contrast and Gamma. Three value buttons appear:
 - ~ Use the **{Bright}** button to set brightness.
 - ~ Use the **{Contrast}** button to set contrast.
 - ~ Use the **{Gamma}** button to set gamma.
- Press **{RGB Bright}** to adjust the output's RGB brightness. Three value buttons appear:
 - ~ Use the **{Red Bright}** button to set red brightness.
 - ~ Use the **{Green Bright}** button to set green brightness.
 - ~ Use the **{Blue Bright}** button to set blue brightness.
- Press **{RGB Contrast}** to adjust the output's RGB contrast. Three value buttons appear:
 - ~ Use the **{Red Contrast}** button to set red contrast.
 - ~ Use the **{Green Contrast}** button to set green contrast.
 - ~ Use the **{Blue Contrast}** button to set blue contrast.
- Press **{Hue Sat}** to adjust hue and color saturation. Two value buttons appear:
 - ~ Use the **{Hue}** button (or knob) to set the hue.
 - ~ Use the **{Sat}** button (or knob) to set the saturation.

User Preferences Menu

From the **System Menu**, press {**User Prefs**} to display the **User Preferences Menu**. The figure below illustrates a sample menu.




Figure 4-77. User Preferences Menu (sample)

The **User Preferences Menu** enables you to set various system preferences.

The following topics are discussed in this section:

- [User Preferences Table](#)
- [User Preferences Functions](#)

4. Menu Orientation

System Menu

User Preferences Table

The figure below illustrates a sample **User Preferences Table**.

Name	Description	Setting
Black on Invalid Video	Range: On/Off	On
Memory Auto Lock	Range: On/Off	Off

Figure 4-78. User Preferences table (sample)

The **User Preferences Table** lists all available preferences, except for those provided in the **Tool Bar**. The yellow highlight indicates the preference that can be changed. To move the highlight, click on another row.

The following columns of information are provided:

- **Name** — lists the name of the user preference.
- **Description** — lists the range of the selected user preference.
- **Setting** — lists the preference's current setting.

The **{Set}** button always applies to the highlighted preference, and the value shown in the button's insert *changes* as different preferences are selected. Press **{Set}** to display the keypad for the selected preference in the table, enabling you to change its value.



User Preferences Functions

The following user preferences are provided:

- **Black on Invalid Video** — when an input is selected on a bus, this preference controls how the system behaves when the input becomes invalid — such as when the input loses sync or video.
 - ~ **On** — shows black in place of the input signal, when the selected signal becomes invalid.
 - ~ **Off** — shows the input signal as is, when the selected signal becomes invalid. In this mode, non-synchronous and/or non-stable video will appear on the switcher's output.

Important

It is highly recommended that you leave the **Black on Invalid Video** preference **On** during production. The **Off** mode may be useful during setup mode only.


- **Memory Auto Lock** — controls automatic locking of the memory register that you have stored to. Default if Off.

Range: On (locked) or Off (unlocked)

- Press **{Set Clock}** to set the system's internal clock, which is used for various logging, reporting and other time-stamping functions. The clock is also used on various Multiviewer layouts.

When pressed, the **Set Clock Keypad** appears, with special keypad functions:

- ~ Ensure that you use the **HH:MM:SS** format to set the clock (Hours:Minutes:Seconds).
- ~ Use the **{:}** button as a separator between digits.



4. Menu Orientation

System Menu

- ~ Press **{AM/PM}** to switch between AM and PM as required.
- ~ Press **{12 HR / 24 HR}** to switch between 12 and 24 hour modes.
- Press **{Reset to Default}** to return a highlighted preference to its default value.

Reset to
Default

Software Menu

From the **System Menu**, press **{Software}** to display the **Software Menu**. The figure below illustrates a sample menu.




Figure 4-79. Software Menu (sample)

The **Software Menu** enables you to update the FSN-1004 and FSN-1400 with the latest software version. The menu's palette provides a table of software versions, plus concise software update instructions.

The following topics are discussed in this section:

- [Software Table](#)
- [Software Functions](#)

4. Menu Orientation

System Menu

Software Table

The **System Menu** includes two status tables, as described below.

- The **System Status Table** provides device, status and software version information:

System Status		
Device	Status	SW Version
FSN-1400	Connected	07.00.25, Oct 3 2012, 11:33:56
FSN-1004 GUI	Connected	07.00.25, Oct 3 2012, 12:21:03

Figure 4-80. System Status Table (sample)

Column descriptions are as follows:

- ~ **Device** — lists the two system devices: FSN-1004 GUI and FSN-1400.
 - ~ **Status** — provides device status, either **Connected** or **Not Connected**.
 - ~ **SW Version** — lists the device's software version.
- The **FSN-1004 Table** lists important system configuration information:

FSN-1400 Status	
Output Format:	1920x1080p @59.94
Video Reference Input:	External, Locked
M/E (Mix/Effects Card):	Present
MVR (Multiviewer Card):	Present
UIC (Universal Input Card):	5
SOC (Standard Output Card):	2

Figure 4-81. FSN-1004 Table (sample)

Row descriptions are as follows:

- ~ **Output Format** — lists the system's native resolution.
- ~ **Video Reference Input** — lists the system's video reference input and "lock" status.
- ~ **M/E** — **M/E (Mix/Effect) Card** is missing or present.
- ~ **MVR** — **Multiviewer Card** is missing or present.
- ~ **UIC** — lists the number of **Universal Input Cards** installed (5).
- ~ **SOC** — lists the number of **Standard Output Cards** installed (2).

Note

When the message "**Software Mismatch**" appears on the FSN-1400 line, you must update the FSN-1400 software. Refer to "Updating FSN-1400 Software" on page 219 for instructions.

Software Functions

The following software functions are provided:

4. Menu Orientation

System Menu



- Press **{Update FSN-1400}** to update FSN-1400 firmware. In Chapter 8, refer to the [“Updating FSN-1400 Software”](#) section on page 219 for instructions.

4. Menu Orientation

System Menu

Output Test Patterns Menu

From the **System Menu**, press {**Output Test Patterns**} to display the **Output Test Patterns Menu**, which enables you to select and display test patterns. Any test pattern can be sent to any output (including Multiviewer outputs), or one test pattern can be sent to all outputs simultaneously.

The test pattern selection does not alter the outputs selected on the GUI, because in the flow of video, test patterns are inserted downstream of the outputs. Once a test pattern is turned off, the originally selected video output returns.

The figure below illustrates a sample **Output Test Patterns Menu**.




Figure 4-82. Output Test Patterns Menu (sample)

The left side of the **Palette** shows the **Rear I/O View** — specifically, slots **8**, **11**, **12** and **13** which include output connectors. This view will match your system configuration exactly. To select an output, touch the desired BNC to highlight it with a yellow border.

Please note:

- The number of each slot is shown along the top of the **Rear I/O View**, and the type of each card is shown along the bottom (e.g., **M/E**).
- If a card is not installed, the label “**Not Installed**” appears in the slot.
- If a BNC connector is not an output (e.g., **DSK Cut**, **DSK Fill**), those BNCs will be grayed out.

4. Menu Orientation

System Menu

The right side of the **Palette** provides a matrix of all available test patterns, plus specific buttons for **{Off}** and **{Raster Box}**.

To send a test pattern to an output, touch the desired BNC in the **Rear I/O View** section, then touch the desired test pattern in the matrix.

The following 13 **Test Patterns** are provided in the matrix:

- H Ramp
- V Ramp
- 100% Color Bars
- 75% Color Bars
- 16 x 16 Grid
- 32 x 32 Grid
- Burst
- 50% Gray
- Gray Steps 1
- Gray Steps 2
- White
- Black
- SMPTE Bars

The following functions are provided in the matrix:

- Press **{Off}** to turn off the test pattern for the selected output.
- Press **{Raster Box}** to enable or disable a raster box for the selected output. The raster box width is fixed at 1 pixel. Note that the raster box can be enabled even if the test pattern is off.

The following functions are provided in the **Tool Bar**:

- Press **{Select All Outputs}** to highlight all outputs in the **Rear I/O View** section. When you select a test pattern in the matrix, that pattern is sent to all outputs.
- Press **{All Off}** to turn off all test patterns and all raster boxes on all outputs simultaneously.



4. Menu Orientation

System Menu

Lock/Unlock GUI

On the **System Menu**, press **{Lock Panel}** to display the following pop-up:




Figure 4-83. System Menu, GUI Lockout Pop-Up

In this mode, the GUI is locked out, and the pop-up remains on display. To unlock the GUI, press **{Unlock}**.

Save All

On the **System Menu**, press **{Save All}** to save all system setup parameters to non-volatile memory. When pressed, a pop-up confirms the save:



Figure 4-84. Save All Pop-up

The following functions are saved when **{Save All}** is pressed:

- Input setups, output setups, DSK settings, and reference video settings
- Communications setups
- Clean Feed assignments, including the **ASSIGN** source association

4. Menu Orientation

System Menu

- Button mappings
- Tally assignments
- User Preferences
- All Aux assignments
- All six “user” colors, from the **Color Background Menu**

Note

The **{Save All}** button in the **Custom Control Section** is identical to the **{Save All}** button on the **System Menu**.

4. Menu Orientation

System Menu

Backup and Restore Menu

From the **System Menu**, press **{Backup and Restore}** to display the **Backup and Restore Menu**, which enables you to back up and restore the system to/from a PC.




Figure 4-85. System Menu, Backup and Restore (sample)

The following functions are provided on the **Backup and Restore Menu**:



- Press **{Backup System}** to initiate the system backup procedure. You will be prompted to select or create a directory for the backup, or to cancel the procedure.



- Press **{Restore System}** to initiate the system restore procedure. You will be prompted to select the directory from which to restore the system files, or to cancel the procedure. After the restore process is complete, you will be prompted to press **{Restart}**, which restarts the FSN-1004.

In Chapter 6, refer to the "[Backing Up and Restoring the System](#)" section on page 196 for complete backup and restore instructions.

Reset Menu

From the **System Menu**, press **{Reset}** to display the **Reset Menu**, which enables you to perform a factory reset and several types of “soft” resets.




Figure 4-86. System Menu, Reset (sample)


On the **Palette**, brief instructions are provided for each type of reset procedure.

The following functions are provided on the **Reset Menu**:



- Press **{Factory Reset}** to reset the entire system to its factory default values. All data will be lost. After pressing the button, the **Factory Reset Pop-up Menu** appears with three options:
 - ~ Reset and save IP settings.
 - ~ Reset all IP settings to factory default values.
 - ~ Cancel the procedure

If you elect to perform one of the two factory reset options, always ensure that you have backed up your system. Refer to the “[Factory Default Settings](#)” section on page 162 for factory reset details.



- Press **{Reset To 1004 Defaults}** to reset the system to FSN-1004 defaults. All stored data is preserved.

4. Menu Orientation

System Menu



- Press **{Soft Reset FSN-1400}** to perform a “soft” reset on the FSN-1400 only. All stored data is preserved, but output video may be temporarily interrupted. After pressing the button, you will be prompted to continue or cancel the procedure.

Factory Default Settings

When you perform a factory reset, defaults are set in multiple switcher locations, as listed in the following table:

Table 4-3. Factory default settings

Switcher Location	Default Setting
All switcher buses	Black
All transitions, rates, curves	Mix, 30 frames, linear
Output format	1920 x 1080p @ 59.94
All UICs	Mapped
Ethernet parameters	Returned to factory defaults or saved — depending on selection in the Factory Reset Pop-up Menu.
Reference input	External
Output V-Lock	Off
Native input sync mode	Auto
Universal inputs auto-acquire	On
Black on invalid video	On (User Preferences Menu)

5. System Setup

In This Chapter

This chapter provides detailed instructions for setting up the FSN-1004 switcher. The following topics are discussed:

- [Setup Prerequisites](#)
- [System Setup Sequence](#)
- [Power Up and Status Check](#)
- [Return to Factory Default](#)
- [Communications Setup](#)
- [Restoring the System](#)
- [Output Format Setup](#)
- [Output Test Patterns](#)
- [Universal Input Setup](#)
- [Aux Output Setup](#)
- [Multiviewer Setup](#)
- [User Preferences Setup](#)
- [Saving the Setup](#)
- [Backing up the System](#)

Note

Once you have reviewed all of the sections in this chapter, please continue with Chapter 6, "[Operations](#)" on page 183.

5. System Setup

Setup Prerequisites

Setup Prerequisites

Before setting up your FSN-1004 switcher, please review the following prerequisites:

- Ensure that you are familiar with the FSN-1004. Refer to Chapter 2, "[FSN-1004 Orientation](#)" on page 25 for details.
- Ensure that all hardware is properly installed, and that all sources and peripherals are properly connected. Refer to Chapter 3, "[Installation](#)" on page 49 for complete details.
- Ensure that you are familiar with all menus and sub-menus.
 - ~ Refer to Chapter 4, "[Menu Orientation](#)" on page 69 for details on all menus except Multiviewer.
 - ~ Refer to Chapter 7, "[Multiviewer Operations](#)" on page 197 for details on all Multiviewer menus.

System Setup Sequence

This section provides a top level view of the entire FSN-1004 setup procedure, plus links to each individual sequence.

Important

For the optimum FSN-1004 setup, it is recommended that you follow all procedures in the order outlined below.

1. [“Power Up and Status Check,”](#) page 166.
2. [“Return to Factory Default,”](#) page 167.
3. [“Communications Setup,”](#) page 168.
4. [“Restoring the System,”](#) page 169.
5. [“Output Format Setup,”](#) page 170.
6. [“Output Test Patterns,”](#) page 171.
7. [“Universal Input Setup,”](#) page 172.
8. [“Aux Output Setup,”](#) page 175.
9. [“Multiviewer Setup,”](#) page 178.
10. [“User Preferences Setup,”](#) page 180.
11. [“Saving the Setup,”](#) page 181.
12. [“Backing up the System,”](#) page 181.

All of the above procedures are covered in the sections that follow in this chapter.

5. System Setup

Power Up and Status Check

Power Up and Status Check



FSN-1004 system setup: **Step 1.**

- Use the following steps to power up your system and check system status.
 - ▲ **Prerequisite** — Ensure that your system is properly installed and cabled. In Chapter 3, refer to the following sections for details:
 - ~ “[PC Connection](#),” page 52.
 - ~ “[System Connections](#),” page 55.
 - ▲ **Prerequisite** — Ensure that you are familiar with the **System Menu**. In Chapter 4, refer to the “[System Menu Description](#)” section on page 108 for complete details.
- 1. Power up the FSN-1004 switcher.
- 2. Launch the FSN-1004 GUI. The **System Menu** is automatically displayed after boot up. If the system is not set up as an FSN-1004, a message says “Do you want to set up as FSN-1004?”. If you answer “Yes”, setup occurs; if you answer “No”, the setup program exits.

Important

If communication is not properly set up, numerous buttons will be grayed out on the **System Menu**. These buttons will activate once communication is properly set.

- 3. Power up all additional peripherals, such as monitors and sources.
- 4. On the **System Menu**:
 - ~ In the **System Status Table**, ensure that all devices are connected. If not, re-check all Ethernet connections. After checking connections, if devices still report “**Not Connected**,” use the “[Communications Setup](#)” procedure on page 168.
 - ~ Ensure that the software versions for the GUI and FSN-1004 match. If not, you may need to update GUI software or match the FSN-1004’s software to the installed GUI software. Refer to Chapter 8, “[Updating Software](#)” on page 215 for details.

Note

If the software versions on the GUI and FSN-1004 match, you do not need to upgrade.

- ~ In the **FSN-1004 Status Table**, ensure that all installed **UIC**, **SOC** and **MVR** cards are recognized. If not, you may need to re-seat the boards in the FSN-1004.

Return to Factory Default

2

FSN-1004 system setup: **Step 2.**

Prior to performing any setup procedures, it is recommended that you perform a factory reset — in order to reset all input, output and source mappings to their default values.

Particularly for customers in the events and rental marketplace, this procedure guarantees that any previous input setups and memory registers (e.g., those that may have been programmed by other users) are completely cleared from system memory.

Note

If you are continuing an event (for example, day two of a three-day event), you do not need to perform a factory reset. However, if you do elect to perform a factory reset, ensure that you have backed up your system. Refer to the “[Backing up the System](#)” section on page 181 for details.

▲ **Prerequisite** — Ensure that you are familiar with the **Reset Menu**. In Chapter 4, refer to the “[Reset Menu](#)” section on page 161.

■ Use the following steps to return the system to factory default values:

1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
2. Press **{Reset}** to display the **Reset Menu**.
3. Press **{Factory Reset}** to reset the entire system to its factory default values. Remember that all data will be lost.
4. When the **Reset Confirmation Pop-up** appears, you can choose to **{Reset and Save IP}**, or **{Reset All}**.

Note

In Chapter 4, refer to the “[Factory Default Settings](#)” section on page 162 for a list of factory default settings.

5. System Setup

Communications Setup

Communications Setup

3

FSN-1004 system setup: **Step 3**

In this procedure, you will set up communication between an FSN-1400 and the FSN-1004 GUI running on your PC or Mac.

▲ **Prerequisite** — Ensure that you are familiar with the **Communications Setup Menu**. In Chapter 4, refer to the “[Communications Setup Menu](#)” section on page 112.

■ Use the following steps to set up communications:

1. In the **Menu Bar**, press **{System}** to access the **System Menu**.

Important

If communication is not properly set up, numerous buttons will be grayed out on the **System Menu**. These buttons will activate once communication is properly set.

2. Press **{Com Setup}** to display the **Communications Setup Menu**.
3. Review the data in the **Ethernet Status Table**, and ensure the following:
 - ~ FSN-1400 Ethernet: **Connected**If status is “**Connected**,” communication is properly set up. Please continue with the “[Output Format Setup](#)” procedure on page 170.
4. If status is “**Not Connected**,” press **{Discover FSN-1400}** to locate the IP address(es) of all FSN-1400 units within your local network.
 - ~ If the pop-up alerts you that no FSN-1400 units have been discovered, check all Ethernet connections, then press **{Discover FSN-1400}** again to re-try the procedure.
 - ~ If FSN-1400 units are discovered, the **FSN-1400 Selection Keypad** appears. Select the desired **FSN-1400**, and press **{Connect}**.
5. **(Advanced)** If you need to change the IP address of a highlighted port, for example, if your system is connected to a house network, press **{Set IP Address}** to display the **IP Address Keypad**. Enter the desired address and press **{Enter}**.
6. **(Advanced)** If you need to change the subnet mask of a highlighted port, press **{Set Subnet Mask}** to display the **Subnet Mask Keypad**. Enter the desired subnet mask and press **{Enter}**.
7. **(Advanced)** If you need to return a highlighted port’s IP address and Subnet Mask to their factory default values, press **{Restore Default Setting}**.

Restoring the System

4

FSN-1004 system setup: **Step 4** (optional)

In this procedure, you will restore your system configuration from a PC — provided that you previously backed up your system to the PC.

▲ **Prerequisite** — Ensure that you are familiar with the **Backup and Restore Menu**. In Chapter 4, refer to the [“Backup and Restore Menu”](#) section on page 160.

■ Use the following steps to restore your system from the PC:

1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
2. Press **{Backup and Restore}** to display the **Backup and Restore Menu**.
3. Press **{Restore System}** to display the PC directory structure, and select the directory that contains the backup files you wish to restore.
4. After the restore process is complete, you will be prompted to press **{Restart}**, which restarts the FSN-1004.

At the conclusion of this procedure, your system is completely set up — exactly the way that you left it when you performed a complete system “backup.” No further setup operations are required.

Please continue with system operations. Refer to Chapter 6, [“Operations”](#) on page 183 for details.

5. System Setup

Output Format Setup

5

FSN-1004 system setup: **Step 5**

In this procedure, you will set up the system's output format (native resolution).

- **Set up format** — Use the following steps to set up the output format:
 1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
 2. Press **{Output Setup}** to display the **Output Setup Menu**.
 3. On the **Output Setup Menu**, press **{M/E Format/Rate}** to display the **Output Format Keypad**.
 4. Select the desired format and press **{Apply}**. In the confirmation pop-up, click **{Set Output Format}** to confirm.

Important

Remember that all input settings will be reset to their default values when you change output formats.

Output Test Patterns

6

FSN-1004 system setup: **Step 6** (optional)

In this procedure, you can display test patterns on selected system outputs (or all system outputs), typically for purposes of setting up external devices.

▲ **Prerequisite** — Ensure that you are familiar with the **Output Test Patterns Menu**. In Chapter 4, refer to the [“Output Test Patterns Menu”](#) section on page 156.

■ Use the following steps to select and display output test patterns:

1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
2. Press **{Output Test Patterns}** to display the **Output Test Patterns Menu**.
3. To display a test pattern on one output:
 - a. Press the desired output connector in the **Rear I/O View** on the left side of the menu.
 - b. Press the desired test pattern in the matrix on the right side of the menu.
 - c. Press **{Raster Box}** to enable or disable the raster box as desired.
 - d. When complete, press **{Off}** to turn the test pattern off.

Note

Remember that you can set a different test pattern on each output.

4. To display a test pattern on all outputs:
 - a. Press **{Select All Outputs}**.
 - b. Press the desired test pattern in the matrix on the right side of the menu.
 - c. Press **{Raster Box}** to enable or disable the raster box as desired.
 - d. When complete, press **{All Off}**.

Important

Ensure that you press **{All Off}** after you have finished using any output test pattern.

5. System Setup

Universal Input Setup

Universal Input Setup

7

FSN-1004 system setup: **Step 7**

In this procedure, you will perform a complete setup on all universal switcher inputs. Ensure that your inputs are properly connected to the selected **UIC** before continuing.

- ▲ **Prerequisite** — Ensure that you are familiar with the following menus:
 - ~ **Input Menu** — Chapter 4, “[Input Setup](#),” page 117.
 - ~ **Connector Colors** — Chapter 4, “[Connector Colors](#),” page 119.
 - ~ **Input Setup Menu** (Universal Inputs) — Chapter 4, “[Input Setup Menu](#),” page 123.

■ **Universal Input Setup** — Use the following steps for basic universal input setup:

1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
2. Press **{Input Setup}** to display the **Input Menu**.

Note

Remember that after a factory reset, **UIC** inputs are not mapped to the GUI, but default names are assigned.

3. In the **Rear I/O View**, press the input connector on the **UIC** that you want to set up. A yellow highlight is placed around all three input connectors, and in the **Input Table**, the input is highlighted.
4. Select the individual **UIC** connector — either the **BNC**, **HD-15** or **DVI**. A green highlight indicates the selection.
5. Press **{Input Name}** to name (or re-name) the selected input. When the pop-up **Keyboard** appears, enter the desired name and press **{Enter}** on the **Keyboard**.
6. Press **{Error Reporting}** to turn error reporting on or off.
 - ~ When **on**, if an input experiences an error, the connector turns red on the rear I/O view, the input's **Programmable Display** turns red, and the “**Error**” button appears.
 - ~ When **off**, the input's **Programmable Display** remains green and the red “**Error**” button does not appear. The connector remains red.

Note

The **{Error Reporting}** function works on a connector-by-connector basis.

■ **Capture and Timing** — Use the following steps to set up universal input capture and timing parameters:

1. Press **{Setup}** to display the **Input Setup Menu** for the selected universal input.
2. Press **{Capture and Process}** to display the **Capture and Process Panel**.
3. Press **{Auto Acquire}** to toggle the **Auto Acquire** mode **On** or **Off** as required.
 - ~ When **Off**, you can set the resolution using the **{Input Format}** button.
 - ~ When **On**, the system attempts to detect the resolution. When a match is found, the format is applied and the **Format** field in the table is

5. System Setup

Universal Input Setup

updated. Once the system acquires a new format, it automatically scales the input up (or down) to the current native resolution.

Note

If an exact match cannot be found, you may need to use **{Input Format}** button to set the format manually.

4. If required, press **{Input Format}** to display the **Input Format Keypad**. Locate the desired format and press **{Apply}**.
5. **Analog and DVI inputs only** — Press **{EDID Format}** to display the **EDID Format Keypad**. Locate the EDID format and press **{Apply}** to program EDID.

Important

This function is designed for advanced users only. Do not program the EDID unless it is necessary.

6. **Analog and DVI inputs only** — Press **{Color Space}** to toggle between **SMPT**E and **RGB** processing, as required.
 7. **Analog inputs only** — Press **{1:1 Sampling}** to toggle the 1:1 sampling mode on or off, as required.
 8. **Analog inputs only** — Press **{Sample Phase}**, and use the **Sample Phase** control to adjust the input's A/D converter. For optimum visual results when adjusting high-resolution sources, output a burst test pattern from the source, and adjust for minimum noise.
 9. **Analog inputs only** — Press **{Adjust H Timing}** to adjust the image's horizontal timing. Use the **{H Pos}**, **{H Active}** and **{H Total}** controls as required.
 10. **Analog inputs only** — Press **{Adjust V Timing}** to adjust the image's vertical timing. Use the **{V Pos}** and **{V Active}** controls as required.
- **Processing Setup** — Use the following steps to set up universal input processing parameters:
 1. Press **{Sharpness}**, and use the **Sharpness** control to set the input's sharpness.
 2. **Component, S-video and composite inputs only** — Press **{Pull-down Comp}** to toggle the **Pull-down Compensation** mode on or off, as required.
 3. **Interlaced formats only** — Press **{De-Interlace}** to display the **De-Interlace Pop-up**. Choose either **Motion Adaptive** or **Field to Frame** mode.
 4. If **Motion Adaptive** de-interlacing is selected, press **{Motion Threshold}** and use the control to adjust the threshold of the motion adaptive de-interlacer, if required.
 - **Sizing and Scaling** — Use the following steps to set up sizing and scaling:
 1. Press **{Sizing and Scaling}** to display the **Sizing and Scaling Panel**.
 2. Use the **{Mask Top}**, **{Mask Bottom}**, **{Mask Left}** and **{Mask Right}** controls to mask selected portions of the image, as required.
 3. Select the method by which you want to size and scale the image. Masked edges are taken into account.
 - ~ Press **{Fill H}** to scale the selected universal input up (or down) to the current native **horizontal** resolution. Aspect ratio is maintained.
 - ~ Press **{Fill V}** to scale the input up (or down) to the current native **vertical** resolution. Aspect ratio is maintained.
 - ~ Press **{Fill H/V}** to scale the input up (or down) to the current native **horizontal** and **vertical** resolutions. Aspect ratio is not maintained.

5. System Setup

Universal Input Setup

4. If required, press **{Reset Fill}** to return the input to its previous scaling. Mask settings are retained.
 5. If required, press **{Clear Mask}** to return all mask settings to 0 (zero). Scaling is maintained.
 6. Press **{Reset All}** to return the input to its previous scaling, and return all mask settings to 0 (zero).
- **Color Correction** — Use the following steps to set up universal input color correction:
1. To adjust the selected input's overall brightness and contrast, press **{Bright Contrast}**. Use the **{Bright}** and **{Contrast}** controls as desired.
 2. To adjust the input's RGB brightness, press **{RGB Bright}**. Use the **{Red Bright}**, **{Green Bright}** and **{Blue Bright}** controls as desired.
 3. To adjust the input's RGB contrast, press **{RGB Contrast}**. Use the **{Red Contrast}**, **{Green Contrast}** and **{Blue Contrast}** controls as desired.
 4. To adjust hue and color saturation, press **{Hue Sat}**. Use the **{Hue}** and **{Sat}** controls as desired.
- **Save Input Settings** — Use the following steps to save input settings:
1. Press **{Save Settings}** to save the selected input's setup parameters.
 2. Press **{Back}** to return to the **Input Menu**.
 3. Repeat from step 3 for each additional input that you wish to set up.

Important

Because you can install a **UIC** in slots 3 and 4, If you move or change card assignments in these two slots during setup, the setup is invalidated, and must be repeated once the final card configuration is reached.

Aux Output Setup



8

FSN-1004 system setup: **Step 8**

This procedure enables you to name standard Aux outputs and set up a variety of parameters for universal Aux outputs (on any installed **SOC**).

▲ **Prerequisite** — Ensure that you are familiar with the **Output Setup Menu**. In Chapter 4, refer to the “[Output Setup Menu](#)” section on page 138.

■ **Map and Name** — Use the following steps to map and name Aux outputs:

1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
2. Press **{Output Setup}** to display the **Output Setup Menu**.
3. In the **Rear I/O View**, press the Aux connector that you want to name. In the **Aux Table**, the Aux output is highlighted.
4. **Name Output**— Press **{Out Name}** to associate a name (up to eight characters in length) with the selected Aux output. When the pop-up **Keyboard** appears, enter the desired name and press **{Enter}** on the **Keyboard**.
5. Repeat from step 3 for all Aux outputs that you wish to map and name.

■ **Format and Processing** — Use the following steps to set the universal Aux output format, and preliminary processing parameters:

1. On the **Aux Setup Menu**, press the **SOC** Aux connector that you want to set up.
2. Press **{Setup}** to display the **SOC Setup Menu** for the selected Aux output.
3. Press **{Output and Process}** to display the **Output and Process Panel**.
4. Press **{Output Format}** to display the **Output Format Keypad**. Locate the desired output format and press **{Apply}**.
5. Press **{Advanced Output Setup}** to display the **Advanced SOC Setup Menu**, which enables you to adjust advanced SOC output parameters. See below for details and instructions.
6. Press **{Sharpness}**, and use the **Sharpness** control to set the input's sharpness.
7. Press **{Flicker Filter}**, and use the **Flicker Filter** control to adjust the flicker.
8. Press **{DVI Sync}**, and select the desired polarity of the digital sync output on the DVI connector.
9. Press **{Analog Type}**, and select the desired type of analog sync output on the HD-15 connector.
10. If **{HV Sync}** is selected on the **{Analog Type}** button, press **{Analog Sync}** and select the desired polarity of the analog sync output on the HD-15 connector.
11. If you want to copy settings to another SOC channel, press **{Copy All Settings}**. In the **Copy Settings Keypad**, select the desired channel, and press **{Copy}** to complete the process.
12. If you want to set the channel's settings to their default value, press **{Restore Default Settings}**.
13. Press **{Back}** to return to the **Aux Setup Menu**. Repeat from step 1 to set up additional Aux outputs.

5. System Setup

Aux Output Setup

- **Advanced Setup** — Use the following steps to set advanced SOC output parameters:

1. On the **Output and Process Panel**, press **{Advanced Output Setup}** to display the **Advanced SOC Setup Menu**.

Caution

The **Advanced SOC Setup Menu** is designed for advanced users who are familiar with all aspects of output timing adjustments. Do not use this menu if you are uncertain about any output timing parameter.

2. On the **Advanced SOC Setup Menu**, press the **SOC** Aux connector that you want to set up.
3. Press **{Totals}**, and use the **{H Total}** and **{V Total}** controls to set the total number of horizontal pixels and vertical lines in the output.

Important

Changing the H and V Totals will cause a disruption to the SOC's output video. Press **{Apply}** to apply changes, or **{Undo}** to reverse un-applied changes.

4. Press **{Active and Pos}**, and use the **{H Pos}**, **{V Pos}**, **{H Active}** and **{V Active}** controls to set the output's H and V active area, and the H and V position.
5. Press **{Sync}**, and use the **{H Sync}** and **{V Sync}** controls to adjust the output's horizontal and vertical sync pulse width.
6. If the selected SOC output format is vertically locked to the native resolution's vertical sync, press **{Offset Timing}**. Use the **{H Offset}** and **{V Offset}** controls to adjust the SOC output's video timing relative to the system's native resolution.
7. Press **{Back}** to return to the **Output and Process Panel**, then press **{Back}** to return to the **Aux Setup Menu**.

- **Sizing and Scaling** — Use the following steps to set up SOC sizing and scaling:

1. On the **Aux Setup Menu**, press the **SOC** Aux connector that you want to set up.
2. Press **{Setup}** to display the **SOC Setup Menu** for the selected output.
3. Press **{Sizing and Scaling}** to display the **Output Sizing and Scaling Panel**.
4. Press **{Size and Position}**, then use the **{H Size}**, **{V Size}**, **{H Position}** and **{V Position}** controls to adjust the output's size and position.
5. If desired, in the **Quick Adjust** section, use the **{Fill H}**, **{Fill V}** and/or **{Fill H/V}** controls to scale the output.
6. If desired, press **{Aspect Ratio}**, then select the desired aspect ratio in the **Aspect Ratio Pop-up**.
7. To size and position the video *within* the boundaries of the output, press **{Pan Zoom Source}**. Use the **{Source H Size}**, **{Source V Size}**, **{Source H Pos}** and **{Source V Pos}** controls to size and position the video.
8. Press **{Mask}**, then use the **{Mask Top}**, **{Mask Bottom}**, **{Mask Left}** and **{Mask Right}** controls to mask selected portions of the output, as required.
9. If desired, in the **Output Mask Presets** section, select the desired preset — and remember that all mask presets in this section are additive.
10. Press **{Back}** to return to the **Aux Setup Menu**.

5. System Setup

Aux Output Setup

- **Color Correction** — Use the following steps to set up SOC color correction:
 1. On the **Aux Setup Menu**, press the **SOC** Aux connector that you want to set up.
 2. Press **{Setup}** to display the **SOC Setup Menu** for the selected output.
 3. Press **{Color Correct}** to display the **Output Color Correction Panel**.
 4. To adjust the output's brightness, contrast and gamma, press **{Bright Contrast Gamma}**. Use the **{Bright}**, **{Contrast}** and **{Gamma}** controls as desired.
 5. To adjust the output's RGB brightness, press **{RGB Bright}**. Use the **{Red Bright}**, **{Green Bright}** and **{Blue Bright}** controls as desired.
 6. To adjust the output's RGB contrast, press **{RGB Contrast}**. Use the **{Red Contrast}**, **{Green Contrast}** and **{Blue Contrast}** controls as desired.
 7. To adjust hue and color saturation, press **{Hue Sat}**. Use the **{Hue}** and **{Sat}** controls as desired.
 8. Press **{Back}** to return to the **Aux Setup Menu**.

5. System Setup

Multiviewer Setup

Multiviewer Setup

9

FSN-1004 system setup: **Step 9**

This procedure enables you to set up all aspects of the Multiviewer.

▲ Prerequisites —

- ~ Ensure that the Multiviewer is properly connected. In Chapter 3, refer to the “[Multiviewer Connections](#)” section on page 68.
- ~ Ensure that you are familiar with all Multiviewer menus and features. Refer to Chapter 7, “[Multiviewer Operations](#)” on page 197 for details.

■ **Output Setup** — Use the following steps to set up the Multiviewer’s output:

1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
2. Press **{Multiviewer Setup}** to display the **Multiviewer Setup Menu**.
3. Press **{Output Setup}** to display the **Multiviewer Output Setup Menu**.
4. Press **{Output Format}** to display the **Multiviewer Output Format Keypad**. Select the format supported by the monitor(s) connected to the Multiviewer’s rear panel. Press **{Apply}** to accept, then press **{Close}** to close the pop-up.
5. If you are using the Multiviewer card’s DVI output connector(s), press **{DVI Sync}** and select the desired sync mode.
6. Press **{Back}** to return to the **Multiviewer Setup Menu**.

■ **Layout** — Use the following steps to select the Multiviewer’s layout:

1. On the **Multiviewer Setup Menu**, press **{Select Layout}** to display the **Select Layout Menu**.
2. Press **{Single Output Layouts}** or **{Dual Output Layouts}** as required.
3. Select one of the pre-configured single or dual screen layouts from the menu.
4. Press **{Back}** to return to the **Multiviewer Setup Menu**.

■ **Color Setup** — Use the following steps to configure the Multiviewer’s color scheme:

1. On the **Multiviewer Setup Menu**, press **{Select Colors}**.
2. Press **{BG Color}** to change the Multiviewer’s background color. Use the **Color Picker** to select the desired color.
3. Press **{Clock BG Color}** to change the background color of the clock (if enabled on your selected layout). Use the **Color Picker** to select the color.
4. Press **{Border Color}** to change the border color for all PIPs. Use the **Color Picker** to select the color.
5. Press **{UMD Color 1}** to change the UMD 1 color selection. Use the **Color Picker** to select. Note that this unique color can be applied to one or more UMDs, using the **UMD Color Pop-up**. Repeat this step for all four UMD colors.
6. Press **{Back}** to return to the **Multiviewer Setup Menu**.

■ **Clock Setup** — Use the following steps to set up the clock:

1. If a clock is configured in your selected layout, press **{Clock Setup}**.
2. Press **{Clock Source}** and choose the clock’s source, either internal or LTC.
3. Press **{Clock Display}** and choose the display mode, either 12 or 24 hour.

5. System Setup

Multiviewer Setup

4. To set the clock time, use the **User Preferences Menu**. Refer to the "[User Preferences Setup](#)" section on page 180 for instructions.
 5. Press **{Back}** to return to the **Multiviewer Setup Menu**.
- **Source Selection** — Use the following steps to assign sources to PIPs in the layout:
1. On the **Multiviewer Setup Menu**, note the "index" numbers inside the PIPs in the selected monitor graphic.
 2. Using the index numbers for reference, click on the associated PIP line in the **PIP Table**.
 3. Press **{Assign Source}** to display the **Assign Source Pop-up**.
 4. Next, in the pop-up:
 - a. To assign a video source to the PIP, press **{Sources}**, and select a source from the list. Press **{Apply}** to accept.
 - b. To assign an aux output to the PIP, press **{Aux}**, and select an aux output from the list. Press **{Apply}** to accept.
 - c. To assign a program, preview or clean feed output to the PIP, press **{Other}**, and select the desired output from the list. Press **{Apply}**.
 5. Repeat from step 2 to assign sources to all other PIPs in the layout.
 6. Press **{Close}** to close the pop-up, when complete.
- **UMD Text Modification** — Use the following steps to modify UMD text:
1. On the **Multiviewer Setup Menu**, note the "index" numbers inside the PIPs.
 2. Using the index numbers for reference, click on the associated PIP line in the **PIP Table**.
 3. Press **{UMD Text}**. When the pop-up **Keyboard** appears, enter the desired UMD text (eight characters maximum), and press **{Enter}** on the **Keyboard**.
 4. Repeat from step 2 to modify UMD text for all other PIPs in the layout, as needed.
 5. Press **{Close}** to close the pop-up, when complete.
- **UMD Color Modification** — Use the following steps to assign unique UMD colors to specific PIPs:
1. Ensure that you have pre-configured a set of four unique colors on the **Select Colors Menu**. Refer to the previous "**Color Setup**" section for details.
 2. On the **Multiviewer Setup Menu**, note the "index" numbers inside the PIPs.
 3. Using the index numbers for reference, click on the associated PIP line in the **PIP Table**.
 4. Press **{UMD Color}** to display the pop-up, then select the color that you wish to assign to the UMD text box.
 5. Repeat from step 2 to modify UMD color for all other PIPs in the layout.

Please note the following important points regarding UMD color:

- The assigned UMD color will be over-ridden by the color **RED** when the selected source appears on the main Program output.
- The assigned UMD color will be over-ridden by the color **GREEN** when the selected source appears on any Preset output (Main, M/E 1 or M/E 2).
- The assigned UMD color will be over-ridden by the color **AMBER** when the selected source appears on the M/E 1 or M/E 2 Program output.

5. System Setup

User Preferences Setup

10

FSN-1004 system setup: **Step 10**

This procedure enables you to set a variety of important user preferences and options.

- ▲ **Prerequisite** — Ensure that you are familiar with the **User Preferences Menu**. In Chapter 4, refer to the [“User Preferences Menu”](#) section on page 151.
- Use the following steps to set user preferences:
 1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
 2. Press **{User Prefs}** to display the **User Preferences Menu**.
 3. Click on the line in which the preference you wish to change appears.
 - ~ Set **Black on Invalid Video** on or off.
 - ~ Set **Memory Auto Lock** on or off.
 4. Press **{Set}** to toggle the selected preference on or off:
 5. Press **{Set Clock}** to display the **Set Clock Keypad**:
 - ~ Ensure that you use the **HH:MM:SS** format to set the time.
 - ~ Use the **{:}** button as a separator between digits.
 - ~ Press **{AM/PM}** to switch between AM and PM as required.
 - ~ Press **{12 HR / 24 HR}** to switch modes as required.
 6. If required, press **{Reset to Default}** to return a highlighted preference to its default value.

Saving the Setup

11

FSN-1004 system setup: **Step 11**

This procedure enables you to save all system setup parameters to non-volatile memory.

- ▲ **Prerequisite** — Ensure that you are familiar with the **Save All** function. In Chapter 4, refer to the [“Save All”](#) section on page 158.
- Use the following steps to save all system setup parameters:
 1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
 2. Press **{Save All}** to display the confirmation pop-up.
 3. Press **{Close}** to clear the pop-up.

Backing up the System

12

FSN-1004 system setup: **Step 12**

In this procedure, you will back up your system configuration to your PC.

- ▲ **Prerequisite** — Ensure that you are familiar with the **Backup and Restore Menu**. In Chapter 4, refer to the [“Backup and Restore Menu”](#) section on page 160.
- Use the following steps to back up your system to a PC:
 1. In the **Menu Bar**, press **{System}** to access the **System Menu**.
 2. Press **{Backup and Restore}** to display the **Backup and Restore Menu**.
 3. Press **{Backup System}** and select or create the folder in which to store the backup data.
 4. Upon completion of the backup, you will be notified that the backup is complete. Press **{Close}** to close the notification window.

5. System Setup

Backing up the System

6. Operations

In This Chapter

This chapter provides comprehensive operating instructions for the FSN-1004. The following topics are discussed:

- [Quick Setup and Operations](#)
- [Quick Function Reference](#)
- [Understanding Error Messages](#)
- [Working with Pop-ups](#)
- [Using the Keypad](#)
- [Working with Memory Registers](#)
- [Backing Up and Restoring the System](#)

6. Operations

Quick Setup and Operations

Quick Setup and Operations

For the optimum speed in setting up and operating your FSN-1004 switcher, use the following steps. For reference, links are provided to the appropriate sections in this guide.

Note

Many of these steps were already covered in Chapter 3 and Chapter 5. As required, use the following list as an easy check-list for all quick setup requirements.

- 1. Connect power** — Ensure that power is properly connected to all FSN-1004 components.
 - ~ Chapter 3, [“PC Connection,”](#) page 52
 - ~ Chapter 3, [“System Connections,”](#) page 55
- 2. Connect inputs** — Connect all input sources to the FSN-1004. (Chapter 3, [“Signal Connections,”](#) page 64.)
- 3. Connect outputs** — Connect the output(s) of the FSN-1004 to your target devices. (Chapter 3, [“Signal Connections,”](#) page 64.)
- 4. Turn on power** — Turn on power to all FSN-1004 components, and to all peripheral equipment. (Chapter 5, [“Power Up and Status Check,”](#) page 166.)
- 5. Factory reset** — If you are using the FSN-1004 for the first time, or if you are using a system that has just returned from another event, perform a full factory reset. (Chapter 5, [“Return to Factory Default,”](#) page 167.)
- 6. Set output format** — Set the desired output resolution and frame rate. (Chapter 5, [“Output Format Setup,”](#) page 170.)
- 7. Enable test patterns** — If required, use test patterns to verify outputs and make the necessary adjustments. When complete, turn off the test patterns. (Chapter 5, [“Output Test Patterns,”](#) page 171.)
- 8. Set up universal inputs** — As required, set up all universal inputs, and perform the necessary adjustments. (Chapter 5, [“Universal Input Setup,”](#) page 172.)
- 9. Set up user preferences** — Complete all user preference choices, as required. (Chapter 5, [“User Preferences Setup,”](#) page 180.)
- 10. Save system configuration** — After completing all “system” setups, save the configuration and back up the system.
 - ~ Chapter 5, [“Saving the Setup,”](#) page 181.
 - ~ Chapter 5, [“Backing up the System,”](#) page 181.
- 11. Set up Multiviewer** — As required, set up the Multiviewer and assign sources to Multiviewer PIPs. ([“Multiviewer Operations,”](#) page 197.)
- 12. Set up memory registers** — Set up the desired “looks” for your show, and store them in memory registers as required. ([“Working with Memory Registers,”](#) page 189.)

6. Operations

Quick Setup and Operations

- 13. Ready to roll** — With all output, input and system configurations saved, and all of your important “looks” stored in memory, put on your headsets and get busy!

Note

For detailed system operating procedures, specific system “tweaks” and operating descriptions on every feature, please start with the [“Quick Function Reference”](#) section on page 186, and select the function that you wish to perform.

6. Operations

Quick Function Reference

Quick Function Reference

Use the following table to quickly access the proper section for specific operating instructions. Both hyperlinks and page numbers are provided.

Table 6-1. FSN-1004 Quick Function Reference Table

To learn about:	Use the Following Section:	Page
Error messages	Understanding Error Messages	186
Keypad operations	Using the Keypad	188
Memory registers	Working with Memory Registers	189
Multiviewer operations	Multiviewer Operations	197
Pop-ups	Working with Pop-ups	188
Quick setup and operation	Quick Setup and Operations	184

Understanding Error Messages

Please note the following important rules regarding error messages.

Note

For the input connectors on the **UIC**, the “red” error conditions only occur if the input has been mapped to the panel, and the signal was previously OK.

LOS:

Slot 1
Input 3

- **LOS** (loss of signal): On occasion, you can experience **LOS** (loss of signal) — typically due to a poor video connection or computer connection.

If this condition occurs:

- ~ A red **Error** button appears in the upper left corner of the **Touch Screen**.
- ~ The input’s **BNC** turns red in the rear I/O view.
- ~ The input’s **Programmable Display** turns red.

During an LOS condition, if the user preference “**Black on Invalid Video**” is turned on, black will replace the lost output video. In Chapter 4, refer to the “[User Preferences Menu](#)” section on page 151 for details.

Invalid:

Slot 1
Input 2

- **Invalid Video**: On occasion, this message can appear if the input format does not match the selected native resolution, or if the input signal is not locked to the system’s video reference input.

If this condition occurs:

- ~ A red **Error** button appears in the upper left corner of the **Touch Screen**.
- ~ The input’s **BNC** turns red in the rear I/O view.

6. Operations

Understanding Error Messages

~ The input's **Programmable Display** turns red.

Note

For both **LOS** and **Invalid Video** conditions, you can also navigate to the **Input Menu**, and check the color of the connector in question to verify the physical input's condition.

If one of these types of error occurs, you have several options:

- Leave the **Error** button and red **Programmable Display** as is.
- Press the **Error** button to display a pop-up with options for more information. The pop-up also has a **{View Error Info}** button, which when pressed, takes you to the **View Errors Menu**.
- Navigate to the **Input Menu**, and note the red BNC that is experiencing the error. Press the **{Error Reporting}** button to toggle error reporting **Off** for the selected input. When **Off**, the red error message turns off, the **Programmable Display** returns to green, and the error is removed from the list in the **View Errors Menu**. In this mode, however, the connector remains red.



Note

The **{Error Reporting}** function works on a connector by connector basis. You can have reporting on for one connector, and off for another.

6. Operations

Working with Pop-ups

Working with Pop-ups

Please note the following important rules regarding pop-ups:

- When a pop-up includes a button, or a series of buttons (e.g., **{Yes}** or **{No}**) you must acknowledge the pop-up with a decision before any other operations can be performed on the **Touch Screen**.
- When a pop-up does not include a button, you must wait until the pop-up clears before any other operations can be performed on the **Touch Screen**. This condition only occurs on several menus, including:
 - ~ **System Menu** (during system initialization procedures)
 - ~ **Software Menu** (during the software update procedure)
 - ~ **Backup and Restore Menu** (during backup and restore procedures)
 - ~ **Reset Menu** (during various reset procedures)
- When any pop-up is displayed, buttons on the GUI still function properly.

Using the Keypad

There are two types of **Keypads** in the system:

- **Touch Screen Keypad** — When any **Value Button** is pressed on the **Touch Screen**, the **Keypad** appears, enabling you to make numeric entries. In this mode, you can enter, trim, clear and undo entries with accuracy. In Chapter 4, refer to the [“Using the Keypad”](#) section on page 82 for details.

Working with Memory Registers

This section provides instructions for working with memory registers. Three modes are available: Store, Recall and View.

- ▲ **Prerequisite** — Ensure that you are familiar with the **Memory Menu**. In Chapter 4, refer to the “**Memory Menu**” section on page 86.

The following topics are discussed in this section:

- [Memory Register Overview](#)
- [Storing Memory Registers](#)
- [Recalling Memory Registers](#)
- [Viewing Memory Registers](#)
- [Locking and Unlocking Memory Registers](#)
- [Deleting Memory Registers](#)
- [Assigning a Keyboard Shortcut to a Memory Register](#)

Memory Register Overview

To understand how the memory system works on FSN-1004 switchers, you can think of each memory register as having a number of individual storage compartments — one for each of the available modules. These modules can be stored or recalled individually, or in combination with other modules.

In addition, each module is comprised of multiple sub-sections called “Enables” which can be toggled on or off as desired. This feature allows you to store one or more individual parts of a module, rather than the entire module.

When you use the memory system, you can elect to use (or bypass) the “Enables” feature.

- **Store.** All Enables will be off by default. If you store a register and you elect to set Enables using the **Memory Menu**, you can store all or part of any selected module.
- **Recall.** All Enables will be on — exactly as originally stored in the register. If you recall a register and you elect to adjust Enables using the **Memory Menu**, you can recall all or part of any selected module — but only those components that were originally stored in the register

Any combination of modules can be stored in a memory register. Please note the following important points regarding modules:



- **Aux Memory Functions**

When you include the **Out** button in a store function, you are taking a precise snapshot of all Source-to-Aux assignments in the **Aux Section**. If you bypass the **Memory Menu**, all Aux routes on the panel will be stored. If you use the Aux “Enables,” you can elect to store any combination of Aux routes.

When you include the **Aux** button in a recall function, the system *immediately* replaces all (or a portion of) the current Aux assignments on the panel, based on your “enables.” You can also modify the Enables, prior to pressing **ENTER**.



- **System Memory Functions**

When you include the **SYS** button in a store function, you are taking a precise snapshot of all system-related functions (such as input setups, output settings,

6. Operations

Working with Memory Registers

Multiviewer layouts, etc.). Using the System “Enables,” you can elect to include or exclude certain system sub-functions.

When you include the **SYS** button in a recall function, the system *immediately* replaces all (or a portion of) the current System settings, based on your “enables.” You can also modify the Enables, prior to pressing **ENTER**.

The table below summarizes the functions you can perform in each mode:

Table 6-2. Memory Menu modes and functions

Memory Menu Mode	Name Registers	Modules	Enables	Lock Registers	Delete Registers
View	Yes	View Only	View Only	Yes	Yes
Store	Yes	Modify	Modify	No	No
Recall	No	Modify	Modify	No	No

Storing Memory Registers

When you store a memory register, you take a “snapshot” of the switcher and the selected modules. Once stored, you can *not* add data to that register — you can only overwrite it with new data.

- ▲ If you store **All Output Destinations** into register 100, you can not add System data into that register. However, you could overwrite register 100 with new data.

Storing a memory register and setting Enables is an easy equation. This method stores partial contents of the selected module(s).

- **STORE, [select register #], [set Enables], ENTER**

The following topics are discussed in this section:

- [Store, Set Enables, Enter Custom Name](#)
- [Memory Store Notes](#)

Note

In **Store Mode**, the description will not appear in the register table until **ENTER** is pressed on the **Keypad**.

Store, Set Enables, Enter Custom Name

- Use the following steps to store a memory register, set Enables, and enter a custom register description:
 1. Set up the switcher in the exact configuration that you want stored.
 2. In the **GUI**, go to the **Memory** page, highlight a register number line in the table, and select **STORE**.
 3. Open the **Enables Menu** by selecting the brown **Enables Button** at the bottom of the screen. By default all Enables are "Off" for the System and Output modules.
 4. Choose the light blue **SYS** or **OUT** modules and turn ON the desired items to be saved in this register. Remember that you can also use the **{All On}** and **{All Off}** functions.

6. Operations

Working with Memory Registers

5. Select **Description** to display the **Keyboard** and enter in the desired description and press **Enter** on the Keyboard.

Note

In **Store Mode**, the description will not appear in the register table until **ENTER** is pressed on the **Keypad**.

6. Press **ENTER** on the **Keypad**. The register is stored, the Enables are set, and the custom description is also stored.

Memory Store Notes

Please note the following important points regarding memory register storage:

- If you are in the midst of a **Store** procedure, the **{Advanced}** button is grayed out. This feature prevents you from locking, unlocking, or deleting registers in the midst of the procedure.
- At any point, prior to pressing **ENTER**, you can add or remove modules within a pending **Store** operation

To add modules (prior to pressing **ENTER**):

- ~ In the **Enables Menu**, press the light blue button for module you wish to add (even if it was not originally selected). All Enables will be off initially, but as soon as you toggle any Enable on, the associated module button in the **Keypad** lights. You can also press **{All On}**.

To remove modules (prior to pressing **ENTER**):

- ~ In the **Enables Menu**, press the light blue button for module you wish to remove, and press **{All Off}**. The associated module button in the **Keypad** turns off.
- Remember that once **ENTER** is pressed, the module's contents are set — and you can no longer add to the register. On recall, however, you can elect to recall all of the register's contents, or part of the contents by using your Enables.

6. Operations

Working with Memory Registers

Recalling Memory Registers

When you recall a memory register, you are recalling all (or part) of the stored register's contents back to the switcher.

Recalling a memory register and bypassing the Enables is an easy equation. This method recalls the entire contents of the selected module(s).

- **RECALL, [select register #], ENTER**

Recalling a memory register and adjusting Enables is also an easy equation. This method recalls partial contents of the selected module(s).

- **RECALL, [select modules], [adjust Enables], ENTER**

The following topics are discussed in this section:

- [Recall, Bypass Enables](#)
- [Recall, Adjust Enables](#)
- [Memory Recall Notes](#)

Recall, Bypass Enables

■ Use the following steps to recall a memory register and bypass Enables:

1. In the **GUI**, go to the **Memory page** and select **RECALL**
2. Select the desired register number.
3. Press **ENTER**. The entire memory register is now recalled to the panel.

Recall, Adjust Enables

■ Use the following steps to recall a memory register and adjust the Enables:

1. In the **GUI**, go to the **Memory page** and select **RECALL**
2. Select the desired register number.
3. Navigate to the **{Enables} Menu**. The selected register will be highlighted in the table, and the "**RECALL**" banner will be lit red.
4. On the modules row, press the light blue button for the first module in which you want to adjust Enables.
 - ~ Note that only the "stored" modules will be blue. All other modules will be grayed out.
 - ~ In the "Enables" box, note that the enables will appear exactly as stored. All those that were not enabled will be grayed out.
5. Toggle the desired Enables on or off, as required. Remember that you can also use the **{All On}** and **{All Off}** functions.
6. Repeat steps **5** and **6** for all remaining modules in which you want to adjust Enables.
7. Press **ENTER** on the **Keypad**. The register is now recalled, using the adjusted Enables.

Memory Recall Notes

Please note the following important points regarding memory register storage:

- Once a **Memory** is recalled, it can be triggered by pressing the **SPACE bar** while in the **SCREENS Menu**.
- If you are in the midst of a **Recall** procedure, the **{Advanced}** button is grayed out. This feature prevents you from locking, unlocking, or deleting registers in the midst of the procedure.
- At any point, prior to pressing **ENTER**, you can add or remove modules within a pending **Recall** operation — but only if the modules were originally included in the register.

To add modules back into the **Recall** (prior to pressing **ENTER**):

- ~ In the **Enables Menu**, if you have toggled any Enables off, simply re-enable them, press **{All On}**, or light the module button itself — but only if the module(s) had originally been stored in the register.

To remove modules from the **Recall** (prior to pressing **ENTER**):

- ~ In the **Enables Menu**, press the light blue button for module you wish to remove, and press **{All Off}**.

6. Operations

Working with Memory Registers

Viewing Memory Registers

In the **View Mode**, you can look at all memory registers, enter register descriptions, and view the status of all modules and Enables. You cannot modify the modules or the Enables within a register, but you *can* lock, unlock and delete registers.

- Use the following steps to view a memory register:
 1. Navigate the **Memory Menu** using one of the following methods:
 - ~ In the **Menu Bar**, press the **{Memory}** button.
 2. Select the desired register that you want to view.
 - ~ Press the **{Memory Register}** button, then on the keypad, enter the desired register and press **{Enter}**.
 3. In the main **Memory Table**, note the register's lock/unlock mode, description, and the exact modules stored in the register.
 4. If desired, press **{Description}** to change the register's description.
 5. If desired, press **{Advanced}** to display the **Advanced Memory Menu**, where you can lock, unlock, and delete registers. Refer to the "[Locking and Unlocking Memory Registers](#)" and "[Deleting Memory Registers](#)" sections below for details.
 6. If desired, press **{Enables}** to switch to the **Enables Menu**. There, you can view the module's Enables, enter or change the description, and switch to the **Advanced Memory Menu**. If desired, you can also view other registers within the **Enables Menu**, using the same methods outlined in step 2 above.

Locking and Unlocking Memory Registers

The **View Mode** is the only mode in which you can lock and unlock registers.

- Use the following steps to lock and unlock memory registers:
 1. Ensure that you are *not* in the **Store** or **Recall** modes. If so, cancel the mode.
 2. Navigate the **Memory Menu** using the following method:
 - ~ In the **Menu Bar**, press the **{Memory}** button.
 3. Select the register that you want to lock or unlock.
 - ~ Press the **{Memory Register}** button, then on the keypad, enter the desired register and press **{Enter}**.
 4. Press **{Advanced}** to display the **Advanced Memory Menu**.
 5. Press the **{Lock Unlock}** button to toggle the register's mode.
 - ~ If currently unlocked, press **{Lock Unlock}** to lock the register. An "X" appears in the table cell under the **Lock** heading. The register can not be deleted or over-written.
 - ~ If currently locked, press **{Lock Unlock}** to unlock the register and remove the "X" from the table cell. The register can now be deleted and over-written.
 6. Repeat from step 3 to lock or unlock additional registers.

Deleting Memory Registers

The **View Mode** is the only mode in which you can delete registers.

- Use the following steps to delete memory registers:
 1. Ensure that you are not in the **Store** or **Recall** modes. If so, cancel the mode.
 2. Navigate the **Memory Menu** using the following method:
 - ~ In the **Menu Bar**, press the **{Memory}** button.
 3. Select the register that you want to delete:
 - ~ Press the **{Memory Register}** button, then on the keypad, enter the desired register and press **{Enter}**.
 4. Press **{Advanced}** to display the **Advanced Memory Menu**.
 5. Ensure that the register is unlocked. If not, unlock it using **{Lock Unlock}**.
 6. Press the **{Delete Register}** button to delete the register. When the “confirm” pop-up appears, press **{Yes}**.
 7. Repeat from step 3 to lock or unlock additional registers.

Assigning a Keyboard Shortcut to a Memory Register

Assigning a keyboard shortcut allows for a memory register to be quickly recalled with one of the keyboard's **F# keys**. The **View Mode** is the only mode in which you can assign a keyboard shortcut.

Use the following steps to assign a keyboard shortcut.

1. Ensure that you are not in the **Store** or **Recall** modes. If so, cancel the mode.
2. Navigate the **Memory Menu** using the following method:
 - ~ In the **Menu Bar**, press the **{Memory}** button.
3. Select the register that you want to assign to a keyboard **F# key**.
 - ~ Press the **{Memory Register}** button, then on the keypad enter the desired register and press **{Enter}**.
4. Press **{Advanced}** to display the **Advanced Memory Menu**.
5. Press the **{Keybrd Short-cut}** button to open the pop-up menu list of shortcut keys.
6. Select one of the keys from the list and select **{Apply}**.
7. The selected **F#** will show in the **Key column**.

6. Operations

Backing Up and Restoring the System

Backing Up and Restoring the System

The following topics are discussed in this section:

- [Backing Up the System](#)
- [Restoring the System](#)

Backing Up the System

The system backup procedure enables you to store the entire system setup to a PC, including all memory registers.

- Use the following steps to back up the system:
 1. Navigate to the **System Menu**:
 2. Press **{Backup and Restore}** to display the **Backup and Restore Menu**.
 3. Press **{Backup System}** to display the directory window on your PC.
 4. In the directory, navigate to the folder in which you want to store a backup file, and select the folder. The backup data (multiple files) will be stored in that folder.

Restoring the System

The system restore procedure enables you to restore the entire system setup from your PC, including all memory registers.

- Use the following steps to restore the system:
 1. Press **{Backup and Restore}** to display the **Backup and Restore Menu**.
 2. Press **{Restore System}** to display the directory window on your PC.
 3. In the directory, navigate to the folder from which you want to restore the system, and select the folder.

7. Multiviewer Operations

In This Chapter

This chapter provides orientation and operating instructions for the FSN-1004's internal Multiviewer (MVR). The following topics are discussed:

- [Introduction to the Multiviewer](#)
- [Multiviewer Menu Orientation](#)
- [Multiviewer Setup](#)
- [Multiviewer Memory](#)

7. Multiviewer Operations

Introduction to the Multiviewer

Introduction to the Multiviewer

The FSN-1004's internal Multiviewer (**MVR**) enables users to display up to 16 PIPs in either single or dual monitor configurations. With the Multiviewer, you can assign a variety of sources to individual PIPs, including video inputs, program and M/E outputs, preview outputs, clean feed outputs and Auxiliary outputs.

Following is a complete list of Multiviewer features.

- **MVR Card** — All functionality is provided via the plug-in **Multiviewer Card** and its associated rear connector panel. In order to provide connections to both SDI and DVI compatible monitors, two connectors (1 x **BNC**, 1 x **DVI-I**) are provided for each output. Please note:
 - ~ The same output signal appears on both the **DVI-I** and **BNC** connectors. **MVR Output 1** can be used in both single and dual multiviewer monitor configurations, as selected on the **Multiviewer Setup Menu**:
 - ~ The output resolution for both **MVR** outputs is set on the **Multiviewer Output Setup Menu**, using the **Output Format Keypad**.
 - ~ Both the **BNC** and **DVI-I** connectors can be active at the same time, provided that the selected format is compatible. The valid combinations are fully listed in the **Output Format Keypad**.

In Chapter 2, refer to the "[Multiviewer Card](#)" section on page 45 for additional information on the **Multiviewer Card** and its connector panel.

- **Single or dual monitor configurations** — a graphical library of pre-configured Multiviewer layouts is provided for both types of configurations.
 - ~ In a single monitor layouts, up to 16 PIPs can be displayed on one monitor, and the selected layout appears identically on **MVR Output 1** and **MVR Output 2**.
 - ~ In a dual monitor layouts, the 16 PIPs are divided between two monitor outputs — one half of the layout appears on **Output 1**, and the other half appears on **Output 2**.
- **PIP enable/disable** — any PIP in any Multiviewer layout can be turned on or off from the **Multiviewer Setup Menu**. This provides a degree of layout customization, per your requirements.
- **Color selection** — the following Multiviewer colors can be adjusted from the **Multiviewer Setup Menu**:
 - ~ Multiviewer background color
 - ~ Clock background color
 - ~ PIP border color
 - ~ **UMD** (Under Monitor Display) color can be changed to one of four user-selectable colors.
- **UMD Tally indications** — the following tally indications are pre-programmed:
 - ~ The assigned UMD color will be over-ridden by the color **RED** when the selected source appears on the main Program output.
 - ~ The assigned color will be over-ridden by **GREEN** when the selected source appears on any Preset output (Main, M/E 1 or M/E 2).
 - ~ The assigned UMD color will be over-ridden by **AMBER** when the selected source appears on the M/E 1 or M/E 2 Program output.

7. Multiviewer Operations

Introduction to the Multiviewer

- **UMD text** — the text that appears in the UMD can be changed or modified as desired, up to an eight character limit.
- **Clock** — when a Multiviewer layout includes a clock, the following clock features are available:
 - ~ The clock source can be set to internal or LTC.
 - ~ The display mode can be set to 12 or 24 hour mode.
 - ~ The time can be set on the **User Preferences Menu**.
- **Error indications** — the following error indications are provided:
 - ~ PIP border color will turn **RED** upon loss of signal (LOS). When the error is resolved, the border returns to the current color as set on the **Multiviewer Setup Menu**.
- **Freeze indications** — the following freeze indications are provided:
 - ~ PIP border color will turn **CYAN** when the selected source is frozen. When the source is un-frozen, the border returns to the current color as set on the **Multiviewer Setup Menu**.

7. Multiviewer Operations

Multiviewer Menu Orientation

Multiviewer Menu Orientation

This section provides a detailed explanation of all Multiviewer menus and features. The following topics are discussed:

- [Multiviewer Setup Menu](#)
- [Multiviewer Output Setup Menu](#)
- [Select Layout Menu](#)
- [Select Colors Menu](#)
- [Clock Setup Menu](#)
- [Assign Source Keypad](#)

Tip

It is recommended that you thoroughly learn all features and functions on all Multiviewer menus, prior to continuing with the setup and operations sections in this chapter.

Multiviewer Setup Menu

From the **System Menu**, press **{Multiviewer Setup}** to show the **Multiviewer Setup Menu**, a sample of which is shown below.




Figure 7-1. Multiviewer Setup Menu (sample)

The **Multiviewer Setup Menu** enables you to configure the Multiviewer's layout, overall appearance, and the sources within each PIP. On the menu:

- The left side of the **Palette** shows a graphic that represents the currently selected single or dual-monitor layout. The current output format is listed above the graphic. The right side shows the **Multiviewer Table**.
- In the layout graphic, each PIP is assigned a number (between **1** and **16**) that corresponds to its associated row in the **Multiviewer Table**. To select a PIP to set up or change, simply click on the row. This paradigm is identical for both single and dual-monitor layouts.

The **Multiviewer Table** provides the following information:

- **PIP #** — Indicates the corresponding PIP number in the layout graphic. If a row is highlighted, the selected PIP can be changed or modified.
- **Mode** — Indicates if the corresponding PIP is on or off (hidden). Use the **{Mode}** button to change the PIP's mode.
- **Source** — Indicates the video source assigned to the PIP. Use the **{Assign Source}** button to change the PIP's video source.

7. Multiviewer Operations

Multiviewer Menu Orientation

- **UMD Text** — Indicates the current text string shown in the corresponding UMD. Use the **{UMD Text}** button to change the text (maximum eight characters).
- **Color** — Indicates the specific color assigned to the selected PIP's UMD. Four color selections are available, as configured on the **Select Colors Menu**. Use the **{UMD Color}** button to change the assigned color.
- **Clock** — If a clock is available in the layout, a special **"Clock"** row appears at the bottom of the table. Highlighting this row enables you to turn the clock on and off.


The following functions are provided in the **Tool Bar**:



To set up the Multiviewer's output, press **{Output Setup}** to display the **Multiviewer Output Setup Menu**. This menu sets the resolution for both **MVR** outputs. Refer to the ["Multiviewer Output Setup Menu"](#) section on page 203 for details.



To select a single or dual Multiviewer layout from the library of pre-configured layouts, press **{Select Layout}** to display the **Select Layout Menu**. Refer to the ["Select Layout Menu"](#) section on page 204 for details.




To set colors for the Multiviewer's background, PIP borders, clock and four UMD color selections, press **{Select Colors}** to display the **Select Colors Menu**. Refer to the ["Select Colors Menu"](#) section on page 208 for details.



To set up the Multiviewer's clock, press **{Clock Setup}** to display the **Clock Setup Menu**. Refer to the ["Clock Setup Menu"](#) section on page 209 for details. Note that the time is set on the **User Preferences Menu**.




To turn a PIP on or off in the selected layout, highlight the row that corresponds to the desired PIP, then press **{Mode}**. In the pop-up, select **On** or **Off**. When a PIP is off, its source, color, and UMD text assignments remain unchanged.



To assign a source to a PIP, highlight the row that corresponds to the desired PIP, then press **{Assign Source}** to display the **Assign Source Keypad**. Refer to the ["Assign Source Keypad"](#) section on page 212 for details.



To change UMD text, highlight the row that corresponds to the desired PIP, then press **{UMD Text}** to display the **Pop-up Keyboard**. Enter the desired text, up to eight characters in length. In Chapter 4, refer to the ["Using the Pop-up Keyboard"](#) section on page 85 for details on keyboard operations.



To change UMD color, highlight the row that corresponds to the desired PIP, then press **{UMD Color}**. In the pop-up menu, select one of the four available UMD colors. Note that the color of each button reflects the colors selected on the **Select Colors Menu**. Refer to the ["Select Colors Menu"](#) section on page 208 for details.

Note

UMD colors can be used to "group" sources. For example, if you want to visually distinguish your cameras from other Multiviewer sources, create and assign a custom UMD color.

Multiviewer Output Setup Menu

From the **Multiviewer Setup Menu**, press **{Output Setup}** to show the **Multiviewer Output Setup Menu**. This menu sets the resolution for both **MVR** outputs.




Figure 7-2. Multiviewer Output Setup Menu, with Output Format Pop-Up Selected (sample)

The following functions are provided in the menu's **Tool Bar**:


To change the Multiviewer output format, press **{Output Format}** to display the **Output Format Keypad**. The keypad is divided into two columns:

- The left-hand column displays the list of available output formats.
- The right-hand column indicates the output connectors (on the **MVR Card**) that are active for the selected output resolution, e.g., **DVI only** or **SDI, DVI**.

Important

The list of available output formats changes, based on the system's native resolution.

- Press **{DVI Sync}** to select the polarity of the digital sync output on the MVR's DVI output connector. The following four options are available in the pop-up: **+H+V**, **+H-V**, **-H+V**, and **-H-V**.



7. Multiviewer Operations

Multiviewer Menu Orientation

Select Layout Menu

From the **Multiviewer Setup Menu**, press **{Select Layout}** to show the **Select Layout Menu** which enables you to select a pre-configured single or dual monitor layout.

The **Select Layout Menu** provides graphic representations of each available layout. To select a layout, simply touch its graphic. The yellow border indicates the current selection.

Use the left (◀) and right (▶) arrows to display more layouts, if available. Once a layout is selected, its configuration is immediately applied to the Multiviewer output.

Press **{Single Output Layouts}** to display all available single output layouts, as shown in the figure below.

Single
Output
Layouts




Figure 7-3. Multiviewer Select Single Layout Menu (sample)

7. Multiviewer Operations

Multiviewer Menu Orientation

Dual
Output
Layouts

Press **{Dual Output Layouts}** to display all available dual output layouts, as shown in the figure below.




Figure 7-4. Multiviewer Select Dual Layout Menu (sample)

The two tables on the following page list all available layouts.

7. Multiviewer Operations

Multiviewer Menu Orientation

The table below lists the available **Single Monitor Output** configurations;

Table 7-1. Multiviewer Single Monitor Output Configurations

Layout #	Total # PIPs	# PIPs				Clock
		Row 1	Row 2	Row 3	Row 4	
1	16	2	7	7	—	—
2	16	3	6	7	—	Yes
3	16	4	6	6	—	Yes
4	14	3	4	7	—	Yes
5	4	2	2	—	—	—
6	6	3	3	—	—	—
7	9	3	3	3	—	—
8	12	4	4	4	—	Yes
9	16	4	4	4	4	—

The table below lists the available **Dual Monitor Output** configurations;

Table 7-2. Multiviewer Dual Monitor Output Configurations

Layout #	Total # PIPs	# PIPs - Monitor 1				# PIPs - Monitor 2			
		Row 1	Row 2	Row 3	Clock	Row 1	Row 2	Row 3	Clock
1	16	2	—	—	Yes	2	6	6	—
2	16	2	—	—	Yes	4	5	5	—
3	16	1	7	—	—	1	7	—	Yes
4	16	2	6	—	Yes	2	6	—	—
5	16	3	3	—	—	5	5	—	Yes
6	14	2	—	—	Yes	4	4	4	—
7	16	2	—	—	Yes	3	5	6	—
8	13	2	7	—	Yes	2	2	—	—
9	15	2	7	—	Yes	3	3	—	—
10	12	3	3	—	Yes	3	3	—	—
11	16	3	3	—	—	4	6	—	Yes
12	15	2	2	—	—	4	7	—	Yes
13	16	4	4	—	Yes	4	4	—	—

7. Multiviewer Operations

Multiviewer Menu Orientation

Select Colors Menu

From the **Multiviewer Setup Menu**, press **{Select Colors}** to show the **Select Colors Menu**, which enables you to set colors for a full range of Multiviewer parameters.





Figure 7-5. Multiviewer Select Colors Menu (sample)


The following functions are provided:



Press **{BG Color}** to select the Multiviewer's background color. Use the **Color Wheel**, the **Color Chips**, or the **User Colors** to select the desired color. The current color box (above the button) updates as different colors are selected or fine-tuned.



Press **{Clock BG Color}** to select the clock's background color. Use the **Color Wheel**, the **Color Chips**, or the **User Colors** to select the desired color.



Press **{Border Color}** to select the default border color for all PIPs. Use the **Color Wheel**, the **Color Chips**, or the **User Colors** to select the desired color.

7. Multiviewer Operations

Multiviewer Menu Orientation



Press **{UMD Color 1}** to select a specific color that can be assigned to any UMD. Use the **Color Wheel**, the **Color Chips**, or the **User Colors** to select the desired color. Select colors for **{UMD Color 2}**, **{UMD Color 3}** and **{UMD Color 4}** in the same manner.

Once colors are assigned, use the **{UMD Color}** button on the **Multiviewer Setup Menu** to assign colors to specific PIP UMDs.

Note

Remember that UMD colors can be used to “group” sources. For example, if you want to visually distinguish your cameras or servers from other Multiviewer sources, create and assign a custom UMD color.

Clock Setup Menu

From the **Multiviewer Setup Menu**, press **{Clock Setup}** to display the **Clock Setup Menu**. These functions apply whenever a layout is selected that includes a clock.

Two functions are available:

Press **{Clock Source}** to toggle the clock source between **Internal** and **LTC**.



7. Multiviewer Operations

Multiviewer Menu Orientation

- When set to **Internal**, as shown in the figure below, the system's internal clock is displayed. Remember that time is set on the **User Preferences Menu**. In Chapter 4, refer to the "[User Preferences Menu](#)" section on page 151 for details.




Figure 7-6. Multiviewer Clock Setup Menu, Internal Source (sample)

7. Multiviewer Operations

Multiviewer Menu Orientation

- When set to **LTC**, as shown in the figure below, the Multiviewer card's **LTC** (Longitudinal Time Code) **Input** is used. In Chapter 2, refer to the "[Multiviewer Card](#)" section on page 45 for details on the types of time code connections that can be used.




Figure 7-7. Multiviewer Clock Setup Menu, LTC Source (sample)

Press **{Clock Display}** to toggle the clock between **12 HR** and **24 HR** modes.



Assign Source Keypad

From the **Multiviewer Setup Menu**, press **{Assign Source}** to display the **Assign Source Keypad**. This keypad enables you to assign a source to the highlighted PIP (as indicated in the **Multiviewer Table**).




Figure 7-8. Assign Source Keypad (sample)

In the keypad, use the up (▲) and down (▼) arrows to locate the desired source in the list, then press **{Apply}** to accept. When a source is assigned, its current name appears in the PIP's UMD — but this name can be changed using the **{UMD Text}** function.

Three types of PIP sources are available:


Press **{Sources}** to assign input sources to the selected PIP, e.g., those sources that appear on the GUI.



Press **{Aux}** to assign Aux output video to the selected PIP, e.g., **Aux 1**, **Aux 2**, etc. Note that these Aux PIPs will not reflect Aux output scaling.



Press **{Other}** to assign Still Buffers to the selected PIP, e.g., **Program**, **Preview**, **M/E 1 PGM**, etc.



7. Multiviewer Operations

Multiviewer Setup

Multiviewer Setup

Comprehensive Multiviewer setup instructions are provided in Chapter 5. Refer to the [“Multiviewer Setup”](#) section on page 178 for complete details.

Multiviewer Memory

Multiviewer setups and layouts (including all PIPs, sources and names) can be stored and recalled using the FSN-1004 memory system.

- Use the following steps to store a Multiviewer layout in a memory register:
 1. Set up the Multiviewer in the exact configuration that you want stored.
 2. On the **Keypad**, press **STORE**. By default, all available modules light in the keypad’s **Module Section**.
 3. De-select all modules except for **SYS**.
 4. Enter the desired memory register number.
 5. Navigate to the **Memory Menu**. The selected register will be highlighted in the table, and the “**STORE**” banner will be lit red.
 6. Press **{Enables}** to display the **Enables Menu**.
 7. In the “Enables” box, toggle off all Enables except for **Multiviewer**.
 8. Press **{Description}** to display the **Keyboard**.
 9. Enter the desired register description and press **{Enter}**.

Note

In **Store Mode**, the description will not appear in the register table until **ENTER** is pressed on the **Keypad**.

10. Press **ENTER** on the **Keypad**. The Multiviewer layout is now stored, and available for recall as desired.

7. Multiviewer Operations

Multiviewer Memory

7. Multiviewer Operations

Multiviewer Memory

8. Updating Software

In This Chapter

This chapter provides detailed instructions for updating FSN-1400 system software and FSN-1004 GUI software. The following topics are discussed:

- [Software Update Overview](#)
- [Hardware Requirements](#)
- [Downloading Software](#)
- [Updating FSN-1400 Software](#)

8. Updating Software

Software Update Overview

Software Update Overview

Firmware files for the FSN-1400 are loaded into the hardware at power-up. These files are stored in the unit's onboard flash memory. Two different update procedures can be performed:

- **Update FSN-1400 and FSN-1004 GUI**—This procedure updates both the FSN-1400 firmware and the FSN-1004 GUI software running on your PC.
 - **Update FSN-1400 only** — This procedure updates only the FSN-1400 firmware. Use this procedure if the label “**Mismatch**” appears in the **System Status Table** on the **System Menu**.
- For a new software update, here are the steps required:
1. Verify your hardware. Refer to the “[Hardware Requirements](#)” section below.
 2. Download the appropriate update file. Refer to the “[Downloading Software](#)” section on page 217.
 3. To update the GUI, unzip the update file and launch the PC application.
 4. To update the FSN-1400, refer to the “[Updating FSN-1400 Software](#)” section on page 219.

Hardware Requirements

The following hardware items are required for upgrading FSN-1400 software:

- IBM-compatible computer with an available Ethernet port.
- Internet connection.

Downloading Software

Two different methods can be used to download FSN-1400 software:

- [Via FTP Site](#)
- [Via Web Site](#)

Via FTP Site

Barco Folsom's FTP site address is: <ftp.folsom.com>

■ To download software from the FTP site:

1. Create a target folder on your PC (e.g., FSN-1400), and ensure that your PC is connected to the internet.
2. Log on to the FTP site using one of the following methods:
 - a. If you are using an FTP client such as **Ipswitch WS_FTP Professional**, log on to our site as follows:
 - **FTP Site:** ftp.folsom.com
 - **User name:** anonymous
 - **Password:** your email address

▲ **Example:** johndoe@somecompany.com
 - b. If you are using a web browser, point the browser to:
ftp://ftp.folsom.com

Note

If you are using **Internet Explorer 7**, after entering the FTP address, click **Page**, and then click **Open FTP Site in Windows Explorer**.

- c. To use Windows Explorer, right-click the **Start** button, then click **Explore**. When the Explorer window opens, enter the FTP site in the address bar.
3. On the FTP site, navigate to the following directory:
ftp://ftp.folsom.com/Image Processing/FSN-1004/
 4. Transfer the following file to the target folder on your PC:
FSN_[revision #].tar.gz

8. Updating Software

Downloading Software

Via Web Site

Barco's web site address is: www.barco.com

- To download software from the web site:
 1. Create a target folder on your PC (e.g., FSN-1400), and ensure that your PC is connected to the internet.
 2. On the web, navigate to:

<http://www.barco.com>
 3. Navigate to the “**Presentation Systems**” home page:

<http://www.barco.com/corporate/en/products/>
 4. Log in to the **Barco Partnerzone** using your **User Name** and **Password**.
 5. Locate the “**Software Updates**” section, and click “**more software updates.**”
 6. Click the **Folsom Image Processing** tab.
 7. Scroll to the **Presentation Systems/Switchers** section, and click the link for the FSN-1400 switcher.
 8. Click the link for the latest version of code:

FSN-1004_[revision #].tar.gz
 9. Click the **Download** button.
 10. When the **File Download Dialog** appears, click **Save**.
 11. When the **Save As Dialog** appears, navigate to the target folder on your PC, and then click **Save**.

Updating FSN-1400 Software

This procedure updates the FSN-1400 software. This step is required:

- If the label “**Mismatch**” appears in the **System Status Table** on the **System Menu**.
- Use the following steps to update FSN-1400 software.
1. If you are not already there, navigate to the **Software Menu**:
 - ~ In the **Navigation Bar**, press **{System}** to display the **System Menu**.
 - ~ Press **{Software}** to display the **Software Menu**.
 2. Press **{Update FSN-1400}**.
 3. In the confirmation pop-up, press **{Yes}**. A pop-up alerts you that the update is in progress.
 4. When prompted in the pop-up, press **{Restart}** to restart the system.



Important

If desired, press **{Close}** to clear the pop-up and display the **Software Menu**. This action will not terminate the “restart” procedure.

If the system fails to restart after several minutes, you can return to the **System Menu** and check the **Communications Setup Menu**. In Chapter 4, refer to the “[Communications Setup Menu](#)” section on page 112 for details.

5. When the pop-up clears, your system is fully updated and ready for operation.

8. Updating Software

Updating FSN-1400 Software

A. Specifications

In This Appendix

This appendix provides detailed technical specifications for the FSN-1004. The following topics are discussed:

- [System Specifications Overview](#)
- [Reference Video Output Specifications](#)
- [Physical and Electrical Specifications](#)
- [Communications Specifications](#)
- [Agency Specifications](#)
- [Cable Specifications](#)
- [Delay Specifications](#)
- [Pinouts](#)
- [Output Format Tables](#)

A. Specifications

System Specifications Overview

System Specifications Overview

The table below provides an overview of all FSN-1004 specifications.

Table A-1. FSN-1004 Specifications Overview

Card	Type	Format
UIC	2 x SDI inputs	SMPTE 425 (3G-SDI), 292M (HDTV), 259M-C (NTSC/PAL)
	2 x DVI inputs	DDWG 1.0
	2 x Analog inputs	RGBHV/RGBS/RGsB, YPbPr video, S-video, Composite
M/E	6x Aux SDI Outputs	SMPTE 425 (3G-SDI), 292M (HDTV)
SYS	SDI ref Input/Loop/Output	SMPTE 292M(HDTV), 259M-C(NTSC/PAL)
	GPIO	4 input (GPI), 8 output (GPO)
	Tally outputs	24 contacts
	2 x Serial Com	RS-232
	Ethernet	10/100 Base-T on RJ-45
SOC	2 x SDI outputs	SMPTE 425 (3G-SDI), 292M (HDTV), 259M-C (NTSC/PAL)
	2 x DVI outputs	DDWG 1.0
	2 x Analog outputs	RGBHV/RGBS/RGsB, YPbPr video, S-video, Composite
MVR	2x DVI outputs	DDWG 1.0
	2x SDI outputs	SMPTE 425 (3G-SDI), 292M (HDTV)

Reference Video Output Specifications

On the **Reference and Output Setup Menu**, you can toggle the **{Reference Out}** button between **Tri-Level Sync** and **Black Burst**. Please note:

- The sync out format (as provided on the **Ref Out BNC**) changes, depending on the selected native video format.
- All **SD** sync out formats are black burst.
- All **HD** sync out formats are tri-level.

The table below illustrates which sync out format is provided, based on each available native video format selection.

Table A-2. FSN-1004 Sync Out Formats

Native Video Format	Sync Out Format
1080p @ 50	1080p @ 50 (tri-level only)
1080p @ 59.94	1080p @ 59.94 (tri-level only)
720p @ 50	625i @ 50
720p @ 50	1080i @ 50
720p @ 50	720p @ 50
720p @ 59.94	525i @ 59.94
720p @ 59.94	1080i @ 59.94
720p @ 59.94	720p @ 59.94
BarcoLink @ 50	N/A
BarcoLink @ 59.94	N/A

A. Specifications

Physical and Electrical Specifications

Physical and Electrical Specifications

The table below lists FSN-1004 physical and electrical specifications.

Table A-3. FSN-1004 Physical and Electrical Specifications

Parameter	Detail	Specification
Power	Connector x 2	Standard IEC, integral on/off switch
		100-240 VAC, 50-60 Hz, 800 watts max. (each supply)
Dimensions	RU	6
	Height	10.5 inches (26.67 cm)
	Width	19.00 inches (48.26 cm)
	Depth	20.75 inches (52.70 cm)
Weight		77.0 lbs (34.92 kg)
Temperature		0-40 degrees C
Humidity		0-95% non-condensing

Communications Specifications

The table below lists FSN-1004 communications specifications.

Table A-4. FSN-1004 Communications Specifications

Parameter	Detail	Specification
FSN-1004	Ethernet	10/100 Mbps
	RS-232 Diagnostic	8, N, 1 @ 115.2 kbaud

Agency Specifications

The table below lists FSN-1004 agency specifications.

Table A-5. FSN-1004 Agency Specifications

Parameter	Detail	Specification
Agency Specifications	EMI/EMC	EN55103-1 E4, EN55103-2, FCC Part 15 Subpart B Class A
	Safety	EN 60950 Class 1

Cable Specifications

The table below lists the recommended specifications for digital video cable.

Table A-6. Digital video cable recommended specifications

Parameter	Detail	Specification
Digital video cable	Belden 1694A	300m at 270Mbps (SD-SDI)
	Belden 1694A	100m at 1.485Gbps and 1.485/1.001Gbps (HD-SDI)

A. Specifications

Delay Specifications

Delay Specifications

The table below summarizes the amount of delay incurred for a selected UIC universal input:

Table A-7. Universal input delay

Universal Input Delay	Input video is $\leq \pm 1/2$ line of reference	Input video is $\geq \pm 1/2$ line of reference
	1 frame delay	2 frames delay

Pinouts

The following topics are discussed in this section:

- [Analog 15-pin D Connector](#)
- [DVI-I Connector](#)
- [Ethernet Connector](#)
- [Serial Connectors](#)

Analog 15-pin D Connector

The figure below illustrates the analog 15-pin D connector:




Figure A-1. Analog 15-pin D connector

The table below lists Analog 15-pin D connector pinouts.

Table A-8. Analog 15-pin D Connector Pinouts

Pin	Signal	Pin	Signal
1	Red	9	+5V Power
2	Green	10	GND
3	Blue	11	
4		12	DDC Data
5		13	H Sync or C Sync
6	Red return	14	V Sync
7	Green return	15	DDC Clock
8	Blue return		

A. Specifications

Pinouts

DVI-I Connector

The figure below illustrates the DVI-I connector:




Figure A-2. DVI-I connector

The table below lists DVI-I connector pinouts. Please note:

- T.M.D.S = Transition Minimized Differential Signal
- DDC = Display Data Channel

Table A-9. DVI-I Connector Pinouts

Pin	Signal	Pin	Signal
1	T.M.D.S. Data 2-	13	T.M.D.S. Data 3+
2	T.M.D.S. Data 2+	14	+5V Power
3	T.M.D.S. Data 2/4 Shield	15	ground (for +5V)
4	T.M.D.S. Data 4-	16	Hot Plug Detect
5	T.M.D.S. Data 4+	17	T.M.D.S. Data 0-
6	DDC Clock	18	T.M.D.S. Data 0+
7	DDC Data	19	T.M.D.S. Data 0/5 Shield
8	Analog Vertical Sync	20	T.M.D.S. Data 5-
9	T.M.D.S. Data 1-	21	T.M.D.S. Data 5+
10	T.M.D.S. Data 1+	22	T.M.D.S. Clock Shield
11	T.M.D.S. Data 1/3 Shield	23	T.M.D.S. Clock +
12	T.M.D.S. Data 3-	24	T.M.D.S. Clock -
MicroCross Pins			
C1	Analog Red Video	C4	Analog Horizontal Sync
C2	Analog Green Video	C5	Analog Common Ground Return
C3	Analog Blue Video		

Note

Pins **C1**, **C2**, **C3**, **C4**, and **C5** are not used on the FSN-1004.

Ethernet Connector

The figure below illustrates the Ethernet connector:




Figure A-3. Ethernet connector

The table below lists Ethernet connector pinouts.

Table A-10. Ethernet Connector Pinouts

Pin	Signal	Wire Color
1	TX Data +	White / Orange
2	TX Data -	Orange
3	RX Data +	White / Green
4		Blue
5		White / Blue
6	RX Data -	Green
7		White / Brown
8		Brown

A. Specifications

Pinouts

Serial Connectors

The figure below illustrates the 9-pin D RS-232 serial connector:




Figure A-4. Serial 9-pin D connector

The table below lists 9-pin D connector pinouts for the **System Card**'s front serial RS-232 diagnostic port:

Table A-11. System Card 9-pin D Front Diagnostic Port Pinouts

Pin	Signal	Pin	Signal
1	CD - Carrier Detect	6	DTR - Data Terminal Ready
2	TXD - Transmitted Data	7	CTS - Clear To Send
3	RXD - Received Data	8	RTS - Request To Send
4	DSR - Data Set Ready	9	Unused
5	GND - Signal Ground		

The table below lists 9-pin D connector pinouts for the **System Card**'s two rear serial ports:

Table A-12. System Card 9-pin D Rear Serial Port Pinouts

Pin	Signal	Pin	Signal
1	GND - Signal Ground	6	GND - Signal Ground
2	RX-	7	RX+
3	TX+	8	TX-
4	Ground	9	Ground
5	Unused		

Output Format Tables

Output Formats

The table below lists the available output formats supported on the M/E card.

Table A-13. M/E Card Output Formats

Standard	Format
SMPTE 292M	1280 x 720p @ 50
	1280 x 720p @ 59.94
SMPTE 425	1920 x 1080p @ 50
	1920 x 1080p @ 59.94
	BarcoLink @ 50
	BarcoLink @ 59.94

A. Specifications

Output Format Tables

B. Contact Information

In This Appendix

The following topics are discussed in this Appendix:

- [Warranty](#)
 - [Return Material Authorization \(RMA\)](#)
 - [Contact Information](#)
-

Warranty

All video products are designed and tested to the highest quality standards and are backed by a full 3-year parts and labor warranty. Warranties are effective upon delivery date to customer and are non-transferable. Barco warranties are only valid to the original purchaser/owner. Warranty related repairs include parts and labor, but do not include faults resulting from user negligence, special modifications, lightning strikes, abuse (drop/crush), and/or other unusual damages.

The customer shall pay shipping charges when unit is returned for repair. Barco will cover shipping charges for return shipments to customers.

Return Material Authorization (RMA)

In the unlikely event that a product is required to return for repair, please call the **Technical Support / Customer Service** direct line, and ask to receive a Return Merchandise Authorization number (RMA).

- (866) 374-7878

RMA Conditions are listed below:

- a. Prior to returning any item, you must receive a **Return Merchandise Authorization (RMA)** number.
- b. All RMA numbers must appear on their return-shipping label.
- c. RMA numbers are valid for ten (10) days from issue date.
- d. All shipping and insurance charges on all RMAs must be prepaid by the customer

B. Contact Information

Contact Information

Contact Information

Barco Media and Entertainment

11101 Trade Center Drive
Rancho Cordova, California 95670
USA

- Telephone: (916) 859-2500
- Fax: (916) 859-2515
- Website: www.barco.com

Sales Contact

- Direct: (916) 859-2505
- Toll Free: (888) 414-7226
- E-mail: folsomsales@barco.com

Barco N.V.

Noordlaan 5
8520 Kurne
BELGIUM

- Telephone: +32 56.36.82.11
- Fax: +32 56.35.16.51
- Website: www.barco.com

Technical Support (USA)

- Telephone: (866) 374-7878 — 6 a.m. to 10 p.m. (PST), 7 days per week
- E-mail: folsomsupport@barco.com
- Online: www.barco.com/esupport

Technical Support (Europe, Middle East, Asia)

- Telephone: 0800900410
- Online: www.barco.com/support/eSupport.aspx

Index

Softkeys and Symbols

{1-1 Sample}	127	{Discover FSN-1004}	113
{Active and Pos}	146, 176	{Dual Output Layouts}	206
{Adjust H Timing}	127	{DVI Sync}	144, 175, 203
{Adjust V Timing}	128	{EDID Format}	125
{Advanced Output Setup}	142, 145, 175, 176	{Enables}	89, 92, 95, 96
{Advanced}	89, 96	{Enter}	84
{All Inputs}	94	{Error Reporting}	121, 187
{All Off}	93, 157	{Factory Reset}	161
{All On}	93	{Fill H}	131, 147
{Analog Sync}	144, 175	{Fill H/V}	132, 148
{Analog Type}	144, 175	{Fill V}	132, 147, 176
{Apply}	112	{Flicker Filter}	128, 143, 175
{Aspect Ratio}	148, 176	{Freeze}	121
{Assign Source}	202, 212	{Gamma}	135
{Auto Acquire}	124	{Green Bright}	135
{Aux 1 - 14}	94	{Green Contrast}	136
{Aux Name}	175	{H Active}	127
{Aux}	212	{H Pos}	127
{Backup and Restore}	110, 160	{H Position}	131
{Backup System}	160	{H Size}	131
{BG Color}	208	{H Total}	128, 145
{Blue Bright}	135	{Hue Sat}	136, 150
{Blue Contrast}	136	{Hue}	136
{Border Color}	208	{Info}	119
{Bright Contrast Gamma}	135, 150	{Input Format}	125
{Bright}	135	{Input Name}	121
{Caps Lock}	85	{Input Setup}	109
{Clear Text}	85	{Lock GUI}	110
{Clear}	83	{Lock Panel}	158
{Clock BG Color}	208	{Lock Unlock}	98
{Clock Display}	211	{Lock}	131, 133
{Clock Setup}	202, 209	{Mask Bottom}	133
{Clock Source}	209	{Mask Left}	133
{Close}	83	{Mask Right}	134
{Color Correct}	150, 177	{Mask Top}	133
{Color Space}	127	{Mask}	133, 149, 176
{Com Setup}	109, 112	{Memory Register}	93, 95
{Contrast}	135	{Mode}	202
{Copy All Settings}	144, 175	{Motion Threshold}	129
{De-Interlace}	129, 143	{Multiviewer Setup}	109, 137, 201
{Delete Register}	97	{Offset Timing Info}	146
{Description}	89, 90, 91, 95	{Offset Timing}	146, 176
		{Other}	212
		{Out Name}	140
		{Output Format}	142, 203

Index

{Output Setup} 109, 138, 175, 202, 203
{Output Test Patterns} 109, 156
{Pan Zoom Source} 133, 148, 176
{Pulldown Comp} 129
{Raster Box} 157
{Red Bright} 135
{Red Contrast} 136
{Reset To 1004 Defaults} 161
{Reset to Default} 153
{Reset} 110, 131, 161
{Restart} 160
{Restore Default Settings} . . . 116, 136, 144, 175
{Restore Saved Settings} 136
{Restore System} 160
{RGB Bright} 135, 150
{RGB Contrast} 136, 150
{Sample Phase} 127
{Sat} 136
{Save All} 110, 158
{Save Settings} 136
{Select All Outputs} 157
{Select Colors} 202, 208
{Select Layout} 202, 204
{Set Clock} 152, 180
{Set IP Address} 112, 115
{Set Subnet Mask} 116
{Set} 152
{Setup} 122
{Sharpness} 128, 143
{Single Output Layouts} 205
{Size and Position} 130, 147, 176
{Sizing and Scaling} 130, 146
{Soft Reset FSN-1400} 162
{Software} 109, 153
{Source H Position} 133
{Source H Size} 133
{Source V Position} 133
{Source V Size} 133
{Sources} 212
{Sync} 146, 176
{Tally} 94
{Totals} 145, 176
{Trim -} 83
{Trim +} 84
{UMD Color 1} 209
{UMD Color} 202
{UMD Text} 202
{Undo} 83
{Unlock} 158
{Update FSN-1004} 155, 219
{User Prefs} 109, 151
{V Active} 128
{V Pos} 128
{V Position} 131
{V Size} 131
{V Total} 146
{View Error Info} 187

Numerics

1-1 Sampling 127

A

About the FSN Series 18
AC
 power 33
 power and voltage selection 58
Access
 memory menu 87
 system menu 108
Acrobat usage 15
 navigating and searching 15
Address, company 3
Adjust
 color correction 135
 color correction, output 150
 SOC H and V active 176
 SOC H and V sync 176
 SOC offset timing 176
 SOC output timing 176
 UOC H and V active 146
 UOC H and V sync 146
 UOC offset timing 146
 UOC output 142
 UOC output parameters 145
 UOC output timing 146
Advanced
 memory functions 95
 SOC setup menu 145, 175, 176
 UOC setup menu 142
Agency specifications 225
Air vents 32
ALL
 SAVE 158
Analog
 15-pin D connector pinouts 227
 format connection table 48
 input flexibility 48, 67
 sync polarity 144, 175
 sync type 144, 175
Application questions 23
Aspect ratio
 output 148, 176
Auto
 acquire 124
 acquire, notes 124
Aux
 enables 94
 memory functions 189
 menu 105
 output connections 65
 outputs, native 40

- slot 139
 - table, description 139
- B**
- Backspace 83
 - Backup
 - and restore menu 160
 - system 160, 181
 - Bar
 - function, keypad 82
 - menu 73
 - prompt 72
 - title 72
 - tool 73
 - Barco
 - contact information 234
 - sales contact information 234
 - technical support information 3, 234
 - warranty 233
 - Basic system 20
 - Black on invalid video 152
 - Block diagram, system 21
 - BNC breakout cable 48, 67
 - Boxes, shipping information 50
 - Brightness, input 135
 - Button
 - categories and color 74
 - conditional 76
 - function 74
 - latching 75
 - location 77
 - momentary 75
 - navigation 75
 - pop-up 77
 - summary of types 79
 - toggle 76
 - value 76
 - Buttons, tables, matrices 74
- C**
- Cable
 - and adapter information 50
 - specifications 225
 - Card
 - descriptions 34
 - ejectors 36
 - FPGA loaded LED 47
 - insertion 61
 - installation 59
 - LEDs, front edge 47
 - M/E 39
 - multiviewer 45, 198
 - power LED 47
 - removal 63
 - slot allocation 27
 - SOC 43
 - standard output 43
 - system 35
 - UIC 41
 - universal input 41
 - Change history 6
 - Chapter structure 14
 - Chassis
 - front view 30
 - overview 26
 - rear view 32
 - Clear 83
 - text 85
 - Clock
 - 12 HR or 24 HR 211
 - internal or LTC 209
 - multiviewer 199
 - set 152, 180
 - setup menu 209
 - Close keypad 83
 - Color
 - correction adjustments 135
 - correction adjustments, output 150
 - multiviewer 198
 - space 127
 - space, RGB 127
 - space, SMPTE 127
 - Colors, connectors, rear panel view 119
 - Communications
 - setup 168
 - setup menu 112
 - specifications 225
 - Company address 3
 - Conditional
 - buttons 76
 - Configuration, system 20
 - Connection
 - analog format table 48, 67
 - aux outputs 65
 - multiviewer 68
 - signals 64
 - system 55
 - Connectivity diagram, system 21
 - Connector
 - analog 15-pin D pinouts 227
 - colors 119
 - DVI-I pinouts 228
 - Ethernet 37
 - Ethernet pinouts 229
 - reference input 37
 - serial, pinouts 230
 - Contact information 233, 234
 - Contrast, input 135
 - Conventions 15

Index

menu system	72
Copy	
settings	144, 175
Copyright	2
CPU	
reset switch	36
Crosspoint M/E Card	20
Customer service portal	3

D

Decimal	84
Decimal entry	84
Default	
factory	167
factory settings	162
naming conventions	122
Default IP address	36, 38
De-interlace	129
output	143
Delay	
specifications	226
Deleting memory registers	97, 195
Description	
aux table	139
cards	34
enable	94
enables menu	92
input table	120
matrices	81
memory menu	88, 99
memory register	89
menu	69
notes and error messages	81
rear panel view	118
rear panel view, Aux setup	139
system menu	108
tables	80
Diagnostics	
port	36
Diagram, system connectivity	21
Discover	113
pop-up	113
Documentation conventions and symbols	15
Door latch	28
Download software	217
via FTP site	217
via web site	218
DVI	
sync polarity	144, 175
sync polarity, multiviewer	203
DVI-I connector pinouts	228

E

EDID format	125
Ejectors, card	36
Electrical specifications	224
Enable descriptions	94
Enables	
aux	94
menu	86
menu description	92
menu sections	92
section	93
system	94
Enter	84
Equipment marking terms	5
Error	
messages	81
messages, understanding	186
multiviewer indications	199
reporting	121, 187
Ethernet	
connections	38
connector	37
connector pinouts	229
status table	112
Extended Display Identification Data	125

F

Factory	
default settings	162
default, return to	167
reset	161
Fan	
tray	31
FCC statement	2
Field to frame	129
Fill	
H	131
H, output	147
H/V	132
H/V, output	148
V	132
V, output	147, 176
Flicker filter	128
output	143, 175
Format	
connection table, analog	67
EDID	125
input	120, 125
FPGA loaded LED	36
Freeze	
input	121
multiviewer indications	199
Front door	28

hinges	29
removal and re-installation	29
status LEDs	28
FSN Series	
about	18
basic system	20
block diagram	21
card slot allocation	27
connectivity diagram	21
hardware description	26
hardware installation	49
introduction to	13
menu tree	70
multiple destinations	22
multiviewer operations	197
operation	183
overview	18
required cards	20
specifications	221
system configuration	20
updating software	215
FSN system	
card slot allocation	59
Ethernet connector	37, 38
front door	28
front view	30
hardware orientation	25
overview	26
rack mount procedure	53
rear view	32
reference input connector	37
status table	110, 154
system connections	55
FTP site	217
Function	
bar, keypad	82
buttons	74
input setup menu, tool bar	136
quick reference table	186
Functions	
input menu	121
output setup menu	140
save all	158
software	154
system menu	109
user preferences	152

G

Gamma, input	135
Glossary of switcher terms	16
Guarantee and compensation	2

H

Hardware

description	26
installation	49
orientation	25
requirements, updating software	216

Hinges	29
---------------	----

History, change	6
------------------------	---

How to

assign multiviewer sources	179
assign multiviewer UMD color	179
back up system	181
back up the system	103, 104, 196
configure multiviewer color	178
connect Aux output signals	65
connect inputs to a UIC	66, 68
delete memory registers	195
display output test patterns	171
download software from FTP site	217
download software from website	218
insert a card	61
insert a rear panel	60
install system connections	55
install your PC	52
lock and unlock memory registers	194
map and name aux outputs	175
modify multiviewer UMD text	179
perform new software update	216
power up system, check status	166
rack mount FSN system	53
recall memory, adjust enables	192
recall memory, bypass enables	192
re-install front door	29
remove a card	63
remove front door	29
restore the system	196
return to factory default	167
save all system parameters	181
save input settings	174
select multiviewer layout	178
set up advanced SOC parameters	176
set up aux output format	175
set up communications	168
set up multiviewer clock	178
set up multiviewer output	178
set up output color correction	177
set up output format	170
set up output sizing, scaling	176
set up universal input	172
set up universal input capture, timing	172
set up universal input color correction	174
set up universal input processing	173
set up universal input sizing, scaling	173
set up user preferences	180
store memory, set enables	190

Index

store multiviewer in memory	213
update software	219
use menu system	72
use this guide	15
view memory registers	194
Hyperlinks	15

I

Input	
brightness	135
capture and process panel	124
capture and timing section	124
card rear panel	32
color correction section	135
color legend pop-up	119
connections, UIC	66
contrast	135
error reporting	121
flexibility, analog	48, 67
format	120, 125
format table	231
freeze	121
gamma	135
map	120
menu	117
menu functions	121
name	120, 121
power	58
processing section	128
scaling	130
setup menu	122
setup menu tool bar functions	136
setup menu, universal inputs	123
sizing and scaling panel	129
slot	120
table	120
Insertion	
card	61
rear panel	60
Inspection	50
Installation	
card	59
hardware	49
PC	52
rack mount	53
rear panel	59
safety precautions	50
shipping information	50
site preparation	50
unpacking and inspection	50
Introduction	
to multiviewer	198
to the FSN Series	13
Invalid	
signal	81

video	186
Invert numeric entry, +/-	83
IP address	112
change	115
default	36
reset switch	36

K

Keyboard	
using pop-up	85
Keypad	
assign multiviewer source	212
function bar	82
notes	84
output format	203
register	82
set clock	152, 180
touch screen	188
UOC output format	142
using	82, 188

L

Latching	
buttons	75
momentary and conditional buttons	75
LED	
card front edge	47
card power	47
FPGA loaded	36, 47
power	28
system power	35
video reference	29, 36
Line voltage selection	58
Location buttons	77
Lock	88
memory registers	194
Locking and unlocking registers	96, 97
Loop, reference	37
LOS	186
loss of signal	81
Loss of signal	186

M

M/E	
card	39
card components	39
card connectors	39
card rear panel	32
MAC	113
Map	

input	120	multiviewer output setup	203
Mask		multiviewer setup	137, 201
output	149	orientation	69
preset functions	134	output setup	138
preset functions, output	149	output test patterns	156
presets section	134	reset	161
presets section, output	149, 176	rules and conventions	72
Matrices, description	81	select multiviewer colors	208
Memory		select multiviewer layout	204
advanced functions	95	SOC setup	141
AUX functions	189	software	153
delete registers	195	system	107
deleting registers	97	tree	70
functions table	190	usage, rules	72
lock and unlock registers	194	user preferences	151
locking and unlocking registers	96, 97	Menu Tree	70
menu	86, 99	Midplane architecture	26
menu access	87	Mode	
menu description	88, 99	recall	86
multiviewer	213	store	86
naming registers	95	view	86
recall mode	86	Module	
recall notes	193	section	93
recall registers	192	Momentary buttons	75
recall, add modules	193	Motion	
recall, adjust enables	192	adaptive	129
recall, bypass enables	192	threshold	129
recall, remove modules	193	Multiviewer	20
register overview	189	assign source keypad	212
registers, working with	189	card	45, 198
selecting registers	95	card connectors	45
store mode	86	clock	199
store notes	191	clock setup menu	209
store, add modules	191	color selection	198
store, remove modules	191	connections	68
store, set enables, custom name	190	error indications	199
storing registers	190	freeze indications	199
summary of functions, table	86	introduction to	198
SYS functions	189	memory	213
table	88	menu orientation	200
view mode	86	monitor configurations	198
view registers	194	operations	197
Memory Auto Lock	152	output format keypad	203
Menu		output setup menu	203
advanced SOC setup	145, 175, 176	PIP enable/disable	198
advanced UOC setup	142	select colors menu	208
aux	105	select layout menu	204
backup and restore	160	set clock	152
bar	73	setup	178, 213
clock setup	209	setup menu	137, 201
communications setup	112	table	201
description	69	UMD tally	198
enables	86	UMD text	199
input	117	MVR	20, 45
input setup, universal inputs	123		
memory	86, 99		
multiviewer orientation	200		

Index

N

Name	
conventions	122
input	120, 121
PGM	140
Naming memory registers	95
Native	
aux outputs	40
resolution	49
Navigation buttons	75
Notes	
and error messages	81
auto acquire	124
keypad	84
memory recall	193
memory register storage	191
pop-up	81
Notice	2

O

Operation	
FSN Series	183
multiviewer	197
quick setup	184
system backup and restore	196
Operators safety summary	4
Orientation	
hardware	25
menu	69
multiviewer menus	200
Output	
and process panel	142
aspect ratio	148, 176
color correction panel	150
connector combinations, universal	44
de-interlace	143
flicker filter	143, 175
format	111, 154
format keypad	142, 203
format table	231
mask	149
pan zoom source	148, 176
processing section	143
PVW	140
quick adjust	147, 176
section	142
setup	170, 175
setup menu	138
setup menu functions	140
setup, multiviewer	203
sharpness	143
size and position	147, 176
sizing and scaling panel	146

sizing and scaling section	146
specifications, reference	223
status section	143
test patterns menu	156
test patterns setup	171
tool bar functions	144
universal	44, 46
Output Format Setup	170
Overview	
FSN series	18
FSN system	26
memory registers	189
software update	216
system specifications	222

P

Palette	73
Panel	
input capture and process	124
input sizing and scaling	129
lockout pop-up	158
output and process	142
output color correction	150
output sizing and scaling	146
soft reset	162
PC installation	52
PDF file usage	15
navigating and searching	15
Physical	
specifications	224
Pinouts	227
analog 15-pin D connector	227
DVI-I connector	228
Ethernet connector	229
serial connector	230
Plus/Minus (+/-)	83
Pop-up	
buttons	77
discover	113
input color legend	119
keyboard	85
note	81
panel lockout	158
working with	188
Power	
AC connectors	33
consumption	58
cord, line voltage selection	58
input	58
LED	28
precautions	58
supplies	30
up	166
Preset	
mask functions	134

mask functions, output	149
Program	
name	140
Prompt bar	72
Pulldown comp	129
PVW	
output	140

Q

Quick	
function reference table	186
setup and operations	184
Quick Adjust section	131
output	147, 176

R

Rack mount installation	53
Raster box	157
Rear	
view, chassis	32
Rear panel insertion	60
Rear panel installation	59
Rear panel removal	60
Rear panel view	117, 156
connector colors	119
description	118, 139
RECALL	87
Recall	
memory notes	193
memory registers	192
mode	86
Reference	
input	111, 154
input connector	37
loop	37
video output specifications	223
Reg	88
Register, keypad	82
Registers	
naming	95
selecting	95
Removal	
card	63
rear panel	60
Required cards	20
Reset	
factory	161
menu	161
soft	162
soft system	161
Reset switch	
CPU	36

IP address	36
Resolution, native	49
Restore	
default settings	136, 144, 175
saved settings	136
system	160
Return material authorization	233
RGB color space	127
RMA	233

S

Safety	
precautions	50
summary	4
Sample contact information	234
Sample phase	127
Sampling, 1-1	127
Save	
all	158
all, functions list	158
settings	136
Scale inputs	130
Section	
enables	93
enables menu	92
input capture and timing	124
input color correction	135
input processing	128
mask presets	134
mask presets, output	149, 176
module	93
output	142
output processing	143
output sizing and scaling	146
output status	143
quick adjust	131
quick adjust, output	147, 176
sizing and scaling	130
Select	
colors menu, multiviewer	208
Selecting memory registers	95
Sequence, system setup	165
Serial	
connector pinouts	230
Set	
clock	152, 180
clock keypad	152, 180
multiviewer clock	152
Settings, factory default	162
Setup	
back up system	181
communications	168
multiviewer	178, 213
output	170, 175
output format	170

Index

output test patterns	171
power up and status check	166
prerequisites	164
restore the system	169
return to factory default	167
save system parameters	181
sequence	165
system	163
universal inputs	172
user preferences	180
Sharpness	128
output	143
Shipping information, boxes	50
Signal	
connections	64
invalid	81
Site preparation	50
Sizing and Scaling section	130
Slot	
aux	139
input	120
SMPTE color space	127
SOC	20, 43
card components	43, 45
card connectors	43
setup menu	141
Soft	
reset	162
system reset	161
Software	
downloading	217
functions	154
menu	153
table	154
update	219
update overview	216
update, hardware requirements	216
updating	215
version	14
Specifications	221
agency	225
cable	225
communications	225
delay	226
electrical	224
input format table	231
overview	222
physical	224
pinouts	227
reference video output	223
Standard	
output card	43
Status	
check	166
LEDs	28
table, system menu	110
Store	87
mode	86
Storing, memory registers	190
Subnet mask	113, 116
Summary	
button types	79
memory functions	190
memory functions table	86
Support, technical information	3, 234
Symbols	15
SYS	
memory functions	189
System	
backup	160
backup and restore	196
card	20
card components	37
card connectors	35
card description	35
card rear panel	33
card slot	31
configuration	20
connections	55
enables	94
flexibility	27
menu	107
menu access	108
menu description	108
menu functions	109
menu, status tables	110
multiple destinations	22
power LED	35
restore	160, 169
save parameters	181
setup	163
setup prerequisites	164
setup sequence	165
soft reset	161
specifications overview	222
status LEDs	28

T

Table	
analog format connections	67
aux, description	139
card slot allocation	59
descriptions	80
dual monitor output, multiviewer	207
Ethernet status	112
format connections	48
input	120
input formats	231
memory functions summary	190
memory registers	88
multiviewer	201
output formats	231

quick function reference	186
single monitor output, multiviewer	207
software	154
Status	110, 154
status, system menu	110
summary of memory functions	86
user preferences	152
Tally	
multiviewer UMD	198
Technical support information	3, 234
Terms, equipment marking	5
Test patterns	
list	157
menu	156
setup	171
Text, clear	85
Timing	
adjust H	127
adjust V	128
Title bar	72
Toggle buttons	76
Tool bar	73
Touch screen	
keypad	188
Trademarks	3
Transition	
display contrast	152
Tree, menu	70
Trim -	83
Trim +	84

U

UIC	20, 41
analog format connection table	67
card components	41
card connectors	41
connection notes	66
input connections	66
UMD tally	198
Understanding	
error messages	186
Undo	83
Universal	
input card	41
input setup	172
output	44, 46
output connector combinations	44
Unlock memory registers	194
Unpacking	50
UOC	
output adjustments	142
output connections	65
Update	
FSN-1400 only	216
software	155, 215, 219

User preferences	
functions	152
menu	151
setup	180
table	152
Using	
keyboard, pop-up	85
keypad	82, 188

V

Value buttons	76
Video	
invalid	186
reference input	111, 154
reference LED	29, 36
View	
memory registers	194
mode	86

W

Warranty	233
Web site, download software	218
Working with	
memory registers	189
pop-ups	188

Index