

PDS 3G Series

Quick Start Guide

Barco Inc.
11101 Trade Center Drive
Rancho Cordova, CA
95670 • USA

Toll Free: +1 (888) 414-7226
Fax: +1 (916) 859-2515
Technical Support: +1 (866) 374-7878
Website: www.barco.com

EMEA Support
Website: www.barco.com/support/eSupport.aspx
Phone: 0800900410

Menu Display

Use **ADJUST** knob, plus **SEL** and **ESC** buttons to navigate menus.

Adjust

- **Counter-clockwise:** scroll down menu tree, or decrement values.
- **Clockwise:** scroll up menu tree, or increment values.

SEL

Press to enter a menu, change or accept a parameter, or answer "Yes" to a query.

Inputs Section


Sources 1-4: Analog
Sources 5-8*: DVI or Analog
SDI: 3G/HD/SD-SDI
LOGO/BLACK: Full screen capture
*(sources 7-8 not on PDS-701 3G)

Button States

Off: Input not selected
Blinking: Input "pending" for transition
Lit solid: Input on Program

LOGO/BLACK

Press to pend or initiate a black or logo transition.
Auto Take mode affects function (see *User Preferences*)
Blinking: Pending
Lit solid: Logo or Black on Program



ESC

Press to exit a menu without making changes, cancel an operation, or answer "No" to a query.

FRZ

Press to freeze or un-freeze current Program source.
Lit solid = frozen.

PIP1 and PIP2

Press to set up, transition to and transition from one or both PIPs.
(Output mode must be set to PIP.)

TAKE

Press to mix the selected input to Program, or to execute a pending black transition. Use the **Setup Menu** to adjust the transition time.

NOTE

After each **TAKE**, Program and pending sources flip-flop.

Quick Setup and Operations



The following list summarizes PDS setup and operations. For error-free installation, always refer to the listed section in the User's Guide.

1

Connect Power — Ensure that power is properly connected to the PDS. (Chapter 3, "Cable and Adapter Information")

2

Connect Inputs — Connect all analog, DVI, and SDI input sources to the PDS. (Chapter 3, "Signal Installation")

3

Connect Outputs — Connect the output(s) of the PDS to your projector(s) or other target devices. (Chapter 3, "Signal Installation")

4

Power On — Turn on power to the PDS, your projector(s), and to all peripheral equipment. (Chapter 4, "Power-Up Initialization")

5

Factory Reset — When using a PDS for the first time, perform a factory reset. (Chapter 4, "Factory Reset Menu")

6

Launch GUI — (Optional) Connect your laptop to the PDS, log onto the PDS using its IP address, and launch the GUI. (Chapter 5, "GUI Operations")

7

Set Output Format — Set the desired output resolution and frame rate. (Chapter 4, "Output Format")

8

Enable Test Pattern — Turn on a test pattern, verify an image, and adjust as required. When complete, turn off the pattern. (Chapter 4, "Test Pattern")

9

Save Output Configuration — After completing all output adjustments, save the output configuration. (Chapter 4, "Save Config")

10

Select and Adjust Input — Select an input, and perform the necessary image adjustments. (Chapter 4, "Input Menu")

11

Save Input Configuration — After completing all adjustments for an input, save the input configuration. (Chapter 4, "Save Config")

12

Repeat for Each Input — Repeat steps 10 and 11 for each input that you have connected to the PDS.

13

Adjust System Parameters — Adjust parameters such as transition time, display brightness, user prefs. (Chapter 4, "User Preference Menu," "System Menu")

14

Save System Configuration — After completing all system adjustments, save the system configuration. (Chapter 4, "Save System State")

15

Enable Remote Control — (Optional) Connect Ethernet or Serial communications, and issue desired commands. (Appendix B, "Remote Control")

16

Ready to Roll — With all output, input and system configurations saved, press the desired input button, and press **TAKE**.

